


brother®

BASIC USER'S GUIDE



DCP-J515W
DCP-J715W

Version 0

ARL/ASA/NZ/SAF

If you need to call Customer Service

Please complete the following information for future reference:

Model Number: DCP-J515W, DCP-J715W
(Circle your model number)

Serial Number: ¹ _____

Date of Purchase: _____

Place of Purchase: _____

¹ The serial number is on the back of the unit. Retain this User's Guide with your sales receipt as a permanent record of your purchase, in the event of theft, fire or warranty service.

Register your product on-line at

<http://www.brother.com/registration/>

User's Guides and where do I find it?

| Which manual? | What's in it? | Where is it? |
|------------------------------|--|---------------------------------|
| Safety and Legal | Please read the Safety Instructions before you set up your machine. | Printed / In the box |
| Quick Setup Guide | Read this Guide first. Follow the instructions for setting up your machine and installing the drivers and software for the operating system and connection type you are using. | Printed / In the box |
| Basic User's Guide | Learn the basic Copy, Scan and PhotoCapture Center™ operations and how to replace consumables. See troubleshooting tips. | Printed / In the box |
| Advanced User's Guide | Learn more advanced operations: Copy, printing reports and performing routine maintenance. | PDF file / Documentation CD-ROM |
| Software User's Guide | Follow these instructions for Printing, Scanning, Network Scanning, PhotoCapture Center™, and using the Brother ControlCenter utility. | PDF file / Documentation CD-ROM |
| Network User's Guide | This Guide provides more advanced information for configuring the Ethernet and Wireless network connections. In addition, find information about network utilities, network printing, troubleshooting tips and supported network specifications. | PDF file / Documentation CD-ROM |

Table of Contents

(BASIC USER'S GUIDE)

| | | |
|----------|---|-----------|
| 1 | General information | 1 |
| | Using the documentation | 1 |
| | Symbols and conventions used in the documentation | 1 |
| | Accessing the Advanced User's Guide, Software User's Guide and Network User's Guide..... | 1 |
| | Viewing Documentation..... | 1 |
| | Accessing Brother Support (Windows®)..... | 3 |
| | Accessing Brother Support (Macintosh) | 3 |
| | Control panel overview | 4 |
| | LCD display indications | 5 |
| | Basic Operations | 6 |
| | Warning LED indications | 6 |
| | LCD display | 7 |
| | Setting the backlight brightness..... | 7 |
| 2 | Loading paper | 8 |
| | Loading paper and other print media..... | 8 |
| | Loading envelopes and postcards..... | 10 |
| | Loading photo paper..... | 12 |
| | Removing small printouts from the machine | 14 |
| | Printable area | 15 |
| | Paper settings..... | 16 |
| | Paper Type | 16 |
| | Paper Size | 16 |
| | Acceptable paper and other print media..... | 17 |
| | Recommended print media | 17 |
| | Handling and using print media..... | 18 |
| | Choosing the right print media..... | 19 |
| 3 | Loading documents | 21 |
| | How to load documents | 21 |
| | Using the ADF (DCP-J715W only) | 21 |
| | Using the scanner glass | 21 |
| | Scannable area | 22 |
| 4 | Making copies | 23 |
| | How to copy | 23 |
| | Stop copying..... | 23 |
| | Copy settings..... | 23 |
| | Paper options | 24 |

| | | |
|----------|---|-----------|
| 5 | Printing photos from a memory card or USB Flash memory drive | 25 |
| | PhotoCapture Center™ Operations..... | 25 |
| | Using a memory card or USB Flash memory drive | 25 |
| | Getting started | 26 |
| | Print Images..... | 28 |
| | View Photos..... | 28 |
| | PhotoCapture Center™ print settings..... | 28 |
| | How to scan to a memory card or USB Flash memory drive..... | 29 |
| 6 | How to print from a computer | 31 |
| | Printing a document..... | 31 |
| 7 | How to scan to a computer | 32 |
| | Scanning a document..... | 32 |
| | Scanning using the scan key | 32 |
| | Scanning using a scanner driver | 32 |
| A | Routine maintenance | 33 |
| | Replacing the ink cartridges | 33 |
| | Cleaning and checking the machine..... | 36 |
| | Cleaning the scanner glass | 36 |
| | Cleaning the paper pick-up rollers..... | 36 |
| | Cleaning the print head | 37 |
| | Checking the print quality | 37 |
| | Checking the print alignment..... | 38 |
| B | Troubleshooting | 39 |
| | Error and Maintenance messages..... | 39 |
| | Error animation | 43 |
| | Document jam (DCP-J715W only) | 43 |
| | Printer jam or paper jam | 44 |
| | Troubleshooting..... | 46 |
| | If you are having difficulty with your machine | 46 |
| | Machine Information | 51 |
| | Checking the serial number..... | 51 |
| | Reset functions..... | 51 |
| | How to reset the machine..... | 51 |
| C | Menu and features | 52 |
| | On-screen programming..... | 52 |
| | Menu table | 53 |
| | Entering Text | 68 |
| | Inserting special characters..... | 68 |
| | Making corrections | 68 |

| | | |
|----------|-----------------------------------|-----------|
| D | Specifications | 69 |
| | General | 69 |
| | Print media..... | 71 |
| | Copy | 72 |
| | PhotoCapture Center™ | 73 |
| | PictBridge (DCP-J715W only) | 74 |
| | Scanner | 75 |
| | Printer | 76 |
| | Interfaces | 77 |
| | Computer requirements | 78 |
| | Consumable items | 79 |
| | Network (LAN) | 80 |
| E | Index | 81 |

Table of Contents

(ADVANCED USER'S GUIDE)

The *Advanced User's Guide* explains the following features and operations. You can view the *Advanced User's Guide* on the Documentation CD-ROM.

1 General setup

Memory storage
Sleep Mode
LCD display

2 Printing reports

Reports

3 Making copies

Copy settings

4 Printing photos from a memory card or USB Flash memory drive

PhotoCapture Center™ operations
Print Images
PhotoCapture Center™ print settings
Scan to a memory card or USB Flash memory drive

5 Printing photos from a camera (DCP-J715W only)


Printing photos directly from a PictBridge camera
Printing photos directly from a digital camera (without PictBridge)

A Routine maintenance

Cleaning and checking the machine
Packing and shipping the machine

B Glossary

C Index



Using the documentation

Thank you for buying a Brother machine! Reading the documentation will help you make the most of your machine.

Symbols and conventions used in the documentation

The following symbols and conventions are used throughout the documentation.

| | |
|----------------|--|
| Bold | Bold typeface identifies specific buttons on the machine's control panel, or on the computer screen. |
| <i>Italics</i> | Italicized typeface emphasizes an important point or refers you to a related topic. |
| Courier New | Text in the Courier New font identifies messages on the LCD of the machine. |

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injuries.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injuries.

IMPORTANT

IMPORTANT indicates a potentially hazardous situation which may result in property-damage-only accidents or loss of product functionality.



Notes tell you how you should respond to a situation that may arise or give tips about how the operation works with other features.



Electrical Hazard icons alert you to possible electrical shock.

Accessing the Advanced User's Guide, Software User's Guide and Network User's Guide

This Basic User's Guide does not contain all the information about the machine such as how to use the advanced features for Copy, PhotoCapture Center™, Printer, Scanner and Network. When you are ready to learn detailed information about these operations, read the **Advanced User's Guide**, **Software User's Guide** and **Network User's Guide** that are on the Documentation CD-ROM.

Viewing Documentation

- 1 Turn on your computer. Insert the Documentation CD-ROM into your CD-ROM drive.



Note

(Windows® users)

If the screen does not appear automatically, go to

My Computer (Computer), double-click the CD-ROM icon, and then double-click **index.html**.

- 2 (Macintosh users)
Double-click the CD-ROM icon, and then double-click **index.html**.

- 3 Click your country.



- 4 Point to your language, point to **View Guide**, and then click the guide you want to read.



Note

- (Windows® users only)
Your web browser may display a yellow bar at the top of the page that contains a security warning about Active X controls. For the page to display correctly you must click on the bar, click **Allow Blocked Content**, then click **Yes** in the Security Warning dialog box.
 - (Windows® users only)¹
For faster access, you can copy all user documentation in PDF format to a local folder on your computer. Point to your language, then click **Copy to local disk**.
- ¹ Microsoft® Internet Explorer® 6.0 or greater.

How to find Scanning instructions

There are several ways you can scan documents. You can find the instructions as follows:

Software User's Guide

- *Scanning*
- *ControlCenter*
- *Network Scanning*

ScanSoft™ PaperPort™ 11SE with OCR How-to-Guides (DCP-J715W only)

- The complete ScanSoft™ PaperPort™ 11SE with OCR How-to-Guides can be viewed from the Help selection in the ScanSoft™ PaperPort™ 11SE application.

Presto! PageManager User's Guide (DCP-J715W only)



Note

Presto! PageManager must be downloaded and installed before use. See *Accessing Brother Support (Macintosh)* on page 3 for further instructions.

- The complete Presto! PageManager User's Guide can be viewed from the Help selection in the Presto! PageManager application.

How to find Network setup instructions

Your machine can be connected to a wireless or wired network. (Wired network is not available for DCP-J515W model.) You can find basic setup instructions in the Quick Setup Guide. If your wireless access point or router supports Wi-Fi Protected Setup or AOSS™, follow the steps in the Quick Setup Guide. For more information about network setup please see the *Network User's Guide* on the Documentation CD-ROM.

Accessing Brother Support (Windows®)

You can find all the contacts you will need, such as Web support (Brother Solutions Center) on the Installation CD-ROM.

- Click **Brother Support** on the **Top Menu**. The following screen will appear:



- To access our website (<http://www.brother.com>), click **Brother Home Page**.
- For the latest news and product support information (<http://solutions.brother.com/>), click **Brother Solutions Center**.
- To visit our website for original Brother Supplies (<http://www.brother.com/original/>), click **Supplies Information**.
- To access the Brother CreativeCenter (<http://www.brother.com/creativecenter/>) for FREE photo projects and printable downloads, click **Brother CreativeCenter**.
- To return to the **Top Menu**, click **Back** or if you have finished, click **Exit**.

Accessing Brother Support (Macintosh)

You can find all the contacts you will need, such as Web support (Brother Solutions Center) on the Installation CD-ROM.


- Double-click the **Brother Support** icon. The following screen will appear:



- (DCP-J715W only)
To download and install Presto! PageManager, click **Presto! PageManager**.
- To register your machine from the Brother Product Register Page (<http://www.brother.com/registration/>), click **On-Line Registration**.
- For the latest news and product support information (<http://solutions.brother.com/>), click **Brother Solutions Center**.
- To visit our website for original Brother Supplies (<http://www.brother.com/original/>), click **Supplies Information**.

Control panel overview

The **DCP-J515W** and **DCP-J715W** have the same control panel keys.



1 LCD (Liquid Crystal Display)

Displays messages on the screen to help you set up and use your machine.

Also, you can adjust the angle of the LCD screen by lifting it.

2 Number of Copies

Use this key to make multiple copies.

3 Menu keys:

■ ◀ or ▶

Press to scroll backward or forward to a menu selection.

Also, press to choose options.

■ ▲ or ▼

Press to scroll through the menus and options.

■ Clear

Press to go back to the previous menu level.

■ Menu

Lets you access the main menu to program the machine.

■ OK

Lets you confirm a selection.

4 Start keys:

■ Mono Start

Lets you start making copies in monochrome. Also lets you start a scanning operation (in colour or mono, depending on the scanning setting in the ControlCenter software).

■ Colour Start

Lets you start making copies in full colour. Also lets you start a scanning operation (in colour or mono, depending on the scanning setting in the ControlCenter software).

5 Stop/Exit

Stops an operation or exits from a menu.

6 On/Off

You can turn the machine on and off.

If you turn the machine off, it will still periodically clean the print head to maintain print quality. To prolong print head life, provide the best ink cartridge economy, and maintain print quality, you should keep your machine connected to the power at all times.

7 Mode keys:

-  **SCAN**
Lets you access Scan mode.
-  **PHOTO CAPTURE**
Lets you access PhotoCapture Center™ mode.

8 ! Warning LED


Turns orange and blinks when the LCD displays an error or an important status message.

**Note**

Most of the illustrations in this User's Guide show the DCP-J515W.

LCD display indications

The LCD display shows the mode the machine is in, the current settings, and the available ink volume.

**1 Ink indicator**

Lets you see the available ink volume.

2 Memory Status

Lets you see the available memory in the machine.

3 Wireless Status

A four level indicator shows the current wireless signal strength if you are using a wireless connection.



The warning icon  appears when there is an error or a maintenance message. For details, see *Error and Maintenance messages* on page 39.

Basic Operations

The following steps show how to change a setting in the machine. In this example the Paper Type setting is changed from Plain Paper to Inkjet Paper.

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose General Setup.



Press **OK**.


- 3 Press **▲** or **▼** to choose Paper Type.
- 4 Press **◀** or **▶** to choose Inkjet Paper. Press **OK**.
You can see the current setting on the LCD:



- 5 Press **Stop/Exit**.

Warning LED indications

The Warning LED (light emitting diode) is a light that shows the status of the machine, as shown in the table.



| LED | DCP status | Description |
|-------------|----------------|--|
| ! Off | Ready | The DCP is ready for use. |
| ! Orange | Cover open | The cover is open. Close the cover. (See <i>Error and Maintenance messages</i> on page 39.) |
| | Cannot Print | Replace the ink cartridge with a new one. (See <i>Replacing the ink cartridges</i> on page 33.) |
| | Paper error | Put paper in the tray or clear the paper jam. Check the LCD message. (See <i>Error and Maintenance messages</i> on page 39.) |
| | Other messages | Check the LCD message. (See <i>Error and Maintenance messages</i> on page 39.) |

LCD display

Setting the backlight brightness

If you are having difficulty reading the LCD, try changing the brightness setting.

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose **General Setup**.
Press **OK**.
- 3 Press **▲** or **▼** to choose **LCD Settings**.
Press **OK**.
- 4 Press **▲** or **▼** to choose **Backlight**.
- 5 Press **◀** or **▶** to choose **Light**, **Med** or **Dark**.
Press **OK**.
- 6 Press **Stop/Exit**.

2

Loading paper


Loading paper and other print media




Note

To print on Photo (10 × 15 cm) or Photo L (89 × 127 mm) paper, you must use the photo paper tray. (See *Loading photo paper* on page 12.)


- 1 If the paper support flap is open, close it, and then close the paper support. Pull the paper tray completely out of the machine.



- 2 Lift the output paper tray cover (1).




- 3 With both hands, gently press and slide the paper side guides (1) and then the paper length guide (2) to fit the paper size. Make sure that the triangular marks (3) on the paper side guides (1) and paper length guide (2) line up with the marks for the paper size you are using.




**Note**

When you use Legal size paper, press and hold the universal guide release button (1) as you slide out the front of the paper tray.




- 4 Fan the stack of paper well to avoid paper jams and misfeeds.

**! IMPORTANT**


Always make sure that the paper is not curled.

- 5 Gently put the paper into the paper tray print side down and top edge in first. Check that the paper is flat in the tray.


**! IMPORTANT**

Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause feed problems.


- 6 Gently adjust the paper side guides (1) to fit the paper with both hands. Make sure the paper side guides touch the sides of the paper.




- 7 Close the output paper tray cover.



- 8 *Slowly* push the paper tray completely into the machine.



- 9 While holding the paper tray in place, pull out the paper support (1) until it clicks, and then unfold the paper support flap (2).



! IMPORTANT

DO NOT use the paper support flap for Legal size paper.

Loading envelopes and postcards


About envelopes

- Use envelopes that weigh between 80 to 95 gsm.
- Some envelopes need margin settings to be set in the application. Make sure you do a test print first before printing many envelopes.

! IMPORTANT

DO NOT use any of the following types of envelopes, as they will cause paper feed problems:

- That are of a baggy construction.
- That are embossed (have raised writing on them).
- That have clasps or staples.
- That are pre-printed on the inside.




Occasionally you may experience paper feed problems caused by the thickness, size and flap shape of the envelopes you are using.

How to load envelopes and postcards


- 1 Before loading, press the corners and sides of envelopes or postcards to make them as flat as possible.

! IMPORTANT

If envelopes or postcards are "double-feeding", put one envelope or postcard in the paper tray at a time.




- 2 Put envelopes or postcards in the paper tray with the address side down and the leading edge (top of the envelopes) in first. With both hands, gently press and slide the paper side guides (1) and paper length guide (2) to fit the size of the envelopes or postcards.



If you have problems printing on envelopes with the flap on the short edge, try the following suggestions:

- 1 Open the envelope flap.
- 2 Put the envelope into the paper tray with the address side down and the flap positioned as shown in the illustration.



- 3 Adjust the size and margin in your application.

Loading photo paper

Use the photo paper tray which has been assembled on the top of the output paper tray cover to print on Photo (10 × 15 cm) and Photo L (89 × 127 mm) size paper. When you use the photo paper tray, you do not have to take out the paper that is in the tray beneath it.

- 1 Squeeze the blue photo paper tray release button (1) using your right index finger and thumb and push the photo paper tray forward until it clicks into the photo printing position (2).





Photo Paper Tray

- 2 Press and slide the paper side guides (1) and paper length guide (2) to fit the paper size.




- 3 Put the photo paper into the photo paper tray and gently adjust the paper side guides to the paper. Make sure the paper side guides touch the sides of the paper. Check that the paper is flat in the tray.



Note

- Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause feed problems.
- Always make sure that the paper is not curled or wrinkled.

- 4 When you have finished printing photos return the photo paper tray to the *Normal* printing position. Squeeze the blue photo paper tray release button (1) using your right index finger and thumb and pull the photo paper tray back until it clicks (2).



! IMPORTANT

If you do not return the photo paper tray to the *Normal* printing position after printing photos, you will get a `No Paper Fed` error when you use standard paper.




Photo paper tray in the normal printing position





Photo paper tray in the photo printing position

Removing small printouts from the machine


When the machine ejects small paper onto the output paper tray cover you may not be able to reach it. Make sure printing has finished, and then pull the tray completely out of the machine.




Printable area

The printable area depends on the settings in the application you are using. The figures below show the unprintable areas on cut sheet paper and envelopes. The machine can print in the shaded areas of cut sheet paper when the Borderless print feature is available and turned on. (See *Printing for Windows*[®] or *Printing and Faxing for Macintosh* in the *Software User's Guide*.)

Cut Sheet Paper



Envelopes



| | Top (1) | Bottom (2) | Left (3) | Right (4) |
|-----------|---------|------------|----------|-----------|
| Cut Sheet | 3 mm | 3 mm | 3 mm | 3 mm |
| Envelopes | 12 mm | 24 mm | 3 mm | 3 mm |



Note

The Borderless feature is not available for envelopes.

Paper settings

Paper Type

To get the best print quality, set the machine for the type of paper you are using.

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose General Setup.
Press **OK**.
- 3 Press **▲** or **▼** to choose Paper Type.
- 4 Press **◀** or **▶** to choose Plain Paper, Inkjet Paper, Brother BP71, Brother BP61, Other Glossy or Transparency.
Press **OK**.
- 5 Press **Stop/Exit**.



Note

The machine ejects paper with printed surfaces face up onto the paper tray in front of the machine. When you use transparencies or glossy paper, remove each sheet at once to prevent smudging or paper jams.

Paper Size

You can use five sizes of paper for printing copies: A4, A5, Letter, Legal and 10 × 15 cm. When you load a different size of paper in the machine, you will need to change the paper size setting at the same time.

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose General Setup.
Press **OK**.
- 3 Press **▲** or **▼** to choose Paper Size.
- 4 Press **◀** or **▶** to choose A4, A5, 10x15cm, Letter or Legal.
Press **OK**.
- 5 Press **Stop/Exit**.

Acceptable paper and other print media

The print quality can be affected by the type of paper you use in the machine.

To get the best print quality for the settings you have chosen, always set the Paper Type to match the type of paper you load.

You can use plain paper, inkjet paper (coated paper), glossy paper, transparencies and envelopes.

We recommend testing various paper types before buying large quantities.

For best results, use Brother paper.

- When you print on inkjet paper (coated paper), transparencies and glossy paper, be sure to choose the correct print media in the “**Basic**” tab of the printer driver or in the Paper Type setting of the menu. (See *Paper Type* on page 24.)
- When you print on Brother photo paper, load one extra sheet of the same photo paper in the paper tray. An extra sheet has been included in the paper package for this purpose.
- When you use transparencies or photo paper, remove each sheet at once to prevent smudging or paper jams.
- Avoid touching the printed surface of the paper immediately after printing, the surface may not be completely dry and may stain your fingers.

Recommended print media

To get the best print quality, we suggest using Brother paper. (See the table below.)

If Brother paper is not available in your country, we recommend testing various papers before purchasing large quantities.

We recommend using “3M Transparency Film” when you print on transparencies.

Brother paper

| Paper Type | Item |
|-------------------|---------|
| A4 Plain | BP60PA |
| A4 Glossy Photo | BP71GA4 |
| A4 Inkjet (Matte) | BP60MA |
| 10 × 15 cm Glossy | BP71GP |


Handling and using print media

- Store paper in its original packaging, and keep it sealed. Keep the paper flat and away from moisture, direct sunlight and heat.
- Avoid touching the shiny (coated) side of photo paper. Load photo paper with the shiny side facing down.
- Avoid touching either side of transparencies because they absorb water and perspiration easily, and this may cause decreased output quality. Transparencies designed for laser printers/copiers may stain your next document. Use only transparencies recommended for inkjet printing.

! IMPORTANT

DO NOT use the following kinds of paper:

- Damaged, curled, wrinkled, or irregularly shaped paper



1 2 mm or greater curl may cause jams to occur.

- Extremely shiny or highly textured paper
- Paper that cannot be arranged uniformly when stacked
- Paper made with a short grain

Paper capacity of the output paper tray cover

Up to 50 sheets of 80 gsm A4 paper.

- Transparencies and photo paper must be picked up from the output paper tray cover one page at a time to avoid smudging.

Choosing the right print media

Paper type and size for each operation

| Paper Type | Paper Size | | Usage | | |
|------------|---------------------|-----------------------------------|-------------------------------|---------------|---------|
| | | | Copy | Photo Capture | Printer |
| Cut Sheet | A4 | 210 × 297 mm (8.3 × 11.7 in.) | Yes | Yes | Yes |
| | Letter | 215.9 × 279.4 mm (8 1/2 × 11 in.) | Yes | Yes | Yes |
| | Legal | 215.9 × 355.6 mm (8 1/2 × 14 in.) | Yes | – | Yes |
| | Executive | 184 × 267 mm (7 1/4 × 10 1/2 in.) | – | – | Yes |
| | JIS B5 | 182 × 257 mm (7.2 × 10.1 in.) | – | – | Yes |
| | A5 | 148 × 210 mm (5.8 × 8.3 in.) | Yes | – | Yes |
| | A6 | 105 × 148 mm (4.1 × 5.8 in.) | – | – | Yes |
| Cards | Photo | 10 × 15 cm (4 × 6 in.) | Yes | Yes | Yes |
| | Photo L | 89 × 127 mm (3 1/2 × 5 in.) | – | – | Yes |
| | Photo 2L | 13 × 18 cm (5 × 7 in.) | – | Yes | Yes |
| | Index Card | 127 × 203 mm (5 × 8 in.) | – | – | Yes |
| | Postcard 1 | 100 × 148 mm (3.9 × 5.8 in.) | – | – | Yes |
| | Postcard 2 (Double) | 148 × 200 mm (5.8 × 7.9 in.) | – | – | Yes |
| Envelopes | C5 Envelope | 162 × 229 mm (6.4 × 9 in.) | – | – | Yes |
| | DL Envelope | 110 × 220 mm (4.3 × 8.7 in.) | – | – | Yes |
| | COM-10 | 105 × 241 mm (4 1/8 × 9 1/2 in.) | – | – | Yes |
| | Monarch | 98 × 191 mm (3 7/8 × 7 1/2 in.) | – | – | Yes |
| | JE4 Envelope | 105 × 235 mm (4.1 × 9.3 in.) | – | – | Yes |
| | Transparencies | A4 | 210 × 297 mm (8.3 × 11.7 in.) | Yes | – |
| Letter | | 215.9 × 279.4 mm (8 1/2 × 11 in.) | Yes | – | Yes |
| Legal | | 215.9 × 355.6 mm (8 1/2 × 14 in.) | Yes | – | Yes |
| A5 | | 148 × 210 mm (5.8 × 8.3 in.) | Yes | – | Yes |

Paper weight, thickness and capacity

| Paper Type | | Weight | Thickness | No. of sheets |
|----------------|--------------------|---------------|-----------------|-------------------|
| Cut Sheet | Plain Paper | 64 to 120 gsm | 0.08 to 0.15 mm | 100 ¹ |
| | Inkjet Paper | 64 to 200 gsm | 0.08 to 0.25 mm | 20 |
| | Other Glossy Paper | Up to 220 gsm | Up to 0.25 mm | 20 ^{2 3} |
| Cards | Photo Card | Up to 220 gsm | Up to 0.25 mm | 20 ^{2 3} |
| | Index Card | Up to 120 gsm | Up to 0.15 mm | 30 |
| | Postcard | Up to 200 gsm | Up to 0.25 mm | 30 |
| Envelopes | | 75 to 95 gsm | Up to 0.52 mm | 10 |
| Transparencies | | – | – | 10 |

¹ Up to 100 sheets of 80 gsm paper.

² For Photo 10 × 15 cm paper and Photo L 89 × 127 mm paper, use the photo paper tray. (See *Loading photo paper* on page 12.)

³ BP71 260 gsm paper is especially designed for Brother inkjet machines.

3

Loading documents

How to load documents

You can make copies and scan from the ADF (automatic document feeder) and from the scanner glass.

Using the ADF (DCP-J715W only)

The ADF can hold up to 15 pages and feeds each sheet individually. Use standard 80 gsm paper and always fan the pages before putting them in the ADF.

Document Sizes Supported

| | |
|---------|-----------------|
| Paper: | 80 gsm A4 |
| Length: | 148 to 355.6 mm |
| Width: | 148 to 215.9 mm |
| Weight: | 64 to 90 gsm |


How to load documents

! IMPORTANT

- DO NOT pull on the document while it is feeding.
- DO NOT use paper that is curled, wrinkled, folded, ripped, stapled, paper clipped, pasted or taped.
- DO NOT use cardboard, newspaper or fabric. Instead use the scanner glass.

Make sure documents written with ink are completely dry.

- 1 Unfold the ADF Document Output Support Flap (1).
- 2 Fan the pages well.
- 3 Adjust the paper guides (2) to fit the width of your document.
- 4 Make sure you place your documents, **face down, top edge first** in the ADF underneath the guides until you feel them touch the feed roller and the LCD shows ADF Ready.



! IMPORTANT

DO NOT leave thick documents on the scanner glass. If you do this, the ADF may jam.

Using the scanner glass

You can use the scanner glass to copy or scan pages of a book or one page at a time.

Document Sizes Supported

| | |
|---------|----------------|
| Length: | Up to 297 mm |
| Width: | Up to 215.9 mm |
| Weight: | Up to 2 kg |



How to load documents



Note

To use the scanner glass, the ADF must be empty. (DCP-J715W only)

- 1 Lift the document cover.
- 2 Using the document guidelines on the left and top, place the document face down in the upper left corner of the scanner glass.



- 3 Close the document cover.




IMPORTANT

If you are scanning a book or thick document, DO NOT slam the cover down or press on it.

Scannable area

The scannable area depends on the settings in the application you are using. The figures below show unscannable areas.



| Usage | Document Size | Top (1) Bottom (2) | Left (3) Right (4) |
|-------|---------------|-----------------------|-----------------------|
| Copy | A4 | 3 mm | 3 mm |
| | Letter | 3 mm | 3 mm |
| Scan | A4 | 3 mm | 3 mm |
| | Letter | 3 mm | 3 mm |

4


Making copies

How to copy

The following steps show the basic copy operation. For details about each option, see the *Advanced User's Guide*.

- 1 Do one of the following to load your document:
 - Place the document *face down* in the ADF. (DCP-J715W only)
(See *Using the ADF (DCP-J715W only)* on page 21.)
 - Load your document *face down* on the scanner glass.
(See *Using the scanner glass* on page 21.)

- 2 Press **+** or **-** repeatedly until the number of copies you want appears (up to 99).



1 No. of Copies

- 3 Press **Mono Start** or **Colour Start**.



Note

If you want to sort copies, use the ADF. (DCP-J715W only)

Stop copying

To stop copying, press **Stop/Exit**.

Copy settings

You can change the following copy settings. Press **▲** or **▼** to scroll through the copy settings. When the setting you want is highlighted, press **OK**.

(Basic User's Guide)

For details about changing the following copy settings, see page 24.

- Paper Type
- Paper Size

(Advanced User's Guide)

For details about changing the following copy settings, see chapter 3:

- Quality
- Enlarge/Reduce
- Density
- Ink Save Mode
- Stack/Sort (DCP-J715W only)
- Page Layout
- Book Copy
- Watermark Copy
- Set New Default
- Factory Reset

Paper options

Paper Type

If you are copying on special paper, set the machine for the type of paper you are using to get the best print quality.

- 1 Load your document.
- 2 Enter the number of copies you want.
- 3 Press ▲ or ▼ to choose Paper Type.
- 4 Press ◀ or ▶ to choose Plain Paper, Inkjet Paper, Brother BP71, Brother BP61, Other Glossy or Transparency.
Press **OK**.
- 5 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

Paper Size

If you are copying on paper other than A4 size, you will need to change the paper size setting.

You can copy only on A4, Legal, Letter, A5 or Photo 10 × 15 cm paper.

- 1 Load your document.
- 2 Enter the number of copies you want.
- 3 Press ▲ or ▼ to choose Paper Size.
- 4 Press ◀ or ▶ to choose A4, A5, 10x15cm, Letter or Legal.
Press **OK**.
- 5 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

PhotoCapture Center™ Operations



Note

USB Flash memory is not available for DCP-J515W model.

Even if your machine is not connected to your computer, you can print photos directly from digital camera media or a USB Flash memory drive. (See *Print Images* on page 28.)

You can scan documents and save them directly to a memory card or USB Flash memory drive. (See *How to scan to a memory card or USB Flash memory drive* on page 29.)

You can access a memory card or USB Flash memory drive that is inserted in the front of the machine from your computer.

(See *PhotoCapture Center™* for Windows® or *Remote Setup & PhotoCapture Center™* for Macintosh in the *Software User's Guide*.)


Using a memory card or USB Flash memory drive

Your Brother machine has media drives (slots) for use with the following popular digital camera media: Memory Stick™, Memory Stick PRO™, Memory Stick Duo™, Memory Stick PRO Duo™, SD, SDHC and USB Flash memory drives.


The PhotoCapture Center™ feature lets you print digital photos from your digital camera at high resolution to get photo quality printing.

Getting started

Firmly put a memory card or USB Flash memory drive into the correct slot.







1 USB Flash memory drive (DCP-J715W only)



! IMPORTANT

The USB direct interface supports only a USB Flash memory drive, a PictBridge compatible camera, or a digital camera that uses the USB mass storage standard. Any other USB devices are not supported.


2 Memory card slot

| Slot | Compatible memory cards | |
|---|---|---|
| Upper slot  |  | Memory Stick™ Memory Stick PRO™ |
| |  | Memory Stick Duo™ Memory Stick PRO Duo™ |
| |  | Memory Stick Micro™ (Adapter required) |
| Lower slot  |  | SD SDHC |
| |  | mini SD (Adapter required) micro SD (Adapter required) |

! IMPORTANT

DO NOT insert a Memory Stick Duo™ into the lower SD slot, this may cause damage to the machine.

PHOTO CAPTURE key indications:



- **PHOTO CAPTURE** light is on, the memory card or USB Flash memory drive is correctly inserted.
- **PHOTO CAPTURE** light is off, the memory card or USB Flash memory drive is not correctly inserted.
- **PHOTO CAPTURE** light is blinking, the memory card or USB Flash memory drive is being read or written to.

! IMPORTANT

DO NOT unplug the power cord or remove the memory card or USB Flash memory drive from the media drive (slot) or USB direct interface while the machine is reading or writing to the memory card or USB Flash memory drive (the **PHOTO CAPTURE** key is blinking). **You will lose your data or damage the card.**

The machine can only read one device at a time.

Print Images

View Photos

You can preview your photos on the LCD before you print them. If your photos are large files there may be a delay before each photo is displayed on the LCD.

- 1 Make sure you have put the memory card or USB Flash memory drive in the correct slot.
Press  (**PHOTO CAPTURE**).
- 2 Press ▲ or ▼ to choose View Photo(s).
Press **OK**.
- 3 Press ◀ or ▶ to choose your photo.
- 4 Press + or - repeatedly to enter the number of copies you want.
- 5 Repeat steps 3 and 4 until you have chosen all the photos.



Note

Press **Clear** to go back to the previous level.

- 6 After you have chosen all the photos, do one of the following:
 - Press **OK** and change the print settings. (See *PhotoCapture Center™ print settings* on page 28.)
 - If you do not want to change any settings, press **Colour Start** to print.

PhotoCapture Center™ print settings


You can change the print settings temporarily for the next print.

The machine returns to its default settings after 3 minutes.



Note

You can save the print settings you use most often by setting them as the default. (See *Setting your changes as a new default* in chapter 4 in the *Advanced User's Guide*.)



1 No. of prints

(For View Photo(s), Search by Date, Slide Show)

You can see the total number of photos that will be printed.

(For Print All Photos, Print Photos, Enhance Photos, Trimming)

You can see the number of copies of each photo that will be printed.

(For DPOF printing)

This does not appear.

How to scan to a memory card or USB Flash memory drive

You can scan monochrome and colour documents into a memory card or USB Flash memory drive. Monochrome documents will be stored in PDF (*.PDF) or TIFF (*.TIF) file formats. Colour documents may be stored in PDF (*.PDF) or JPEG (*.JPG) file formats. The factory setting is **Color 150** and the default file format is **PDF**. The machine automatically creates file names based on the current date. (For details, see the *Quick Setup Guide*.) For example, the fifth image scanned on July 1, 2010 would be named 01071005.PDF. You can change the colour and quality.

| Quality | Selectable File Format |
|-------------|------------------------|
| Color 150 | JPEG / PDF |
| Color 300 | JPEG / PDF |
| Color 600 | JPEG / PDF |
| B/W 200x100 | TIFF / PDF |
| B/W 200 | TIFF / PDF |

- 1 Make sure you have put the memory card or USB Flash memory drive in the correct slot.

! IMPORTANT

DO NOT take out the memory card or USB Flash memory drive while **PHOTO CAPTURE** is blinking to avoid damaging the card, USB Flash memory drive or data stored on it.

- 2 Load your document.
- 3 When you want to scan to a memory card or USB Flash memory drive, press  (**SCAN**).

- 4 Press **▲** or **▼** to choose **Scan to Media**.



Press **OK**.

- 5 Do one of the following:
 - To change the quality, press **▲** or **▼** to choose **Quality**. Go to step 6.
 - Press **Mono Start** or **Colour Start** to start scanning without changing additional settings.

- 6 Press **◀** or **▶** to choose **Color 150**, **Color 300**, **Color 600**, **B/W 200x100** or **B/W 200**. Press **OK**.

- 7 Do one of the following:
 - To change the file type, go to step 8.
 - Press **Mono Start** or **Colour Start** to start scanning without changing additional settings.

- 8 Press **▲** or **▼** to choose **File Type**. Press **◀** or **▶** to choose **JPEG**, **PDF** or **TIFF**. Press **OK**.



Note

- If you chose a **Color** resolution in step 6, you cannot choose **TIFF**.
- If you chose a **B/W** resolution in step 6, you cannot choose **JPEG**.

- 9 Do one of the following:
 - To change the file name, go to step 10.
 - Press **Mono Start** or **Colour Start** to start scanning without changing additional settings.

- 10 The file name is set automatically; however, you can set a name of your choice using the ▲, ▼, ◀ or ▶ keys. Press ▲ or ▼ to choose `File Name`. Press **OK**. Enter the new name. (See *Entering Text* on page 68.) You can only change the first 6 characters. Press ▲, ▼, ◀ or ▶ to select , and press **OK**.
- 11 Press **Mono Start** or **Colour Start**.



Note

You can place multiple documents on the scanner glass and scan them as separate files. (See *Auto Crop* in *chapter 4* in the *Advanced User's Guide*.)

Printing a document

The machine can receive data from your computer and print it. To print from a computer, install the printer driver.

(See *Printing for Windows*[®] or *Printing and Faxing for Macintosh* in the *Software User's Guide* for the details about the print settings.)

- 1 Install the Brother printer driver on the Installation CD-ROM. (See the *Quick Setup Guide*.)
- 2 From your application, choose the Print command.
- 3 Choose the name of your machine in the **Print** dialog box and click **Properties**.
- 4 Choose the settings you want in the Properties dialog box.
 - **Media Type/Quality**
 - **Paper Size**
 - **Page Layout**
 - **Colour Settings**
 - **Scaling**
 - **Use Watermark**
 - **Print Date & Time**
- 5 Click **OK**.
- 6 Click **OK** to begin printing.

Scanning a document

There are several ways to scan documents. You can use the **SCAN** key on the machine or the scanner drivers on your computer.

- 1 To use the machine as a scanner, install a scanner driver. If the machine is on a Network, configure it with a TCP/IP address.
 - Install the scanner drivers on the Installation CD-ROM. (See the *Quick Setup Guide* and *Scanning* in the *Software User's Guide*.)
 - Configure the machine with a TCP/IP address if network scanning does not work. (See *Configuring Network Scanning* in the *Software User's Guide*.)
- 2 Load your document. (See *Loading documents* on page 21.)
 - Use the ADF to scan multiple pages of documents. It feeds each sheet automatically. (DCP-J715W only)
 - Use the scanner glass to scan a page of a book or one sheet at a time.
- 3 Do one of the following:
 - To scan using the **SCAN** key, go to *Scanning using the scan key*.
 - To scan using a scanner driver at your computer, go to *Scanning using a scanner driver*.

Scanning using the scan key

For more information, see *Using the Scan key* in the *Software User's Guide*.

- 1 Press the **SCAN** key.
- 2 Choose the scan mode you want.
 - Scan to File
 - Scan to Media
 - Scan to E-mail
 - Scan to OCR¹
 - Scan to Image
- ¹ DCP-J715W only (Macintosh users)
Presto! PageManager must be downloaded and installed before use. See *Accessing Brother Support (Macintosh)* on page 3 for further instructions.
- 3 (For network users)
Choose the computer you want to send the data to.
- 4 Press **Start** to begin scanning.

Scanning using a scanner driver

For more information, see *Scanning a document using the TWAIN driver* or *Scanning a document using the WIA driver* in the *Software User's Guide*.

- 1 Start a scanning application and click the **Scan** button.
- 2 Adjust the settings such as **Resolution**, **Brightness** and **Scan Type** in the **Scanner Setup** dialog box.
- 3 Click **Start** or **Scan** to begin scanning.

Replacing the ink cartridges

Your machine is equipped with an ink dot counter. The ink dot counter automatically monitors the level of ink in each of the 4 cartridges. When the machine detects an ink cartridge is running out of ink, the machine will tell you with a message on the LCD.

Note

For example, when one of the ink cartridge is nearly empty, the LCD will display `Ink low` (name of colour).

You should purchase a replacement cartridge in preparation for when the machine indicates the colour is completely empty.

When one of the ink cartridge is empty, the LCD will display `Cannot Print or B&W Print Only`.

You should only replace the actual ink cartridge when this message `Cannot Print or B&W Print Only` appears on the LCD.

The LCD will tell you which ink cartridge is low or needs replacing. Be sure to follow the LCD prompts to replace the ink cartridges in the correct order.



Even though the machine tells you to replace an ink cartridge, there will be a small amount of ink left in the ink cartridge. It is necessary to keep some ink in the ink cartridge to prevent air from drying out and damaging the print head assembly.

IMPORTANT

Brother multifunction machines are designed to work with ink of a particular specification and will work to a level of optimum performance and reliability when used with genuine Brother Original ink cartridges. Brother cannot guarantee this optimum performance and reliability if ink or ink cartridges of other specifications are used. Brother does not therefore recommend the use of cartridges other than genuine Brother Original cartridges or the refilling of used cartridges with ink from other sources. If damage is caused to the print head or other parts of this machine as a result of using incompatible products with this machine, any repairs required as a result may not be covered by the warranty.



- 1 Open the ink cartridge cover. If one or more ink cartridges have reached the end of their life, the LCD shows `Cannot Print or B&W Print Only`.

- 2 Press the lock release lever as shown to release the cartridge indicated on the LCD. Remove the cartridge from the machine.




- 3 Open the new ink cartridge bag for the colour shown on the LCD, and then take out the ink cartridge.


- 4 Turn the green knob on the protective yellow cap clockwise until it clicks to release the vacuum seal, then remove the cap (1).



- 5 Each colour has its own correct position. Insert the ink cartridge in the direction of the arrow on the label.



- 6 Gently push the ink cartridge in until it clicks, and then close the ink cartridge cover.



- 7 The machine will automatically reset the ink dot counter.



Note

- If you replaced an ink cartridge, for example Black, the LCD may ask you to verify that it was a brand new one (for example, Did You Change **BK** Black). For each new cartridge you installed, press + (Yes) to automatically reset the ink dot counter for that colour. If the ink cartridge you installed is not a brand new one, be sure to press - (No).
- If the LCD shows `No Ink Cartridge or Cannot Detect` after you install the ink cartridges, check that the ink cartridges are installed correctly.

⚠ CAUTION

If ink gets in your eyes, wash it out with water at once and call a doctor if you are concerned.


! IMPORTANT

- DO NOT take out ink cartridges if you do not need to replace them. If you do so, it may reduce the ink quantity and the machine will not know the quantity of ink left in the cartridge.
- DO NOT touch the cartridge insertion slots. If you do so, the ink may stain your skin.
- If ink gets on your skin or clothing immediately wash it off with soap or detergent.
- If you mix the colours by installing an ink cartridge in the wrong position, clean the print head several times after correcting the cartridge installation.
- Once you open an ink cartridge, install it in the machine and use it up within six months of installation. Use unopened ink cartridges by the expiration date written on the cartridge package.
- DO NOT dismantle or tamper with the ink cartridge, this can cause the ink to leak out of the cartridge.


Cleaning and checking the machine

Cleaning the scanner glass

- 1 Lift the document cover (1). Clean the scanner glass (2) and the white plastic (3) with a soft lint-free cloth moistened with a non-flammable glass cleaner.



- 2 (DCP-J715W only) In the ADF unit, clean the white bar (1) and the glass strip (2) with a lint-free cloth moistened with a non-flammable glass cleaner.




Note


In addition to cleaning the glass strip with a non-flammable glass cleaner, run your finger tip over the glass strip to see if you can feel anything on it. If you feel dirt or debris, clean the glass strip again concentrating on that area. You may need to repeat the cleaning process three or four times. To test, make a copy after each cleaning attempt.

Cleaning the paper pick-up rollers

- 1 Pull the paper tray completely out of the machine.
- 2 Unplug the machine from the electrical socket and open the Jam Clear Cover (1) at the back of the machine.



- 3 Clean the Paper Pick-up Rollers (1) with isopropyl alcohol on a cotton swab.



- 4 Close the Jam Clear Cover. Make sure the cover is closed correctly.
- 5 Re-connect the power cord.
- 6 Slowly push the paper tray completely back into the machine.

Cleaning the print head

To maintain good print quality, the machine will automatically clean the print head when needed. You can start the cleaning process manually if there is a print quality problem.

Clean the print head and ink cartridges if you get a horizontal line in the text or graphics, or blank text on your printed pages. You can clean Black only, three colours at a time (Cyan/Magenta/Yellow), or all four colours at once.

Cleaning the print head consumes ink. Cleaning too often uses ink unnecessarily.

! IMPORTANT

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose Ink Management. Press **OK**.
- 3 Press **▲** or **▼** to choose **Cleaning**. Press **OK**.
- 4 Press **▲** or **▼** to choose **Black, Color** or **All**. Press **OK**.
The machine cleans the print head. When cleaning is finished, the machine will go back to standby mode automatically.



Note

If you clean the print head at least five times and the print has not improved, try installing a new Brother Original Innobella™ ink cartridge for each problem colour. Try cleaning the print head again up to five more times. If the print has not improved call your Brother dealer.

Checking the print quality

If faded or streaked colours and text appear on your output, some of the nozzles may be clogged. You can check this by printing the Print Quality Check Sheet and looking at the nozzle check pattern.

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose Ink Management. Press **OK**.
- 3 Press **▲** or **▼** to choose **Test Print**. Press **OK**.
- 4 Press **▲** or **▼** to choose **Print Quality**. Press **OK**.
- 5 Press **Colour Start**.
The machine begins printing the Print Quality Check Sheet.
- 6 Check the quality of the four colour blocks on the sheet.
- 7 Do one of the following:
 - If all lines are clear and visible, press **+** to choose **Yes**, and go to step 11.
 - If you can see missing short lines as shown below, press **-** to choose **No**.

OK



Poor



- 8 The LCD asks you if the print quality is OK for black and the three colours. Press **+** (Yes) or **-** (No).
- 9 The LCD asks you if you want to start cleaning. Press **+** (Yes).
The machine starts cleaning the print head.

- 10 After cleaning is finished, press **Colour Start**.
The machine starts printing the Print Quality Check Sheet again. Return to step 6.

- 11 Press **Stop/Exit**.
If you repeat this procedure at least five times and the print quality is still poor, replace the ink cartridge for the clogged colour.
After replacing the ink cartridge, check the print quality. If the problem still exists, repeat the cleaning and test print procedures at least five times for the new ink cartridge. If ink is still missing, call your Brother dealer.

! IMPORTANT

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.

Note



When a print head nozzle is clogged the printed sample looks like this.



After the print head nozzle is cleaned, the horizontal lines are gone.

Checking the print alignment

You may need to adjust the print alignment after transporting the machine, if your printed text becomes blurred or images become faded.

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose **Ink Management**. Press **OK**.
- 3 Press **▲** or **▼** to choose **Test Print**. Press **OK**.
- 4 Press **▲** or **▼** to choose **Alignment**. Press **OK**.
- 5 Press **Mono Start** or **Colour Start**. The machine starts printing the Alignment Check Sheet.
- 6 Check the 600 dpi and 1200 dpi test prints to see if number 5 most closely matches number 0.
 - If the number 5 samples of both the 600 dpi and 1200 dpi test prints are the best matches, press **+** (**Yes**) to finish Alignment Check, and go to step 9.
 - If another test print number is a better match for either 600 dpi or 1200 dpi, press **-** (**No**) to choose it.
- 7 For 600 dpi, press **◀** or **▶** to choose the number of the test print that most closely matches the number 0 sample (1-8). Press **OK**.
- 8 For 1200 dpi, press **◀** or **▶** to choose the number of the test print that most closely matches the number 0 sample (1-8). Press **OK**.
- 9 Press **Stop/Exit**.

Error and Maintenance messages

As with any sophisticated office product, errors may occur and consumable items may need to be replaced. If this happens, your machine identifies the error and shows an error message. The most common error and maintenance messages are shown below.

You can correct most errors and routine maintenance by yourself. If you need more help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at <http://solutions.brother.com/>

| Error Message | Cause | Action |
|-------------------------------|--|--|
| B&W Print Only Replace Ink | <p>One or more of the colour ink cartridges have reached the end of their life.</p> <p>You can use the machine in black & white mode for approximately four weeks depending on the number of pages you print.</p> <p>While this message appears on the LCD, each operation works in the following way:</p> <ul style="list-style-type: none"> ■ Printing If you click Greyscale in the Advanced tab of the printer driver you can use the machine as a monochrome printer. ■ Copying If the paper type is set to Plain Paper or Inkjet Paper you can make copies in monochrome. <p>If the paper type is set to Other Glossy, Brother BP71 or Brother BP61 the machine will stop all print operations. <i>If you unplug the machine, or take out the ink cartridge, you cannot use the machine until you change to a new ink cartridge.</i></p> | <p>Replace the ink cartridges. (See <i>Replacing the ink cartridges</i> on page 33.)</p> |

| Error Message | Cause | Action |
|----------------------------------|---|--|
| Cannot Detect | You installed a new ink cartridge too quickly and the machine did not detect it. | Take out the new ink cartridge and re-install it slowly. |
| | If you are using non Brother Original ink the machine may not detect the ink cartridge. | Replace the cartridge with a Brother Original ink cartridge. If the error message remains, contact your Brother dealer. |
| | An ink cartridge is not installed correctly. | Take out the new ink cartridge and re-install it slowly until it clicks. (See <i>Replacing the ink cartridges</i> on page 33.) |
| Cannot Print Replace Ink | One or more of the ink cartridges have reached the end of their life. The machine will stop all print operations. | Replace the ink cartridges. (See <i>Replacing the ink cartridges</i> on page 33.) |
| Cover is Open | The scanner cover is not completely closed. | Lift the scanner cover and then close it again. |
| | The ink cartridge cover is not completely closed. | Firmly close the ink cartridge cover until it clicks. |
| Data Remaining | Print data is left in the machine's memory. | Press Stop/Exit . The machine will cancel the job and clear it from the memory. Try to print again. |
| Document Jam (DCP-J715W only) | The document was not inserted or fed correctly, or the document scanned from the ADF was too long. | (See <i>Using the ADF (DCP-J715W only)</i> on page 21.) (See <i>Document jam (DCP-J715W only)</i> on page 43.) |
| High Temperature | The print head is too warm. | Allow the machine to cool down. |
| Hub is Unusable. | A Hub or USB Flash memory drive with Hub has been connected to the USB direct interface. | A Hub or USB Flash memory drive with Hub are not supported. Unplug the device from the USB direct interface. |
| Image Too Long. | The proportions of your photo are irregular so effects could not be added. | Choose a regularly proportioned image. |
| Image Too Small. | The size of your photo is too small to trim. | Choose a larger image. |
| Ink Absorber Full | Internal servicing required. This problem may be caused by the use of cartridges other than genuine Brother Original cartridges or the refilling of empty cartridges with ink from other sources. If damage is caused to the print head or other parts of this machine as a result of using other brands of ink or ink cartridges, any repairs required as a result may not be covered by the warranty. | Call Brother Customer Service / your Brother dealer. |

| Error Message | Cause | Action |
|-----------------------|---|--|
| Ink Absorber NearFull | The ink absorber box or flushing box is near full. | Call Brother Customer Service / your Brother dealer. |
| Ink low | One or more of the ink cartridges are near the end of their life. | Order a new ink cartridge. |
| Low Temperature | The print head is too cold. | Allow the machine to warm up. |
| Media Error | The memory card is either corrupted, incorrectly formatted, or there is a problem with the memory card. | Put the card firmly into the slot again to make sure it is in the correct position. If the error remains, check the media drive (slot) of the machine by putting in another memory card that you know is working. |
| Media is Full. | The memory card or USB Flash memory drive you are using already contains 999 files. | Your machine can only save to your memory card or USB Flash memory drive if it contains less than 999 files. Try deleting unused files to free some space and try again. |
| No File | The memory card or USB Flash memory drive in the media drive does not contain a .JPG file. | Put the correct memory card or USB Flash memory drive into the slot again. |
| No Ink Cartridge | An ink cartridge is not installed correctly. | Take out the ink cartridge and put it in again seating it properly. (See <i>Replacing the ink cartridges</i> on page 33.) |
| No Paper Fed | The Photo Paper Tray is in the <i>Photo</i> printing position. | Make sure that the Photo Paper Tray is in the <i>Normal</i> printing position. (See step 4 and the Important note in <i>Loading photo paper</i> on page 12.) |
| | The machine is out of paper or paper is not correctly loaded in the paper tray. | Do one of the following: <ul style="list-style-type: none"> ■ Refill the paper in the paper tray, and then press Mono Start or Colour Start. ■ Remove the paper and load it again and then press Mono Start or Colour Start. (See <i>Loading paper and other print media</i> on page 8.) |
| | The paper is jammed in the machine. | Remove the jammed paper by following the steps in <i>Printer jam or paper jam</i> on page 44. |
| | The Jam Clear Cover is not closed correctly. | Check the Jam Clear Cover is closed evenly at both ends. (See <i>Printer jam or paper jam</i> on page 44.) |



| Error Message | Cause | Action |
|--|--|--|
| Out of Memory | The machine's memory is full. | Copy operation in progress: Press Stop/Exit and wait until the other operations in progress finish and then try again. |
| | The memory card or USB Flash memory drive you are using does not have enough free space to scan the documents. | Delete unused files from your memory card or USB Flash memory drive to make some free space and then try again. |
| Paper Jam | Paper is jammed in the machine. | Remove the jammed paper by following the steps in <i>Printer jam or paper jam</i> on page 44. |
| | | Make sure the paper length guide is adjusted to the correct paper size. |
| Unable to Clean XX Unable to Init. XX Unable to Print XX Unable to Scan XX | The machine has a mechanical problem. –OR– A foreign object such as a paper clip or ripped paper is in the machine. | Open the scanner cover and remove any foreign objects and paper scraps inside the machine. If the error message continues, disconnect the machine from the power for several minutes, then reconnect it. |
| Unusable Device Disconnect device from front connector & turn machine off & then on | A broken device has been connected to the USB direct interface. | Unplug the device from the USB direct interface, then press On/Off to turn the machine off and then on again. |
| Unusable Device Please Disconnect USB Device. | A USB device or USB Flash memory drive that is not supported has been connected to the USB direct interface. (For more information, visit us at http://solutions.brother.com/) | Unplug the device from the USB direct interface. |
| Wrong Paper Size | Paper is not the correct size. | Check that the Paper Size setting matches the size of paper in the tray. Load the correct size of paper, and then press Mono Start or Colour Start . (See <i>Paper Size</i> on page 16.) |

Error animation


Error animations display step-by-step instructions when paper gets jammed. You can read the steps at your own pace by pressing ► to see the next step and ◀ to go backward.

Document jam (DCP-J715W only)

Documents can jam in the ADF unit if they are not inserted or fed correctly, or if they are too long. Follow the steps below to clear a document jam.

Document is jammed in the top of the ADF unit

- 1 Take out any paper from the ADF that is not jammed.
- 2 Open the ADF cover.
- 3 Pull the jammed document up and to the left.




- 4 Close the ADF cover.
- 5 Press **Stop/Exit**.

! IMPORTANT

To avoid future document jams close the ADF cover correctly by pushing it gently in the middle.

Document is jammed inside the ADF unit

- 1 Take out any paper from the ADF that is not jammed.
- 2 Lift the document cover.
- 3 Pull the jammed document out to the left.





- 4 Close the document cover.
- 5 Press **Stop/Exit**.

B


Printer jam or paper jam

Take out the jammed paper depending on where it is jammed in the machine.


- 1 Unplug the machine from the electrical socket.
- 2 Open the Jam Clear Cover (1) at the back of the machine. Pull the jammed paper out of the machine.




- 3 Close the Jam Clear Cover. Make sure the cover is closed correctly.




- 4 If the paper support flap is open, close it, and then close the paper support. Pull the paper tray completely out of the machine.



- 5 Pull out the jammed paper (1).



- 6 Using both hands, grasp the plastic tabs on both sides of the machine and lift the scanner cover (1) until it locks securely in the open position.




Move the print head (if necessary) to take out any paper remaining in this area. Make sure that jammed paper is not left in the corners of the machine. Check *both* ends of the print carriage.



Note


If the print head is at the right corner as shown in the illustration, you cannot move it. Re-connect the power cord, then hold down **Stop/Exit** until the print head moves to the middle. Unplug the machine from the power source, and take out the paper.



! IMPORTANT


If ink gets on your skin or clothing immediately wash it off with soap or detergent.

- 7 Lift the scanner cover to release the lock (1). Gently push the scanner cover support down (2) and close the scanner cover (3) using both hands.



- 8 Push the paper tray firmly back into the machine.

- 9 While holding the paper tray in place, pull out the paper support (1) until it clicks, and then unfold the paper support flap (2).



Make sure you pull out the paper support until it clicks.

! IMPORTANT

DO NOT use the paper support flap for Legal size paper.

- 10 Re-connect the power cord.

Troubleshooting

If you think there is a problem with your machine, check the chart below and follow the troubleshooting tips.

Most problems can be easily resolved by yourself. If you need additional help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at <http://solutions.brother.com/>

If you are having difficulty with your machine

Printing

| Difficulty | Suggestions |
|--------------------|--|
| No printout | Check the interface cable on both the machine and your computer. (See <i>the Quick Setup Guide</i> .) |
| | Make sure the machine is plugged in and not turned off. |
| | Check to see if the LCD is showing an error message. (See <i>Error and Maintenance messages</i> on page 39.) |
| | One or more ink cartridges have reached the end of their life. (See <i>Replacing the ink cartridges</i> on page 33.) |
| | If the LCD says <code>Cannot Print and Replace Ink</code> , see <i>Replacing the ink cartridges</i> on page 33. |
| | Check that the correct printer driver has been installed and chosen. |
| | Make sure that the machine is online. Click Start and then Printers and Faxes . Choose Brother DCP-XXXX (where XXXX is your model name), and make sure that Use Printer Offline is unchecked. |
| | When you choose the Print Odd Pages and Print Even Pages settings, you may see a print error message on your computer, as the machine pauses during the printing process. The error message will disappear after the machine re-starts printing. |
| Poor print quality | Use only Genuine Brother Consumables as ink from other manufactures can cause print quality problems. |
| | Check the print quality. (See <i>Checking the print quality</i> on page 37.) |
| | Make sure that the Media Type setting in the printer driver or the <code>Paper Type</code> setting in the machine's menu matches the type of paper you are using. (See <i>Printing for Windows</i> [®] or <i>Printing and Faxing for Macintosh</i> in the <i>Software User's Guide</i> and <i>Paper Type</i> on page 16.) |
| | Make sure that your ink cartridges are fresh. The following may cause ink to clog: <ul style="list-style-type: none"> ■ The expiration date written on the cartridge package has passed. (Brother Original cartridges stay usable for up to two years if kept in their original packaging.) ■ The ink cartridge was in your machine over for six months. ■ The ink cartridge may not have been stored correctly before use. |
| | Try using the recommended types of paper. (See <i>Acceptable paper and other print media</i> on page 17.) |
| | The recommended environment for your machine is between 20 °C to 33 °C. |

Printing (continued)

| Difficulty | Suggestions |
|---|---|
| White horizontal lines appear in text or graphics. | Clean the print head. (See <i>Cleaning the print head</i> on page 37.) |
| | Make sure you are using Brother Original Innobella™ ink. |
| | Try using the correct types of paper. (See <i>Acceptable paper and other print media</i> on page 17.) |
| | If you want to print on Photo 10 × 15 cm or Photo L 89 × 127 mm paper, make sure you use the photo paper tray. (See <i>Loading photo paper</i> on page 12.) |
| The machine prints blank pages. | Clean the print head. (See <i>Cleaning the print head</i> on page 37.) |
| Characters and lines are stacked. | Check the printing alignment. (See <i>Checking the print alignment</i> on page 38.) |
| Printed text or images are skewed. | Make sure the paper is loaded correctly in the paper tray and the paper side guides are adjusted correctly. (See <i>Loading paper and other print media</i> on page 8.) |
| | Make sure the Jam Clear Cover is closed correctly. |
| Smudged stain at the top centre of the printed page. | Make sure the paper is not too thick or curled. (See <i>Acceptable paper and other print media</i> on page 17.) |
| Smudged stain at the right or left corner of the printed page. | Make sure the paper is not curled when you print on the back side of the paper with the Print Odd Pages and Print Even Pages settings. |
| Printing appears dirty or ink seems to run. | Make sure you are using the recommended types of paper. (See <i>Acceptable paper and other print media</i> on page 17.) Don't handle the paper until the ink is dry. |
| | If you are using photo paper, make sure that you have set the correct paper type. If you are printing a photo from your PC, set the Media Type in the Basic tab of the printer driver. |
| | Make sure you are using Brother Original Innobella™ ink. |
| Stains appear on the reverse side or at the bottom of the page. | Make sure the printer platen is not dirty with ink. (See <i>Cleaning the machine's printer platen</i> in appendix A in the <i>Advanced User's Guide</i> .) |
| | Make sure you are using the paper support flap. (See <i>Loading paper and other print media</i> on page 8.) |
| The machine prints dense lines on the page. | Check Reverse Order in the Basic tab of the printer driver. |
| The printouts are wrinkled. | In the printer driver Advanced tab, click Colour Settings , and uncheck Bi-Directional Printing . |
| | Make sure you are using Brother Original Innobella™ ink. |
| Cannot perform "Page Layout" printing. | Check that the paper size setting in the application and in the printer driver are the same. |
| Print speed is too slow. | Try changing the printer driver setting. The highest resolution needs longer data processing, sending and printing time. Try the other quality settings in the printer driver Advanced tab. Also, click the Colour Settings , and make sure you uncheck Colour Enhancement . |
| | Turn the borderless feature off. Borderless printing is slower than normal printing. (See <i>Printing for Windows</i> ® or <i>Printing and Faxing</i> for Macintosh in the <i>Software User's Guide</i> .) |
| Colour Enhancement is not working correctly. | If the image data is not full colour in your application (such as 256 colour), Colour Enhancement will not work. Use at least 24 bit colour data with the Colour Enhancement feature. |

Printing (continued)

| Difficulty | Suggestions |
|--|---|
| Photo paper does not feed correctly. | When you print on Brother Photo paper, load one extra sheet of the same photo paper in the paper tray. An extra sheet has been included in the paper package for this purpose. |
| | Clean the paper pick-up rollers. (See <i>Cleaning the paper pick-up rollers</i> on page 36.) |
| Machine feeds multiple pages. | Make sure the paper is loaded correctly in the paper tray. (See <i>Loading paper and other print media</i> on page 8.) |
| | Check that more than two types of paper are not loaded in the paper tray at any one time. |
| There is a paper jam. | Make sure the paper length guide is set to the correct paper size. Do not extend the paper tray when you load A5 or smaller size paper. (See <i>Printer jam or paper jam</i> on page 44.) |
| Printed pages are not stacked neatly. | Make sure you are using the paper support flap. (See <i>Loading paper and other print media</i> on page 8.) |
| Machine does not print from Adobe® Illustrator®. | Try to reduce the print resolution. (See <i>Printing for Windows®</i> or <i>Printing and Faxing for Macintosh</i> in the <i>Software User's Guide</i> .) |

Copying Difficulties

| Difficulty | Suggestions |
|--|--|
| Vertical black lines or streaks appear on copies. | Vertical black lines or streaks on copies are typically caused by dirt or correction fluid on the scanner. Clean scanner glass and white plastic above it. (See <i>Cleaning the scanner glass</i> on page 36.) |
| Poor copy results when using the ADF. (DCP-J715W only) | Try using the scanner glass. (See <i>Using the scanner glass</i> on page 21.) |
| Vertical black lines or streaks appear in copies. (DCP-J715W only) | Vertical black lines or streaks on copies are typically caused by dirt or correction fluid on the glass strip. Clean the glass strip. (See <i>Cleaning the scanner glass</i> on page 36.) |
| Fit to Page does not work correctly. | Make sure the document is not skewed on the scanner glass. Reposition the document and try again. |

Scanning Difficulties

| Difficulty | Suggestions |
|--|--|
| TWAIN/WIA errors appear when starting to scan. | Make sure the Brother TWAIN/WIA driver is chosen as the primary source. In PaperPort™ 11SE with OCR, click File, Scan or Get Photo and click Select to choose the Brother TWAIN/WIA driver. (DCP-J715W only) |
| Poor scanning results when using the ADF. (DCP-J715W only) | Try using the scanner glass. (See <i>Using the scanner glass</i> on page 21.) |
| OCR does not work. (DCP-J715W only) | Try increasing the scanner resolution. (Macintosh users) Presto! PageManager must be downloaded and installed before use. See <i>Accessing Brother Support (Macintosh)</i> on page 3 for further instructions. |

Software Difficulties

| Difficulty | Suggestions |
|---|--|
| Cannot install software or print. | (Windows® users only) Run the Repair MFL-Pro Suite program on the Installation CD-ROM. This program will repair and reinstall the software. |
| “Device Busy” | Make sure the machine is not showing an error message on the LCD. |
| Cannot print images from FaceFilter Studio. | To use FaceFilter Studio, you must install the FaceFilter Studio application from the Installation CD-ROM supplied with your machine. To install FaceFilter Studio see the <i>Quick Setup Guide</i> . Also, before you start FaceFilter Studio for the first time, you must make sure your Brother machine is turned on and connected to your computer. This will allow you to access all the functions of FaceFilter Studio. |

PhotoCapture Center™ Difficulties

| Difficulty | Suggestions |
|---|---|
| Removable Disk does not work correctly. | <ol style="list-style-type: none"> 1 Have you installed the Windows® 2000 update? If not, do the following: <ol style="list-style-type: none"> 1) Unplug the USB cable. 2) Install the Windows® 2000 update using one of the following methods. <ul style="list-style-type: none"> ■ Install MFL-Pro Suite from the Installation CD-ROM. (See the <i>Quick Setup Guide</i>.) ■ Download the latest service pack from the Microsoft Web site. 3) Wait about 1 minute after you restart the PC, and then connect the USB cable. 2 Take out the memory card or USB Flash memory drive and put it back in again. 3 If you have tried “Eject” from within Windows®, take out the memory card or USB Flash memory drive before you continue. 4 If an error message appears when you try to eject the memory card or USB Flash memory drive, it means the card is being accessed. Wait a while and then try again. 5 If all of the above do not work, turn off your PC and machine, and then turn them on again. (You will have to unplug the power cord of the machine to turn it off.) |
| Cannot access Removable Disk from Desktop icon. | Make sure that you have correctly inserted the memory card or USB Flash memory drive. |
| Part of my photo is missing when printed. | Make sure that Borderless Printing and Cropping are turned off. (See <i>Borderless printing</i> in chapter 4 and <i>Cropping</i> in chapter 4 in the <i>Advanced User's Guide</i> .) |

Network Difficulties

| Difficulty | Suggestions |
|---|--|
| Cannot print over the Network. | <p>Make sure that your machine is powered on and is online and in Ready mode. Print a Network Configuration list (see <i>Printing Reports</i> in <i>chapter 2</i> in the <i>Advanced User's Guide</i>) and check the current Network settings printed in this list.</p> <p>(DCP-J715W only)</p> <p>Reconnect the LAN cable to the hub to verify that the cabling and network connections are good. If possible, try connecting the machine to a different port on your hub using a different cable. If the connections are good, the machine shows LAN Active for 2 seconds.</p> <p>(If you are having Network problems, see the <i>Network User's Guide</i> for more information.)</p> |
| The network scanning feature does not work. | <p>(Windows® users)</p> <p>It is necessary to configure third-party Security/Firewall Software to allow Network scanning. To add port 54925 for Network scanning, enter the information below:</p> <p>In Name: Enter any description, for example Brother NetScan.</p> <p>In Port number: Enter 54925.</p> <p>In Protocol: UDP is selected.</p> <p>Please refer to the instruction manual that came with your third-party Security/Firewall Software or contact the software manufacturer.</p> <p>(Macintosh users)</p> <p>Re-select your machine in the Device Selector application located in Macintosh HD/Library/Printers/Brother/Utilities/DeviceSelector or from the model list in ControlCenter2.</p> |
| The Brother software cannot be installed. | <p>(Windows® users)</p> <p>Allow network access to the following programs if your security software displays an alert message during MFL-Pro Suite installation.</p> <p>BrC3Rgin.exe</p> <p>BmIPMon</p> <p>Brother Status Monitor (Network)</p> <p>ControlCenter Program</p> <p>Generic Host Process f...</p> <p>Setup.exe</p> <p>Spooler SubSystem App</p> <p>wdsw MFC Application</p> <p>(Macintosh users)</p> <p>Re-select your machine in the Device Selector application located in Macintosh HD/Library/Printers/Brother/Utilities/DeviceSelector or from the model list in ControlCenter2.</p> |
| Cannot connect to wireless network. | <p>Investigate the problem using the WLAN Report.</p> <p>Press Menu key, choose <i>Print Reports</i> and then press OK. Choose WLAN Report.</p> <p>For details, see the <i>Network User's Guide</i>.</p> |
| Reset the network settings. | <p>Press Menu key, choose <i>Network</i> and then press OK. Choose Network Reset.</p> <p>For details, see the <i>Network User's Guide</i>.</p> |

Machine Information

Checking the serial number

You can see the machine's serial number on the LCD.

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose `Machine Info`. Press **OK**.
- 3 Press **▲** or **▼** to choose `Serial No.` Press **OK**.
- 4 Press **Stop/Exit**.

Reset functions

The following reset functions are available:

1 `Network`

You can reset the print server back to its default factory settings such as the IP address information.

2 `All Settings`

You can reset all the machine settings back to the settings that were set at the factory.

Brother strongly recommends you use this operation when you dispose of the machine.



Note

Unplug the interface cable before you choose `Network` or `All Settings`. (DCP-J715W only)

How to reset the machine

- 1 Press **Menu**.
- 2 Press **▲** or **▼** to choose `Initial Setup`. Press **OK**.
- 3 Press **▲** or **▼** to choose `Reset`. Press **OK**.
- 4 Press **▲** or **▼** to choose the type of reset you want to use. Press **OK**. Press **+** to confirm.
- 5 Press **+** to reboot the machine.

C

Menu and features

On-screen programming

Your machine is designed to be easy to operate with LCD on-screen programming using the menu keys. User-friendly programming helps you take full advantage of all the menu selections your machine has to offer.

Since your programming is done on the LCD, we have created step-by-step on-screen instructions to help you program your machine. All you need to do is follow the instructions as they guide you through the menu selections and programming options.

Menu table

The menu table will help you understand the menu selections and options that are found in the machine's programs. The factory settings are shown in Bold with an asterisk.

Menu ()

| Level1 | Level2 | Level3 | Options | Descriptions | Page |
|--|--------------|---|---|---|--------------------|
| Ink Management | Test Print | — | Print Quality Alignment | Lets you check the print quality or alignment. | 37 |
| | Cleaning | — | Black Color All | Lets you clean the print head. | 37 |
| | Ink Volume | — | — | Lets you check the available ink volume. | See ¹ . |
| General Setup | Paper Type | — | Plain Paper* Inkjet Paper Brother BP71 Brother BP61 Other Glossy Transparency | Sets the type of paper in the paper tray. | 16 |
| | Paper Size | — | A4* A5 10x15cm Letter Legal | Sets the size of the paper in the paper tray. | 16 |
| | LCD Settings | Backlight | Light* Med Dark | You can adjust the brightness of the LCD backlight. | 7 |
| Dim Timer | | Off 10Secs 20Secs 30Secs* | You can set how long the LCD backlight stays on for after you go back to the Ready screen. | See ¹ . | |
| ¹ See <i>Advanced User's Guide</i> . | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

| Level1 | Level2 | Level3 | Options | Descriptions | Page |
|------------------------------|------------|--------|---|--|--------------------|
| General Setup (Continued) | Sleep Mode | — | 1Min 2Mins 3Mins 5Mins* 10Mins 30Mins 60Mins | You can choose how long the machine must be idle before it goes into sleep mode. | See ¹ . |

¹ See *Advanced User's Guide*.



The factory settings are shown in Bold with an asterisk.

Network menu (DCP-J515W)

| Level1 | Level2 | Level3 | Options | Descriptions |
|---------|--------|--------------------|---|---|
| Network | TCP/IP | BOOT Method | Auto* Static RARP BOOTP DHCP | Chooses the BOOT method that best suits your needs. |
| | | IP Address | [000-255]. [000-255]. [000-255]. [000-255] | Enter the IP address. |
| | | Subnet Mask | [000-255]. [000-255]. [000-255]. [000-255] | Enter the subnet mask. |
| | | Gateway | [000-255]. [000-255]. [000-255]. [000-255] | Enter the Gateway address. |
| | | Node Name | BRWXXXXXXXXXXXXXX | You can see the current Node name. |
| | | WINS Config | Auto* Static | You can choose the WINS configuration mode. |

See *Network User's Guide*.



The factory settings are shown in Bold with an asterisk.

| Level1 | Level2 | Level3 | Options | Descriptions | |
|-------------------------------|---|--|--|---|--|
| Network (Continued) | TCP/IP (Continued) | WINS Server | (Primary) 000.000.000.000 (Secondary) 000.000.000.000 | Specifies the IP address of the primary or secondary server. | |
| | | DNS Server | (Primary) 000.000.000.000 (Secondary) 000.000.000.000 | Specifies the IP address of the primary or secondary server. | |
| | | APIPA | On* Off | Automatically allocates the IP address from the link-local address range. | |
| | Setup Wizard | — | — | You can manually configure your print server for a wireless network. | |
| | WPS/AOSS | — | — | You can easily configure your wireless network settings using the one-button push method. | |
| | WPS w/PIN Code | — | — | You can easily configure your wireless network settings using WPS with a PIN code. | |
| | WLAN Status | Status | — | You can see the current wireless network status. | |
| | | Signal | — | You can see the current wireless network signal strength. | |
| | | SSID | — | You can see the current SSID. | |
| | | Comm. Mode | — | You can see the current Communication Mode. | |
| | MAC Address | — | — | You can see your machine's Mac address from the control panel. | |
| | WLAN Enable | — | On Off* | Lets you use the wireless network connection. | |
| | Network Reset | — | — | Restores all network settings to factory default. | |
| | See <i>Network User's Guide</i> . | | | | |
| |  | The factory settings are shown in Bold with an asterisk. | | | |

Network menu (DCP-J715W)

| Level1 | Level2 | Level3 | Level4 | Options | Descriptions |
|--|-----------|--------|--------------------|--|---|
| Network | Wired LAN | TCP/IP | BOOT Method | Auto* Static RARP BOOTP DHCP | Chooses the BOOT method that best suits your needs. |
| | | | IP Address | [000-255]. [000-255]. [000-255]. [000-255] | Enter the IP address. |
| | | | Subnet Mask | [000-255]. [000-255]. [000-255]. [000-255] | Enter the Subnet mask. |
| | | | Gateway | [000-255]. [000-255]. [000-255]. [000-255] | Enter the Gateway address. |
| | | | Node Name | BRNXXXXXXXXXXXX | Enter the Node name. |
| | | | WINS Config | Auto* Static | Chooses the WINS configuration mode. |
| | | | WINS Server | (Primary) 000.000.000.000 (Secondary) 000.000.000.000 | Specifies the IP address of the primary or secondary server. |
| | | | DNS Server | (Primary) 000.000.000.000 (Secondary) 000.000.000.000 | Specifies the IP address of the primary or secondary server. |
| | | | APIPA | On* Off | Automatically allocates the IP address from the link-local address range. |
| See <i>Network User's Guide</i> . | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

| Level1 | Level2 | Level3 | Level4 | Options | Descriptions |
|---|--|-------------|-------------|--|--|
| Network (Continued) | Wired LAN (Continued) | Ethernet | — | Auto* 100B-FD 100B-HD 10B-FD 10B-HD | Chooses the Ethernet link mode. |
| | | MAC Address | — | — | You can see your machine's Mac address from the control panel. |
| | WLAN | TCP/IP | BOOT Method | Auto* Static RARP BOOTP DHCP | Chooses the BOOT method that best suits your needs. |
| | | | IP Address | [000-255]. [000-255]. [000-255]. [000-255] | Enter the IP address. |
| | | | Subnet Mask | [000-255]. [000-255]. [000-255]. [000-255] | Enter the Subnet mask. |
| | | | Gateway | [000-255]. [000-255]. [000-255]. [000-255] | Enter the Gateway address. |
| | | | Node Name | BRWXXXXXXXXXXXXX | Enter the Node name. |
| | | | WINS Config | Auto* Static | Chooses the WINS configuration mode. |
| | | | WINS Server | (Primary) 000.000.000.000 (Secondary) 000.000.000.000 | Specifies the IP address of the primary or secondary server. |
| | | | DNS Server | (Primary) 000.000.000.000 (Secondary) 000.000.000.000 | Specifies the IP address of the primary or secondary server. |
| See Network User's Guide. | | | | | |
|  | The factory settings are shown in Bold with an asterisk. | | | | |

| Level1 | Level2 | Level3 | Level4 | Options | Descriptions | |
|------------------------|--|-----------------------|------------|--------------------|---|--|
| Network (Continued) | WLAN (Continued) | TCP/IP (Continued) | APIPA | On* Off | Automatically allocates the IP address from the link-local address range. | |
| | | Setup Wizard | — | — | You can manually configure your print server for a wireless network. | |
| | | WPS/AOSS | — | — | You can easily configure your wireless network settings using the one-button push method. | |
| | | WPS w/PIN Code | — | — | You can easily configure your wireless network settings using WPS with a PIN code. | |
| | | WLAN Status | Status | — | — | You can see the current wireless network status. |
| | | | Signal | — | — | You can see the current wireless network signal strength. |
| | | | SSID | — | — | You can see the current SSID. |
| | | | Comm. Mode | — | — | You can see the current Communication Mode. |
| | | MAC Address | — | — | — | You can see your machine's Mac address from the control panel. |
| | | Network I/F | — | Wired LAN* WLAN | — | You can choose the network connection type. |
| | Network Reset | — | Yes No | — | Restores all wired and wireless network settings to the factory default. | |
| | <i>See Network User's Guide.</i> | | | | | |
| |  The factory settings are shown in Bold with an asterisk. | | | | | |

Menu () (continued)

| Level1 | Level2 | Level3 | Options | Descriptions | Page |
|--|----------------|--------------|---------------------------------------|---|--------------------|
| Print Reports | Help List | — | — | You can print these lists and reports. | See ¹ . |
| | User Settings | — | — | | |
| | Network Config | — | — | | |
| | WLAN Report | — | — | | |
| Machine Info. | Serial No. | — | — | Lets you check the serial number of your machine. | 51 |
| Initial Setup | Date&Time | — | — | Puts the date and time in your machine. | See ² . |
| | Reset | Network | — | Resets the print server back to its factory default settings, such as the IP address information. | 51 |
| | | All Settings | — | Resets all the machine's settings back to the settings that were set at the factory. | 51 |
| | Local Language | — | (Choose the language you want to use) | Allows you to change the LCD language for your country. | See ¹ . |
| ¹ See <i>Advanced User's Guide</i> . ² See <i>Quick Setup Guide</i> . | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

Copy (Default display)

| Level1 | Level2 | Level3 | Options | Descriptions | Page |
|--|-----------------|--------|--|--|--------------------|
| Quality | — | — | Fast Normal* Best | Choose the Copy resolution for your type of document. | See ¹ . |
| Enlarge/Reduce | 100%* | — | — | — | |
| | Enlarge | — | 142% A5→A4 186% 10x15cm→LTR 198% 10x15cm→A4 | You can choose the enlargement ratio for the next copy. | |
| | Reduce | — | 47% A4→10x15cm 69% A4→A5 (DCP-J515W) 83% 93% A4→LTR 97% LTR→A4 (DCP-J715W) 83% LGL→A4 93% A4→LTR 97% LTR→A4 | You can choose the reduction ratio for the next copy. | |
| | Fit to Page | — | — | Your machine will adjust the size automatically to the paper size you set. | |
| | Custom(25-400%) | — | — | You can choose the enlargement or reduction ratio for the next copy. | |
| Paper Type | — | — | Plain Paper* Inkjet Paper Brother BP71 Brother BP61 Other Glossy Transparency | Choose the paper type that matches the paper in the tray. | 24 |
| Paper Size | — | — | A4* A5 10x15cm Letter Legal | Choose the paper size that matches the paper in the tray. | 24 |
| ¹ See <i>Advanced User's Guide</i> . | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

| Level1 | Level2 | Level3 | Options | Descriptions | Page |
|--|------------------------|-------------------|--|---|--------------------|
| Density | — | — | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> * <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Adjusts the density of copies. | See ¹ . |
| Ink Save Mode | — | — | On Off* | You can save some ink. | |
| Stack/Sort (DCP-J715W only) | — | — | Stack* Sort | You can choose to stack or sort multiple copies. | |
| Page Layout | — | — | Off (1 in 1)* 2 in 1 (P) 2 in 1 (L) 4 in 1 (P) 4 in 1 (L) Poster (3 x 3) | You can make N in 1 or Poster copies. | |
| Book Copy | On | — | — | Corrects dark borders and skew when copying from the scanner glass. | |
| | On (Preview) | (Skew Adjustment) | — | | |
| | | (Shadow Revise) | — | | |
| | Off* | — | — | | |
| Watermark Copy | Watermark Copy | — | On Off* (If you choose On, see the watermark copy settings in the following table.) | You can place a logo or text into your document as a Watermark. | |
| | Current Setting | — | — | | |
| | Exit | — | — | | |
| Set New Default | — | — | — | You can save your copy settings. | |
| Factory Reset | — | — | — | You can restore all settings to the factory settings. | |
| ¹ See <i>Advanced User's Guide</i> . | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

Watermark Copy Settings

| Option1 | Option2 | Option3 | Option4 | Descriptions | Page |
|----------|---------|---------------------|---|---|--------------------|
| Template | — | Text | CONFIDENTIAL* DRAFT COPY | Places a text into your document as a Watermark using a template. | See ¹ . |
| | | Position | A B C D E* F G H I Pattern | | |
| | | Size | Small Medium* Large | | |
| | | Angle | -90° -45°* 0° 45° 90° | | |
| | | Transparency | -2 -1 0* +1 +2 | | |
| | | Colour | Red Orange Yellow Blue Green Purple Black* | | |
| | | Apply | — | | |

¹ See *Advanced User's Guide*.



The factory settings are shown in Bold with an asterisk.

| Option1 | Option2 | Option3 | Option4 | Descriptions | Page |
|--|------------------------------------|---------------------|--|--|--------------------|
| Media | (Select image from media) | Position | A B C D E* F G H I Pattern | Places a logo or text into your document as a Watermark using an image from removable media. | See ¹ . |
| | | Size | Small Medium* Large | | |
| | | Angle | -90° -45°* 0° 45° 90° | | |
| | | Transparency | -2 -1 0* +1 +2 | | |
| | | Apply | — | | |
| Scan | (Set page and press Start) | Transparency | -2 -1 0* +1 +2 | Places a logo or text into your document as a Watermark using a scanned image. | |
| | | Apply | — | | |
| ¹ See <i>Advanced User's Guide</i> . | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

Photo Capture ()



| Level1 | Level2 | Level3 | Options | Descriptions | Page |
|------------------|-----------------|--------|---|---|--------------------|
| View Photo(s) | — | — | See the print settings in the following table. | You can preview your photos on the LCD. | 28 |
| Print Index | Layout Format | — | 6 Images/Line* 5 Images/Line | You can print a thumbnail page. | See ¹ . |
| | Paper Type | | Plain Paper* Inkjet Paper Brother BP71 Brother BP61 Other Glossy | | |
| | Paper Size | | A4* Letter | | |
| Print Photos | — | — | See the print settings in the following table. | You can print an individual image. | |
| Enhance Photos | Auto Correct | — | | You can adjust your photos with these settings. | |
| | Enhance Skin | | | | |
| | Enhance Scenery | | | | |
| | Remove Red-Eye | | | | |
| | Monochrome | | | | |
| Sepia | | | | | |
| Search by Date | — | — | You can search your photos in date order. | | |
| Print All Photos | — | — | You can print all photos in your media card or USB Flash memory drive. | | |
| Slide Show | — | — | The machine starts a Slide Show of your photos. | | |
| Trimming | — | — | You can trim your photo and print a part of the image. | | |






¹ See *Advanced User's Guide*.



The factory settings are shown in Bold with an asterisk.

Print Settings

| Option1 | Option2 | Option3 | Option4 | Descriptions | Page |
|--|---|---|---------|----------------------------------|--------------------|
| Print Quality (Does not appear for DPOF printing.) | Normal Photo* | — | — | Choose the print quality. | See ¹ . |
| Paper Type | Plain Paper Inkjet Paper Brother BP71 Brother BP61 Other Glossy* | — | — | Choose the paper type. | |
| Paper Size | 10x15cm* 13x18cm A4 Letter | (When Letter or A4 is chosen) 8 x 10cm 9 x 13cm 10 x 15cm 13 x 18cm 15 x 20cm Max. Size* | — | Choose the paper and print size. | |
| Brightness (Does not appear when Enhance Photos is chosen.) |  | — | — | Adjusts the brightness. | |
| Contrast (Does not appear when Enhance Photos is chosen.) |  | — | — | Adjusts the contrast. | |
| ¹ See <i>Advanced User's Guide</i> . | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

| Option1 | Option2 | Option3 | Option4 | Descriptions | Page |
|--|-----------------------|----------------------|---|--|--------------------|
| Color Enhance (Does not appear when Enhance Photos is chosen.) | On Off* | White Balance | +2  +1  0  -1  -2  | Adjusts the hue of the white areas. | See ¹ . |
| | | Sharpness | +2  +1  0  -1  -2  | Enhances the detail of the image. | |
| | | Color Density | +2  +1  0  -1  -2  | Adjusts the total amount of colour in the image. | |
| Cropping | On* Off | — | — | Crops the image around the margin to fit the paper size or print size. Turn this feature off if you want to print whole images or prevent unwanted cropping. | |
| Borderless | On* Off | — | — | Expands the printable area to fit the edges of the paper. | |
| Date Print (Does not appear when DPOF Print is chosen.) | On Off* | — | — | Prints the date on your photo. | |
| Set New Default | — | — | — | You can save your print settings. | |
| Factory Reset | — | — | — | You can restore all the settings to factory settings. | |
| ¹ See <i>Advanced User's Guide</i> . | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

Scan ()

| Level1 | Option1 | Option2 | Option3 | Descriptions | Page |
|---|-----------------|---------|--|---|--------------------|
| Scan to File | — | — | — | You can scan a monochrome or a colour document into your computer. | See ¹ . |
| Scan to Media (When a memory card or USB Flash memory drive is inserted.) | Quality | — | Color 150* Color 300 Color 600 B/W 200x100 B/W 200 | You can choose the scan resolution and file format for your document. | 29 |
| | File Type | — | (If you chose Colour option in Quality setting) PDF* JPEG | | |
| | | | (If you chose Mono option in Quality setting) PDF* TIFF | | |
| | File Name | — | — | | |
| | Auto Crop | — | On Off* | Scan multiple documents placed on the scanner glass to a memory card or USB Flash memory drive one at a time. | See ² . |
| | Set New Default | — | — | You can save your scan settings. | |
| Factory Reset | — | — | You can restore all settings to the factory settings. | | |
| Scan to E-mail | — | — | — | You can scan a monochrome or a colour document into your E-mail application. | See ¹ . |
| Scan to OCR ³ (DCP-J715W only) | — | — | — | You can have your text document converted to an editable text file. | |
| Scan to Image | — | — | — | You can scan a colour picture into your graphics application. | |
| <p>¹ See <i>Software User's Guide</i>.</p> <p>² See <i>Advanced User's Guide</i>.</p> <p>³ (Macintosh users) Presto! PageManager must be downloaded and installed before use. See <i>Accessing Brother Support (Macintosh)</i> on page 3 for further instructions.</p> | | | | | |
|  The factory settings are shown in Bold with an asterisk. | | | | | |

Entering Text

Press ▲, ▼, ◀ or ▶ to select numbers or characters you want to choose, and press **OK** repeatedly until the file name is complete.

Press ▲, ▼, ◀ or ▶ to select , and press **OK**.



Inserting special characters

To enter special characters, press ▲, ▼, ◀ or ▶ to select , and press **OK**.

Making corrections

If you entered an incorrect letter and want to change it, press ▲, ▼, ◀ or ▶ to select  or . Press **OK** several times to move the cursor under the incorrect character. Then press ▲, ▼, ◀ or ▶ to select , and press **OK**. Re-enter the correct letter.

General

| | | |
|---------------------------------------|--|---------------------------|
| Printer Type | Inkjet | |
| Print Method | Mono: | Piezo with 94 × 1 nozzle |
| | Colour: | Piezo with 94 × 3 nozzles |
| Memory Capacity | 40 MB | |
| LCD (Liquid Crystal Display) | Wide 3.3 in. (82.79 mm) TFT Colour LCD | |
| Power Source | AC 220 to 240V 50/60Hz | |
| Power Consumption ¹ | (DCP-J515W) | |
| | Copying Mode: | Approx. 17 W ² |
| | Standby Mode: | Approx. 3.5 W |
| | Sleep Mode: | Approx. 2 W |
| | Off: | Approx. 0.5 W |
| | (DCP-J715W) | |
| | Copying Mode: | Approx. 17 W ³ |
| | Standby Mode: | Approx. 6 W |
| | Sleep Mode: | Approx. 3.5 W |
| | Off: | Approx. 0.5 W |


¹ When all the modes are connected to USB.

² When resolution: standard, draft: ISO/IEC24712 printed pattern.


³ When using ADF, resolution: standard, draft: ISO/IEC24712 printed pattern.

Dimensions

(DCP-J515W)



(DCP-J715W)



Weight

(DCP-J515W) 6.9 kg

(DCP-J715W) 7.5 kg

Noise

Operating: 50 dB (A) or less ¹

Temperature

Operating: 10 - 35 °C

Best Print Quality: 20 - 33 °C

Humidity

Operating: 20 - 80% (without condensation)

Best Print Quality: 20 - 80% (without condensation)

ADF (automatic document feeder) (DCP-J715W only)

Up to 15 pages

Paper: 80 gsm A4 or Letter size

Document Size

ADF Width (DCP-J715W) : 148 mm to 215.9 mm

ADF Length (DCP-J715W) : 148 mm to 355.6 mm

Scanner Glass Width: Max. 215.9 mm

Scanner Glass Length: Max. 297 mm

¹ Noise depends on printing conditions.

Print media

Paper Input

Paper Tray

- Paper type:

Plain paper, inkjet paper (coated paper), glossy paper ¹, transparencies ^{1 2} and envelopes

- Paper size:

A4, Legal, Executive, Letter, A5, A6, JIS B5, envelopes (commercial No.10, DL, C5, Monarch, JE4), Photo 10 × 15 cm, Photo 2L 13 × 18 cm, Index card and Postcard ³

Width: 98 mm - 215.9 mm

Length: 148 mm - 355.6 mm

For more details, see *Paper weight, thickness and capacity* on page 20.

- Maximum paper tray capacity:

Approx. 100 sheets of 80 gsm plain paper

Photo Paper Tray

- Paper type:

Plain paper, inkjet paper (coated paper) and glossy paper ¹

- Paper size:

Photo 10 × 15 cm and Photo L 89 × 127 mm

Width: 89 mm - 102 mm

Length: 127 mm - 152 mm

- Maximum paper tray capacity:

Approx. 20 sheets

Paper Output

Up to 50 sheets of A4 plain paper (face up print delivery to the output paper tray) ¹

¹ For glossy paper or transparencies, we recommend removing printed pages from the output paper tray immediately after they exit the machine to avoid smudging.

² Use only transparencies recommended for inkjet printing.

³ See *Paper type and size for each operation* on page 19.

Copy

| | |
|--------------------------|--|
| Colour/Monochrome | Yes/Yes |
| Copy Width | Max. 210 mm |
| Multiple Copies | Stacks up to 99 pages |
| Enlarge/Reduce | 25% to 400% (in increments of 1%) |
| Copy Speed | Monochrome: Up to 23 pages/minute (A4 paper) ¹ Colour: Up to 20 pages/minute (A4 paper) ¹ |
| Resolution | (Monochrome) ■ Prints up to 1200 × 1200 dpi (Colour) ■ Prints up to 600 × 1200 dpi |

¹ Based on Brother standard pattern (Fast mode/Stack Copy). Copy speeds vary with the complexity of the document.

PhotoCapture Center™

| | |
|--------------------------------------|--|
| Compatible Media ¹ | <p>Memory Stick™ (16 MB - 128 MB)</p> <p>Memory Stick PRO™ (256 MB - 16 GB)</p> <p>Memory Stick Duo™ (16 MB - 128 MB)</p> <p>Memory Stick PRO Duo™ (256 MB - 16 GB)</p> <p>Memory Stick Micro™ (M2™) with adapter</p> <p>SD (16 MB to 2 GB)</p> <p>SDHC (4 GB to 16 GB)</p> <p>microSD with adapter</p> <p>miniSD with adapter</p> <p>USB Flash memory drive ² (DCP-J715W only)</p> |
| Resolution | Up to 1200 × 2400 dpi |
| File Extension | DPOF (ver.1.0, ver.1.1), Exif DCF (up to ver.2.1) |
| (Media Format) | Photo Print: JPEG ³ , AVI ⁴ , MOV ⁴ |
| (Image Format) | Scan to Media: JPEG, PDF (Colour) |
| | TIFF, PDF (Monochrome) |
| Number of Files | <p>Up to 999 files</p> <p>(The folder inside memory cards or USB Flash memory drive is also counted.)</p> |
| Folder | File must be stored in the 4th folder level of the memory card or USB Flash memory drive. |
| Borderless | A4, Letter, Photo 10 × 15 cm, Photo 2L 13 × 18 cm ⁵ |

¹ Memory cards, adapters and USB Flash memory drive are not included.

² USB 2.0 standard
 USB Mass Storage standard from 16 MB to 32 GB
 Support format: FAT12/FAT16/FAT32

³ Progressive JPEG format is not supported.

⁴ Motion JPEG only

⁵ See *Paper type and size for each operation* on page 19.

PictBridge (DCP-J715W only)

Compatibility

Supports the Camera & Imaging Products Association PictBridge standard CIPA DC-001.
Visit <http://www.cipa.jp/pictbridge> for more information.

Interface

USB direct interface

Scanner

| | |
|--------------------------|--|
| Colour/Monochrome | Yes/Yes |
| TWAIN Compliant | Yes (Windows® 2000 Professional/Windows® XP/ Windows® XP Professional x64 Edition/Windows Vista®/ Windows® 7) Mac OS X 10.4.11 - 10.5.x - 10.6.x ¹ |
| WIA Compliant | Yes (Windows® XP ² /Windows Vista®/Windows® 7) |
| ICA Compliant | Yes (Mac OS X 10.6.x) |
| Colour Depth | 36 bit colour Processing (Input) 24 bit colour Processing (Output) (Actual Input: 30 bit colour/Actual Output: 24 bit colour) |
| Resolution | Up to 19200 × 19200 dpi (interpolated) ³ Up to 1200 × 2400 dpi (optical) (Scanner Glass) Up to 1200 × 600 dpi (optical) (ADF) (DCP-J715W) |
| Scanning Speed | Monochrome: up to 3.44 sec. Colour: up to 4.83 sec. (A4 size at 100 × 100 dpi) |
| Scanning Width | Up to 210 mm |
| Scanning Length | Up to 291 mm |
| Greyscale | 256 levels |

¹ For the latest driver updates for the Mac OS X you are using, visit us at <http://solutions.brother.com/>

² Windows® XP in this User's Guide includes Windows® XP Home Edition, Windows® XP Professional, and Windows® XP Professional x64 Edition.

³ Maximum 1200 × 1200 dpi scanning when using the WIA Driver for Windows® XP, Windows Vista® and Windows® 7 (resolution up to 19200 × 19200 dpi can be chosen by using the Brother scanner utility).

Printer

| | |
|-----------------------|---|
| Resolution | Up to 1200 × 6000 dpi |
| Printing Width | 204 mm [210 mm (borderless) ¹] ³ |
| Borderless | A4, Letter, A6, Photo 10 × 15 cm, Index Card 127 × 203 mm, Photo L 89 × 127 mm, Photo 2L 13 × 18 cm, Postcard 1 100 × 148 mm ² |

¹ When you set the Borderless feature to On.

² See *Paper type and size for each operation* on page 19.

³ When printing on A4 size paper.

Interfaces

USB^{1 2} Use a USB 2.0 interface cable that is no longer than 2 m.

LAN cable³ (DCP-J715W only) Use an Ethernet UTP cable category 5 or greater.

Wireless LAN IEEE 802.11b/g (Infrastructure/Ad-hoc Mode)

- ¹ Your machine has a Hi-Speed USB 2.0 interface (DCP-J715W only).
The machine can also be connected to a computer that has a USB 1.1 interface.
- ² Third party USB ports are not supported.
- ³ See *Network (LAN)* on page 80 and the *Network User's Guide* for detailed network specifications.

Computer requirements

| SUPPORTED OPERATING SYSTEMS AND SOFTWARE FUNCTIONS | | | | | | | | | |
|--|--|--|--|---|--------------------------------|--------------------------------|----------------------------|------------------|--|
| Computer Platform & Operating System Version | | Supported PC Software Functions | PC Interface | Processor Minimum Speed | Minimum RAM | Recommended RAM | Hard Disk Space to install | | |
| | | | | | | | For Drivers | For Applications | |
| Windows® Operating System ¹ | Windows® 2000 Professional ⁴ | Printing, Scanning, Removable Disk ⁵ | USB, 10/100 Base-TX (Ethernet) (DCP-J715W) Wireless 802.11b/g | Intel® Pentium® II or equivalent | 64 MB | 256 MB | 110 MB | 340 MB | |
| | Windows® XP Home ^{2 4} Windows® XP Professional ^{2 4} | | | | 128 MB | | 110 MB | 340 MB | |
| | Windows® XP Professional x64 Edition ² | | | 64-bit (Intel®64 or AMD64) supported CPU | 256 MB | 512 MB | 110 MB | 340 MB | |
| | Windows Vista® ² | | | Intel® Pentium® 4 or equivalent 64-bit (Intel®64 or AMD64) supported CPU | 512 MB | 1 GB | 600 MB | 530 MB | |
| | Windows® 7 ² | | | | 1 GB (32 bit) 2 GB (64 bit) | 1 GB (32 bit) 2 GB (64 bit) | 650 MB | 530 MB | |
| Macintosh Operating System | Windows Server® 2003 (print only via network) | Printing | 10/100 Base-TX (Ethernet) (DCP-J715W) Wireless 802.11b/g | Intel® Pentium® III or equivalent | 256 MB | 512 MB | 50 MB | N/A | |
| | Windows Server® 2003 x64 Edition (print only via network) | | | | | | | | 64-bit (Intel®64 or AMD64) supported CPU |
| | Windows Server® 2003 R2 (print only via network) | | | Intel® Pentium® III or equivalent | 512 MB | 1 GB | 80 MB | 400 MB | |
| | Windows Server® 2003 R2 x64 Edition (print only via network) | | | 64-bit (Intel®64 or AMD64) supported CPU | | | | | |
| | Windows Server® 2008 (print only via network) | | | Intel® Pentium® 4 or equivalent 64-bit (Intel®64 or AMD64) supported CPU | | | | | 2 GB |
| | Windows Server® 2008 R2 (print only via network) | | | 64-bit (Intel®64 or AMD64) supported CPU | | | | | |
| Mac OS X 10.4.11 - 10.5.x | Printing, Scanning, Removable Disk ⁵ | USB ³ , 10/100 Base-TX (Ethernet) (DCP-J715W) Wireless 802.11b/g | PowerPC G4/G5 Intel® Core™ Processor | 512 MB | 1 GB | 80 MB | 400 MB | | |
| | | | | Intel® Core™ Processor | 1 GB | | | 2 GB | |

Conditions:

- ¹ Microsoft® Internet Explorer® 5.5 or greater.
- ² For WIA, 1200 × 1200 resolution. Brother Scanner Utility enables to enhance up to 19200 × 19200 dpi.
- ³ Third party USB ports are not supported.
- ⁴ PaperPort™ 11SE supports Microsoft® SP4 or higher for Windows® 2000 and SP2 or higher for XP (DCP-J715W only).
- ⁵ Removable disk is a function of PhotoCapture Center™.

For the latest driver updates, visit <http://solutions.brother.com/>

All trademarks, brand and product names are the property of their respective companies.

Consumable items

| | |
|--------------------------------------|--|
| Ink | The machine uses individual Black, Yellow, Cyan and Magenta ink cartridges that are separate from the print head assembly. |
| Service Life of Ink Cartridge | The first time you install a set of ink cartridges the machine will use an amount of ink to fill the ink delivery tubes for high quality printouts. This process will only happen once. After this process is complete the cartridges provided with your machine will have a lower yield than standard cartridges (65%). With all following ink cartridges you can print the specified number of pages. |
| Replacement Consumables | <p>(DCP-J515W)</p> <p><Low Yield Black> LC39BK, <Low Yield Cyan> LC39C, <Low Yield Magenta> LC39M, <Low Yield Yellow> LC39Y</p> <p>Black - Approximately 300 pages ¹</p> <p>Cyan, Magenta, Yellow - Approximately 260 pages ¹</p> <p>(DCP-J715W)</p> <p><Standard Black> LC67BK, <Standard Cyan> LC67C, <Standard Magenta> LC67M, <Standard Yellow> LC67Y</p> <p>Black - Approximately 450 pages ¹</p> <p>Cyan, Magenta, Yellow - Approximately 325 pages ¹</p> <p>¹ Approx. cartridge yield is declared in accordance with ISO/IEC 24711</p> <p>For more information about the replacement consumables, visit us at www.brother.com/pageyield</p> |

What is Innobella™?

Innobella™ is a range of genuine consumables offered by Brother. The name "Innobella™" derives from the words "Innovation" and "Bella" (meaning "Beautiful" in Italian) and is a representation of the "innovative" technology providing you with "beautiful" and "long lasting" print results.

When you print photo images, Brother recommends Innobella™ glossy photo paper (BP71 series) for high quality. Brilliant prints are made easier with Innobella™ Ink and paper.



Network (LAN)



For details about the full Network specifications, see the *Network User's Guide*.

| | | |
|----------------------------------|--|-----|
| LAN | You can connect your machine to a network for Network Printing, Network Scanning and access photos from PhotoCapture Center™ ¹ . Also included is Brother BRAdmin Light ² Network Management software. | |
| Wireless Network Security | SSID (32 chr), WEP 64/128 bit, WPA-PSK (TKIP/AES), WPA2-PSK (AES) | |
| Setup Support Utility | AOSS™ | Yes |
| | WPS | Yes |

¹ See the Computer Requirements chart on page 78.

² If you require more advanced printer management, use the latest Brother BRAdmin Professional utility version that is available as a download from <http://solutions.brother.com/>

A

- ADF (automatic document feeder)21
- Apple Macintosh
 - See Software User's Guide.

C

- Cleaning
 - paper pick-up roller36
 - print head37
 - scanner36
- Consumable items79
- Control panel overview4
- ControlCenter
 - See Software User's Guide.
- Copy
 - paper size24
 - paper type24
 - using scanner glass21

D

- Document
 - loading 21, 22

E

- Envelopes 10, 11, 12, 19, 20
- Error messages on LCD39
 - B&W Print Only39
 - Cannot Print40
 - Cover is Open40
 - Data Remaining40
 - Document Jam40
 - Ink Low41
 - No Ink Cartridge41
 - No Paper Fed41
 - Out of Memory42
 - Paper Jam42
 - Unable to Clean42
 - Unable to Init.42
 - Unable to Print42
 - Unable to Scan42

G

- Greyscale 75

H

- Help
 - LCD messages 52
 - Menu Table 53

I

- Ink cartridges
 - ink dot Counter 33
 - replacing 33
- Innobella™ 79

J

- Jams
 - document 43
 - paper 44

L

- LCD (Liquid Crystal Display) 52
 - Brightness 7

M

- Macintosh
 - See Software User's Guide.
- Maintenance, routine
 - replacing ink cartridges 33
- Mode, entering
 - PhotoCapture 5
 - Scan 5

N

- Network
 - Printing
 - See Network User's Guide.
 - Scanning
 - See Software User's Guide.
- Number of Copies key 4

O

- On/Off key 4
- Out of Memory message 42

P

- Paper 17, 71
 - capacity 20
 - loading 8, 10, 12
 - loading envelopes and postcards 10
 - loading photo paper 12
 - printable area 15
 - size 16, 19
 - size of document 21
 - type 16, 19
- PaperPort™ 11SE with OCR
 - See Software User's Guide. See also Help in the PaperPort™ 11SE application.
- Photo Paper Tray 12
- PhotoCapture Center™
 - from PC
 - See Software User's Guide.
 - Memory Stick PRO™ 25
 - Memory Stick™ 25
 - Preview photos 28
 - Print settings
 - Quality 28
 - SD 25
 - SDHC 25
 - specifications 73
- Presto! PageManager
 - See Software User's Guide. See also Help in the Presto! PageManager application.
- Print
 - area 15
 - difficulties 46
 - improving quality 37
 - on small paper 14
 - paper jams 44
 - resolution 76
 - specifications 76
- Programming your machine 52

R

- Resolution
 - copy 72
 - print 76
 - scan 75

S

- Scannable area 22
- Scanner glass
 - cleaning 36
 - using 21
- Scanning
 - See Software User's Guide.
- Serial Number
 - how to find See inside front cover

T

- Transparencies 16, 17, 18, 19, 20, 71
- Troubleshooting 46
 - document jam 43
 - error messages on LCD 39
 - if you are having difficulty
 - copying 48
 - Network 50
 - PhotoCapture Center™ 49
 - printing 46
 - scanning 48
 - software 49
 - paper jam 44
 - print alignment 38
 - print quality 37

W

- Windows®
 - See Software User's Guide.

For Australia Only:

Warranty & Repair - For details about warranty on your Brother Product, the details are listed on the following link: www.brother.com.au under Warranty. For warranty service (repair) of your Brother product you will need to retain a copy of your sales docket and contact the Support Centre for location of the nearest Authorised Warranty Centre (AWC)

Support - For technical support for your Brother Product other than what you can resolve through the User's Guide, please visit our website or our solutions website for FAQs/Troubleshooting, Drivers & Software, or contact the Product Support Centre for any technical or customer care/support enquiry.

Product Support Centre: Australia

Brother International (Aust) Pty Ltd

Phone: 02 8875 6000
Fax: 02 9870 7223
Email: productsupport@brother.com.au
Web Site: www.brother.com.au
Solutions Site: <http://solutions.brother.com>

Our Technical Support Consultants are available 5 days a week by phone during the hours of 8.30am to 5pm Monday to Friday.

For New Zealand Only:

To contact Brother International (NZ) Limited for support with a Brother product please use the following methods.

Phone:

| | |
|-----------------------------|--|
| Premium End User Assistance | 0900 552 152 |
| Auto Attendant Self Help | 0800 652 152 |
| Brother Recycle Assistance | 0800 632 467 |
| Fax Assistance | 0800 837 822 |
| Email Assistance | Please visit www.brother.co.nz and submit a helpdesk enquiry from Online Help |
| Web Assistance | Please visit www.brother.co.nz under Online Help for Frequently Asked Questions, Driver downloads, Warranty information and Service Centres |

Our Technical Support Consultants are available 7 days a week by phone during the hours of 8.30am to 5pm Monday to Friday and 9am to 5pm Saturday and Sunday. Outside of these hours you can find assistance from our Auto Attendant Self Help and our Website www.brother.co.nz under Online Help.

brother®

Visit us on the World Wide Web
<http://www.brother.com>

This machine is approved for use in the country of purchase only. Local Brother companies or their dealers will only support machines purchased in their own countries.