

9019

SINGER

CONGRATULATIONS

You are about to begin an adventure in creativity. You are going to sew! And, you are going to sew with one of the easiest to use machines ever made

The following features have been included on your machine, promising rewarding hours of uncomplicated sewing pleasure:

- Clearly defined thread path, reducing the possibility of threading errors.
- Built in buttonholder for fast, easy buttonholes
- Start needle designed to allow you to sit, see & sew better
- One-step pattern selection, eliminating complicated selection operation

In addition, this machine features a removable bed extension, permitting both flat and free-arm sewing; snap-on presser feet that are quickly removed and easily replaced; a one-way needle clamp that makes it impossible to put the needle in backwards; and a one step buttonhole attachment that allows you to make buttonholes in one, easy step!

Take some time to acquaint yourself with this owner's manual and your machine. Whether you are a novice or an experienced sewer, you will discover how easy it is to create something uniquely your own!


Dear Customer:

We recommend that for future reference you record the Serial Number of your Sewing Machine in the space provided.

Refer to illustration at right for location of Serial Number on your machine.

Model No. _____

Serial No. _____



To ensure that you are always provided with the most modern sewing capabilities, the manufacturer reserves the right to change the appearance, design or accessories of this sewing machine when considered necessary.

*A Trademark of The Singer Company

Printed in Taiwan

TABLE OF CONTENTS

Important Safeguards.....	2
1. Getting to Know Your Machine	3
Principal Parts.....	4
Accessories.....	5
2. Getting Ready to Sew	7
Connecting the Machine/Running the Machine.....	7
Choosing and Changing Needles.....	7
Free Arm Sewing.....	8
Changing Presser Foot.....	8
Replacing Presser Foot with Shank.....	9
Attaching Feed Cover.....	10
Winding a Bobbin.....	10
Threading the Machine.....	11
Inserting a Wound Bobbin.....	12
Raising Bobbin Thread.....	13
Selecting a Pattern.....	14
3. Straight Stitching	15
Preparation.....	16
Sewing a Seam.....	16
Free Motion Embroidery.....	17
Inserting a Zipper.....	19
4. Special Stitches	20
Preparation.....	20
Zig-Zag Stitch.....	20
Zig-Zag Blindstitch.....	21
Multi Stitch Zig-Zag.....	22
"M" Stitch.....	23
Crescent Stitch.....	23
Arrow Stitch.....	24
Domino Stitch/Rampart Stitch/Satin Bead Stitch.....	24
Stretch Overedge Stitch.....	25
Straight Stretch Stitch.....	26
5. One-Step Buttonholing	27
6. Caring for Your Machine	29
Removing and Replacing Bobbin Case.....	29
Removing and Replacing Light Bulb.....	30
Cleaning the Machine.....	31
Performance Checklist.....	31
Additional Accessories.....	32
Fabric, Thread and Needle Table.....	33
	34

IMPORTANT SAFETY INSTRUCTIONS

When using this machine, basic safety precautions should always be followed including the following:
Read all instructions before using this machine.

DANGER.

To reduce the risk of electric shock:

- The machine should never be left unattended when plugged in. Always unplug the machine from the electric outlet immediately after using and before cleaning.
- Always unplug before changing light bulb. Replace bulb with the same type rated 15 watts. Be sure to replace the face plate which covers the light bulb before operating the machine.

WARNING.

To reduce the risk of burns, fire, electric shock or injury to persons:

- Be sure that the electrical voltage of the socket outlet (wall receptacle) is the same as the rated voltage of the motor.
- Use this machine only for its intended use as described in this Operator's Guide. Use only attachments recommended by the manufacturer as contained in the Operator's Guide.
- To disconnect, turn all controls to the off ("0") position, then remove plug from outlet.
- Disconnect the power-line plug from the socket outlet or switch the machine off when making any adjustments in the needle area, such as threading needle, changing needle, changing needle plate or changing presser foot, etc.
- Always unplug the machine from the electrical outlet when removing covers, lubricating, or when making any other user servicing adjustments mentioned in the Operator's Guide.
- Do not attempt to adjust the motor belt. Contact your nearest Service Center should any adjustment be required.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Handle the foot controller with care and avoid dropping it on the floor. Be sure not to place anything on top of it.
- Always use the proper needle plate. The wrong plate can cause the needle to break.
- Do not use bent needles.
- When sewing, keep fingers away from all moving parts. Special care is required around the sewing machine needle.

- Do not pull or push fabric while stitching. This may deflect the needle causing it to break.

- Before removing the bobbin case, remove plug from the socket outlet.
- For double insulated machines, when servicing, use only identical Singer replacement parts. See Instructions for Servicing of Double-Insulated Appliances.
- Never operate the machine if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the machine to the nearest authorized dealer or Service Center for examination, repair, electrical, or mechanical adjustment.
- Never operate the machine with any air openings blocked. Keep ventilation openings of the machine and foot controller free from the accumulation of lint, dust, and loose cloth.

- Never drop or insert any object into any opening.
- Do not use outdoors.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

- Do not allow to be used as a toy. Close attention is necessary when the machine is used by or near children.
- SERVICING OF DOUBLE-INSULATED PRODUCTS. In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, nor should a means for grounding be added to the product. Servicing of a double-insulated product requires extreme care and knowledge of the system, and should be done only by qualified service personnel. Replacement parts for a double-insulated product must be identical to those parts in the product. A double-insulated product is marked with the words "DOUBLE-INSULATION" or "DOUBLE INSULATED".

SAVE THESE INSTRUCTIONS

Servicing should be performed by an authorized service representative.

This product is intended for household use.

FOR EUROPEAN AND SIMILAR TERRITORIES:

This product is suppressed for radio and television interference with the International Electrotechnical Commission requirements of the CISPR.

Machines for Great Britain and some other countries having similar wiring standards are shipped from the factory with a plug for connection to the mains. The wires in this mains lead are coloured in accordance with the following code:


Blue: neutral (N) Brown: live (L)

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red. If a 13 Amp. (BS 1363) plug is used, a 3 Amp. fuse must be fitted, or if any other type of plug is used, a 5 Amp. fuse must be fitted either in the plug or adaptor or at the distribution board. Neither cord is to be connected to the earth terminal of a three-pin plug.

SECTION 1 GETTING TO KNOW YOUR MACHINE

Principal Parts




Principal Parts

1. **Hand Wheel** provides a means for raising or lowering the needle.
2. **Bobbin Winder** lets you fill the bobbin with thread quickly and easily.
3. **Pattern Display Panel** shows a variety of patterns available for your sewing needs.
4. **Spool Pin and Cap** hold the top thread supply and allow it to unwind smoothly as the spool does not turn.
5. **Stitch Width Lever** controls the width of patterns and sets the needle for straight stitching.
6. **Snap-In Thread Guide** helps to insure a smooth flow of thread from the spool to the tension.
7. **Bobbin Winder Tension Disc** provides thread tension for bobbin winding.
8. **Needle Thread Tension Dial** controls top thread tension.
9. **Face Plate** is a removable cover protecting movable parts and sewing light.
10. **Sewing Light** illuminates sewing area.
11. **Buttonhole Lever** activates the one-step buttonholer.
12. **Needle Clamp** holds needle in machine and prevents incorrect insertion.
13. **Needle Plate** supports the fabric during sewing.
14. **Removable Extension Table** lets you change the machine bed from flat to free arm.
15. **Presser Foot Lifter**, at the back of machine, lets you raise and lower presser foot.
16. **Thread Cutter**
17. **Slide Plate** opens for easy removal and replacement of bobbin.
18. **Feed System** moves fabric under presser foot.
19. **Presser Foot** holds fabric against the feed system and snaps on and off.
20. **Stitch Length Lever** allows for a variety of stitch lengths.
21. **Power and Light Switch** turns on the machine and sewing light at the same time.
22. **Reverse Lever** provides either momentary or continuous reverse fabric movement.
23. **Pattern Selector Dial** turns directly to any of the patterns, plus buttonhole, shown on the pattern display panel.
24. **Stitch Balance Ring** adjusts appearance of Special Stitch patterns and buttonholes.
25. **Electrical Power Cord** connects machine to your electrical outlet.
26. **Speed Controller** regulates the sewing machine speed.

ACCESSORIES


The accessories for your machine are designed to simplify many of your sewing projects.



1. **General Purpose Needle Plate (A)**, and **Presser Foot (B)**, are standard on the machine. Used for straight and zig-zag sewing.
2. **Zipper Foot (E)**, for inserting zippers.
3. **Feed Cover (F)**, used for button sewing, free motion work and darning. It keeps the feed from moving fabric.
4. **Special Purpose Presser Foot (J)**, used for decorative and zig-zag stitching.
5. **One-Step Buttonhole Attachment (L)**, used to stitch a complete buttonhole in one single step.
6. **Spool Holder**, for medium and large thread spools.
7. **Lint Brush**, for cleaning the machine.
8. **Needle Pack**, includes an assortment for sewing various types of fabrics.
9. **Bobbins**, transparent for easy viewing.
10. **Blindstitch Hem Guide**, is used to position the hem for blindstitch hemming.

SECTION 2 GETTING READY TO SEW CONNECTING THE MACHINE

Before plugging in your machine, be sure that the voltage and number of cycles indicated on the electrical data table (1), conform to your electrical power supply.




Plug the controller (2), into the receptacle, at the right end of the machine.

Then connect the electrical power cord plug (3), to your electrical outlet.

Do not operate machine without material under the presser foot as this may damage the feed and the foot.

RUNNING THE MACHINE

The machine and the sewing light are turned on and off by the same power switch.



POWER SWITCH


Power on-press "1" side of switch.
Power off-press "0" side.

To run the machine, press the speed controller. The harder you press, the faster the machine will sew.

To stop the machine from sewing, remove pressure from speed controller.

CHOOSING AND CHANGING NEEDLES


IMPORTANT: For best sewing results, use only Singer needles. Check the needle package, and the Fabric, Thread and Needle Table on page 34, for the correct needle and fabric combination.



- Raise needle to its highest position.
- Loosen needle clamp screw and remove needle.
- With flat side of needle to the back, insert new needle up into clamp as far as it will go.
- Tighten needle clamp screw securely.


FREE ARM SEWING

Free arm sewing makes it easier to sew hard-to-reach areas.




To change machine for free arm sewing, push in and lift right edge (1) of extension table, slide it to the left and off the machine.

- Topstitch edges on sleeves, or finish waistbands and pants legs easily.




- Sew buttonholes without stretching cuffs or neckbands.




CHANGING THE PRESSER FOOT (B) (E) (J) (L)


Your machine comes with the General Purpose Presser Foot already attached. You can easily change to any one of the other presser feet which snap onto a common shank by following the directions below.



- Raise needle to its highest position by turning hand wheel toward you.
- Raise presser foot using presser foot lifter in back of machine.
- Push toe of presser foot (1) up, until it snaps off the shank (2).




- Take foot off machine.



- Place new foot under center of shank.
- Lower presser foot lifter, fitting shank over presser foot pin (3).
- Don't turn screw. Instead, push presser foot screw (4) down firmly until foot snaps into place.

REPLACING PRESSER FOOT WITH SHANK


Presser feet with built-in shanks can be replaced as follows:



- Turn machine off.
- Raise needle and presser foot.
- Loosen presser foot screw (1) and remove presser foot with shank (2), guiding it toward you and to the right.
- To replace presser foot with shank, hook shank around the presser bar and tighten presser foot screw.

ATTACHING FEED COVER (F)

The feed cover keeps the feed from moving the fabric.





- Raise needle and presser foot.
- Open slide plate.
- Slide feed cover on top of needle plate, pressing tabs (1) and (2) into holes.
- Close slide plate.
- To remove, open slide plate and lift front edge of cover; pull it away.

WINDING A BOBBIN

Winding a bobbin is quick and easy when you follow the directions below. Always wind the bobbin **before** threading the machine.

- Push in indent (1) on hand wheel disc. This will stop the needle from moving.
- Place spool of thread on spool pin.
- Slide spool cap (2) firmly over rim of spool to prevent thread tangling.
- Lead thread from spool and snap into thread guide post (3).
- Wind thread clockwise around front of bobbin winder tension disc (4).
- Pass thread end, from inside, through small hole in rim of bobbin.
- Place bobbin on spindle and push it to the right.
- Holding thread end, step on speed controller to run machine until desired amount of thread is wound.
- Cut thread; push bobbin to the left and remove it from spindle.
- Trim thread end from top of bobbin.
- Return hand wheel disc to sewing position by pressing on side opposite indent.




THREADING THE MACHINE

Your sewing machine is easily threaded. The clear threading path helps you avoid threading errors.


To thread your machine correctly, simply follow the steps below:

- Raise presser foot lifter.
- Raise needle to its highest position by turning hand wheel toward you.
- Place spool of thread on spool pin (1).
- Slide spool cap (2) firmly over the rim of the spool to prevent thread tangling.
- Snap thread into thread guide post (3).
- Following arrows, guide thread into threading channel (4) down to needle and firmly pull thread.
- Thread needle from front to back.




INSERTING A WOUND BOBBIN


To insert a bobbin, follow the instructions below.




- Raise presser foot.
- Turn hand wheel toward you until needle is in its highest position.



- Open slide plate and remove bobbin.
- 1. Pull 4" (10cm) of thread from replacement bobbin and insert bobbin into case, as shown.



- 2. Holding bobbin in place, guide thread into notch (1), and then into notch (2).




- 3. Draw several inches of thread across bobbin.

- 4. While holding thread on outside, close slide plate.


- Follow directions for "Raising Bobbin Thread" on page 14.

RAISING THE BOBBIN THREAD


Once the needle has been threaded and the bobbin placed in the bobbin case, the bobbin thread must be brought up through the hole in the needle plate.




1. Hold needle thread with left hand.
 - Turn hand wheel slowly toward you, lowering needle into hole in plate.



2. Continue to do this until needle rises above needle plate.
 - Pull gently on needle thread and bring up bobbin thread in a loop.




3. Open loop with fingers to find end of bobbin thread.



4. Draw needle thread through left side opening in presser foot.
 - Pull both threads to back of machine.

SELECTING A PATTERN


All the patterns your machine is capable of sewing are illustrated on the pattern display panel of your sewing machine.



With each application, recommended settings are given. These have been highlighted for easy identification. You can adjust each setting, however, as desired.

SECTION 3 STRAIGHT STITCHING

Before beginning a sewing project, check the Fabric, Thread and Needle Table on page 34 for the best needle and thread combination for your fabric.



- If your machine has 16 or 22 patterns, it will indicate patterns by pattern indicator.

- Select a pattern by turning the selector dial until indicator appears under desired pattern.

- For instance, to sew a Zig-Zag Stitch, you would turn the selector dial until the indicator appears as (1).

- To change the stitch pattern, turn the dial left or right, moving indicator to desired position.

RECOMMENDED SETTINGS


Stitch Selection:	Straight Stitch
Stitch Width:	
Stitch Length:	
Foot:	General Purpose (B)
Needle Plate:	General Purpose (A)

ADJUSTING STITCH LENGTH


The stitch length indicator is numbered 0 - 4. The lower numbers are shorter stitches. Shorter stitches are best for light-weight fabrics; longer ones for heavy fabrics. To adjust the length of your stitches, slide the stitch length lever to the left or right.

ADJUSTING THREAD TENSION


Having selected the correct needle and thread combination for the fabric being used, it may be necessary to adjust the tension of the sewing machine to insure a well-balanced stitch.



Proper tension will produce identical stitches on both the front and back of your fabric (1).




• **Too little tension** will produce a loose stitch, causing loops in your seams (2). Adjust tension by rotating the dial clockwise to a tighter setting.



• **Too much tension** will produce a tight stitch which will cause puckered seams (3). Adjust tension by rotating the dial counterclockwise to a looser setting.

SEWING A SEAM

You can sew seams easily and accurately when you follow the suggestions below.




BASTING

Pin basting and hand basting are easy ways to make temporary seams before machine sewing.

• To pin baste, insert pins at stitching line. **NEVER** place pins on the underside of fabric in contact with the feed. **Do not** sew over pins; pull them out as you stitch.


• To hand baste, make long, loose stitches that can be easily removed.



PLACING FABRIC UNDER PRESSER FOOT

• To place fabric under presser foot, raise presser foot lifter (1) to its "up" position (2), where it locks in place.


• The lifter can be raised and held in the "extra high" position (3) for bulky fabrics.



STITCHING IN REVERSE

• To reinforce beginnings or ends of seams, push in reverse lever (1). Machine will stitch in reverse for as long as you hold the lever in.

• For continuous reverse stitching, push lever in and slide it to the left to lock. Unlock reverse lever by sliding it back to the right and letting it return to its normal position.





KEEPING SEAMS STRAIGHT

To keep seams straight, use one of the guidelines on the needle plate. The most commonly used line (1) is extended onto the slide plate. The crosslines (2) serve as guides when stitching square corners.

TURNING SQUARE CORNERS


To turn a square corner, use crosslines on slide plate.

- Line up fabric with extended guidelines on needle plate and stitch seam, slowing speed as you approach corner.
- When bottom of fabric reaches cornering crosslines (2) on slide plate, stop stitching.
- Be sure needle is down in fabric.
- Raise presser foot slightly. Turn fabric, bringing bottom edge in line with guideline (1).
- Continue stitching seam.



Sewing Curved Seams

- Baste seam line.
- Use a short stitch for elasticity and strength.
- Guide fabric to follow curve.



FREE MOTION EMBROIDERY

In free motion embroidery, you sew without a presser foot, and control the fabric with an embroidery hoop.


RECOMMENDED SETTINGS

Stitch Selection: Straight Stitch or Zig-Zag
 Stitch Width: |||
 Stitch Length: 4-5
 Foot: Remove foot with shank
 Needle Plate: General Purpose (A)

- Attach Feed Cover
- Be sure to lower presser foot lifter.
- When embroidering, as shown, use straight stitches for stems, and zig-zag stitches, at varying widths, for leaves and petals. Lengthen stitches by moving the hoop faster or slower.

INSERTING A ZIPPER


The zipper package will provide complete instructions for inserting zippers.



RECOMMENDED SETTINGS

Stitch Selection: Straight Stitch
 Stitch Width: |||
 Stitch Length: 4-5
 Foot: Zipper (E)
 Needle Plate: General Purpose (A)


- When zipper is to the left of needle, attach left side of zipper foot to shank. The needle will enter left notch of foot, sewing close along zipper teeth.



- Attach right side of zipper foot to shank when a zipper is to the right side of the needle. The needle will enter right notch of foot, sewing close along zipper teeth.


SECTION 4 SPECIAL STITCHES

The Special Stitches on your machine have a variety of practical and decorative uses. In this section are recommended applications for each stitch. However, these stitches can be used for many other sewing projects.



ADJUSTING STITCH WIDTH

To widen or narrow a Special Stitch pattern, move the stitch width lever off Straight Stitch, , toward any other width setting at the right.



ADJUSTING STITCH LENGTH


The stitch length indicator is numbered 0 to 4. The area between 0 and 1 will produce very dense stitching. For more open stitching, slide the stitch length lever anywhere from 2 to 4. When sewing special color coded stitches, The length **MUST** be set in the 3-1/2 to 4 area.

ADJUSTING THREAD TENSION

Some Special Stitch patterns may require looser thread tension than others. To find the proper tension for your application, make a test sample with the thread and fabric you will be using.

ADJUSTING STITCH BALANCE

You can adjust the appearance of special color coded stitch patterns on the display panel, by turning the Stitch balance ring (1) behind the pattern selector dial (2).




A correctly balanced Fagoting Stitch should appear as illustrated (3).

When stitches are too close together (4), separate them by turning the stitch balance ring to the right.

When stitches are too far apart (5), bring them closer together by turning the stitch balance ring to the left.

ZIG-ZAG STITCH WWW

The Zig-Zag Stitch can be used when sewing seams, appliquéing, monogramming or decorating.



SEAM FINISHING

Use a zig-zag stitch to finish seam edges of fabrics that are likely to unravel.

- Sew seams as desired; trim and press open.

RECOMMENDED SETTINGS

Stitch Selection: Zig-Zag Stitch
 Stitch Width: 
 Stitch Length: 
 Foot: 
 Needle Plate: General Purpose (B)
 General Purpose (A)

- Place edge of seam allowance under foot, as shown.
- Stitch close to edge, letting outer zig-zag fall over edge.

SATIN STITCHING

Satin stitching is a series of closely spaced zig-zag stitches. Satin stitch monograms, embroidery and appliques for a smooth, satin-like finish.

- Practice to get desired stitch appearance.

Block Monogramming

- Lightly trace letters on right side of fabric.


RECOMMENDED SETTINGS

Stitch Selection: Zig-Zag Stitch
 Stitch Width: 
 Stitch Length: 
 Foot: 
 Needle Plate: Special Purpose (J)
 General Purpose (A)

- Center tracing under needle.
- Stitch entire outline, leaving needle in fabric when turning.
- Pull threads to wrong side of fabric; tie and trim.

ZIG-ZAG BLINDSTITCH

Use this Blindstitch when sewing hems and seams, or attaching lace and elastic.




- BLINDSTITCH HEMMING**
- Practice first on a scrap of material, carefully following each step.

RECOMMENDED SETTINGS	
Stitch Selection:	Zig-Zag Blindstitch
Stitch Width:	
Stitch Length:	Adjustable
Foot:	Blindstitch (K)
Needle Plate:	General Purpose (A)

- With garment inside out, mark, fold and press hemline (1).
- Turn hem (1) back against inside of garment, leaving $\frac{1}{8}$ " of hem beyond fold (2), as shown.
- Pin or baste all layers in place.


Position the hem under the presser foot with the soft fold resting against wall of the guide. Be sure the flange of the guide is between the soft fold and the top of the hem, as shown.

- Lower the presser foot and begin sewing making certain the straight stitches fall on the edge of the hem and the zig-zag stitches just pierce the soft fold of the work. Adjust stitch width if necessary. While stitching, guide the hem edge in a straight line and feed the soft fold evenly against the wall of the guide.
- If layers of fabric are pinned together, remove pins as you come to them. Do not sew over pins.




MULTI-STITCH ZIG-ZAG

Mending, overcasting, joining or reinforcing can all be done using the Multi-Stitch Zig-Zag.




- MENDING A TEAR**
- Trim ragged edges of tear.
 - Cut a lining of fabric for reinforcement.
 - Bring the edges of tear together and baste lining to wrong side of fabric.


RECOMMENDED SETTINGS	
Stitch Selection:	Multi-Stitch Zig-Zag
Stitch Width:	
Stitch Length:	Adjustable
Foot:	Special Purpose (J)
Needle Plate:	General Purpose (A)

- Place tear, right side up, under presser foot.
- Stitch over the line of the tear, shortening stitch length at each end for reinforcement.
- Trim thread ends close to fabric.
- If needed, sew over tear again.
- Trim away lining close to stitching.

"M" STITCH 
These stitches can be used for stretch seams and decorative stitching.




- LACE TRIM**
- Lace trim may be added to blouses, lingerie and children's wear.
- Cut lace to desired size.
 - Pin lace to right side of fabric where desired.

RECOMMENDED SETTINGS	
Stitch Selection:	"M" Stitch/Sandcastle
Stitch Width:	
Stitch Length:	Adjustable
Foot:	Special Purpose (J)
Needle Plate:	General Purpose (A)

- Carefully stitch along both edges of lace, as shown.
- Trim away the fabric under the lace near stitching lines.

CRESCENT STITCH

These stitches are ideal for borders, edges, smocking and embroidering.





BORDER DESIGN

Border designs decorate clothing and many household items.


- Sew Seams in usual manner and press.
- Mark stitching lines of fabric where desired.

RECOMMENDED SETTINGS

- Stitch Selection: Crescent Stitch
- Stitch Width: 
- Stitch Length: 
- Foot:  Special Purpose (J)
General Purpose (A)
- Needle Plate: 
- Center marked line under presser foot and stitch.
 - Pull threads to wrong side of fabric; tie and trim.

ARROW STITCH



These stitches are decorative and secure finish to seams, pleats and pockets it can also be used as a border design.



BORDER DESIGN


- Sew seams in usual manner and press.
- Mark stitching lines on fabric where desired.

RECOMMENDED SETTINGS

- Stitch Selection: Arrow Stitch
- Stitch Width: 
- Stitch Length: 
- Foot:  Special Purpose (J)
General Purpose (A)
- Needle Plate: 
- Center stitching line under presser foot, and sew.
 - Trim thread ends close to fabric.


DOMINO STITCH

Your machine can sew several stitches which are solely decorative. These stitches let you create unique, personalized garments and household items.




- Use the DOMINO STITCH to form a lively border along the edges of a pair of pillow cases.

RECOMMENDED SETTINGS



- Stitch Selection: Domino Stitch
- Stitch Width: 
- Stitch Length: 
- Foot:  Special Purpose (J)
General Purpose (A)
- Needle Plate: 

RAMPART STITCH




Sewing over filler cord, narrow ribbon, elastic, yarn or thread.

RECOMMENDED SETTINGS




- Stitch Selection: Rampart Stitch
- Stitch Width: 
- Stitch Length: 
- Foot:  Special Purpose (J)
General Purpose (A)
- Needle Plate: 

SATIN BEAD STITCH




Decorative stitches for borders and smocking.

RECOMMENDED SETTINGS

- Stitch Selection: Satin Bead Stitch
- Stitch Width: 
- Stitch Length: 
- Foot:  Special Purpose (J)
General Purpose (A)
- Needle Plate: 

STRETCH OVEREDGE STITCH

With this stitch you can stitch and finish a seam in one step. It is also ideal for finishing seams, hems and facings requiring stretch.



OVEREDGE SEAM

- Trim seam edge 1/4" (6mm) from position you wish your seam.

RECOMMENDED SETTINGS

Stitch Selection: Stretch Overedge Stitch

Stitch Width:


Stitch Length:

Foot: Special Purpose (J)
Needle Plate: General Purpose (A)
Adjust balance, if necessary

- Position trimmed seam under presser foot, as shown.
- Straight stitches should fall on seam line; zig-zag stitches should fall over seam edge.

STRAIGHT STRETCH STITCH

This is a heavy-duty, stretch stitch that can also be used for topstitching.



TOPSTITCHING

- Sew seams in usual manner and press.
- For topstitching hard-to-reach areas, convert machine to free arm sewing.

RECOMMENDED SETTINGS

Stitch Selection: Straight Stretch Stitch

Stitch Width:


Stitch Length:

Foot: Special Purpose (J)
Needle Plate: General Purpose (A)
Adjust balance, if necessary

- Place garment right side up, under foot.
- Slowly topstitch desired areas.
- Pull threads to wrong side of fabric; tie and trim.
- To create a straight stretch stitch, set stitch width to the left and stitch length to #4.

SECTION 5 ONE-STEP BUTTONHOLING

- Your machine automatically makes a buttonhole to the size of your button in one, easy step. You never need to move the fabric or reposition the needle.
- Always make a practice buttonhole on a sample of your fabric.
- Be sure bobbin contains enough thread.
- When making buttonholes on hard-to-free arm sewing.
- Mark buttonhole position on fabric as indicated in pattern.



RECOMMENDED SETTINGS

Stitch Selection: Buttonhole Stitch

Stitch Width:

Stitch Length:


Foot: Buttonhole Attachment (L)
Needle Plate: General Purpose (A)

Fastening the Buttonhole Attachment

- Remove presser foot from shank.
- Place buttonhole attachment behind shank and guide it forward.
- Center pin (1) in attachment under shank, and lower presser foot lifter.
- Press presser foot screw down firmly until shank snaps into place.

Setting the Length of Buttonhole

- Open button clamp (2) and place button on carrier (3)
- Slide clamp (2) back to hold button in place.
- Raise foot lifter and draw needle thread (A) and bobbin thread (B) between upper (4) and lower (5) plates of button attachment, and to the back of machine.
- Place fabric between upper and lower plates.
- Center 3 red guidelines (6) of attachment around beginning line of buttonhole.
- Lower presser foot lifter.
- Push foot from back of button carrier (7) toward you to insure proper buttonhole length.



- Pull buttonhole lever (8), located under sewing light, straight down as far as it will go.
- Press it toward you.
- Start running the machine.
- The entire buttonhole will be stitched in one operation.
- Stop sewing when machine begins overlapping starting stitches.
- Raise foot lifter and remove work from machine; clip thread ends; cut buttonhole opening with scissors or seam ripper.
- (Adjust width and balance of test buttonhole, if necessary.)
- Press buttonhole lever toward you for each buttonhole to be sewn.
- When all buttonholes are completed, push buttonhole lever (8) back up into machine.
- To remove buttonhole attachment, raise presser foot lifter and press down on both sides of button carrier near shank, and slide off machine.

ADJUSTING WIDTH OF BUTTONHOLE OPENING


If the width of the buttonhole opening is too narrow or too wide, it can be adjusted by the stitch width lever.

- Widen the buttonhole opening by moving the stitch width lever slightly left.
- Narrow the buttonhole opening by moving the stitch width lever slightly right.

ADJUSTING BALANCE OF BUTTONHOLE


If the two stitching sides of your buttonhole are unequal, turn stitch balance ring (9) behind pattern selector dial.

- If the right side of stitching is too open (10), turn stitch balance ring slightly left.
- If the left side of stitching is too open (11), turn stitch balance ring slightly right.



SECTION 6 CARING FOR YOUR MACHINE


REMOVING AND REPLACING BOBBIN CASE



- CAUTION:** Before cleaning or adjusting the machine, remove plug from the socket outlet.
- Raise presser foot and needle.
 - Open slide plate and remove bobbin.
 - To remove the bobbin case, the needle plate must be removed first.
 - Lift needle plate (1) from right corner and slide out from under foot.

TO REMOVE BOBBIN CASE

- With a small screwdriver, turn lever (2) back as far as it will go.
- Lift out bobbin case.




TO REPLACE THE BOBBIN CASE

- Guide forked end (3) of bobbin case under feed (4).
- Draw rim of bobbin case under position plate (5).
- Turn lever (2) toward you, locking bobbin case in place.

NOTE: After locking case in place, be sure it is not tight, but can move slightly.


- To replace needle plate, slide it under pin (6) and push it to the left.
- Press needle plate down in place.
- Insert bobbin and close slide plate.



REMOVING AND REPLACING LIGHT BULB

CAUTION:

- Before changing light bulb, make sure you have removed plug from socket outlet. Be sure to replace the face plate which covers the light bulb before operating the machine.




- This machine is designed to use a 15-watt maximum light bulb.

To change the light bulb, the face plate must first be removed.

- Loosen and remove screw (1).
- Slide face plate down and away from machine.


TO REMOVE THE LIGHT BULB

- Push bulb up into socket (2) and turn to the left to unlock bulb pins.
- Pull bulb down and out of socket.



TO REPLACE THE LIGHT BULB


- Push new bulb up into socket and turn to the right until pins lock into position.
- Reposition face plate by sliding top edge of plate under edge of top cover.
- Line up screw hole in plate with screw hole in machine.
- Insert screw and tighten.



20

CLEANING THE MACHINE

Your machine is designed to give you many years of dependable service. To ensure this reliability, take a few minutes to keep the machine clean. How often you clean it depends on how often you use it.



- Using the lint brush, remove lint or dust from:
 - presser bar
 - needle bar
 - bobbin case (if there is a lot of lint in this area, remove the bobbin case for cleaning)
 - machine surface (if necessary, dampen a soft cloth and use a mild soap to clean the surface)
- Remove needle plate as instructed and clean exposed area with a lint brush.

PERFORMANCE CHECKLIST

When sewing difficulties occur, look back through this manual to make sure you are correctly following the instructions. If you still have a problem, the reminders below may help you to correct it.

Needle Does Not Move

- Is machine connected to electrical supply?
- Is the power and light switch on?
- Is controller connected?

Lower Thread Breaks

- Is bobbin correctly wound?
- Is bobbin correctly inserted in to bobbin case?
- Is bobbin case correctly threaded?

Skipped Stitches

- Is machine properly threaded?
- Is fabric firmly held down?
- Is needle correct style and size?
- Is needle straight and sharp?

Needle Moves But Stitch Is Not Formed

- Is needle defective?
- Is needle fully inserted into needle clamp?
- Are bobbin and needle correctly threaded?
- Is bobbin correctly inserted into bobbin case?

Needle Breaks

- Is needle straight and sharp?
- Is needle correct size?
- Is needle fully inserted into needle clamp?
- Are controls properly set?
- Are accessories correct for application?

Fabric Does Not Move Properly Under Presser Foot

- Is presser foot correctly attached to machine?
- Is presser foot lowered?
- Is stitch length correctly set?

Bobbin Winding Difficulties


- Is thread unwinding freely from spool?
- Is bobbin winder engaged?
- Is thread end securely held at start of wind?

Upper Thread Breaks

- Is machine properly threaded?
- Is thread freely unwinding from spool?
- Is proper spool cap being used?
- Is needle correct size for thread?
- Is upper thread tension too tight?
- Is bobbin case properly inserted?
- Is bobbin rim free of nicks?

ADDITIONAL ACCESSORIES

Additional Accessories for your sewing machine are available at your sewing center.



1. **Seam Guide (N)**, helps keep seam allowance even.
2. **Blindstitch Presser Foot (K)**, helps guide fabric for nearly invisible blind-stitch hems.
3. **Button Sewing Foot (H)**, holds buttons securely for fastening.
4. **Darning and Embroidery Foot (G)**, is recommended for free motion work, such as embroidery, monogramming and decorative designs.
5. **Even Feed Foot (M)**, is used for sewing hard to feed pile, stretch and bonded fabrics. Also excellent for plaids, stripes and topstitching.
6. **Overedge Foot**, use with Overedge Stretch Stitch for seams in stretch fabrics.
7. **Seam Ripper**, used to pick and cut threads quickly and neatly.
8. **Twin Needle and Spool Pin (R)**, are used for decorative twin needle (2 threads) stitching on woven and knit fabrics.
9. **Needle Threader (P)**, assists in threading machine needle.
10. **Narrow Hemmer Foot** is used to stitch a narrow hem in a single operation.
11. **Straight Stitch Presser Foot (D)**, and **Needle Plate (C)**, are used when straight stitching light-weight fabrics.

