


SONY

Cyber-shot

Digital Still Camera **User's Guide/ Troubleshooting**



DSC-H2/H5



"Read This First" (separate volume)

Explains the set-up and basic operations for shooting/playback with your camera.

Operating Instructions

Before operating the unit, please read this manual and "Read This First" (separate volume) thoroughly, and retain it for future reference.

Owner's Record

The model and serial numbers are located on the bottom. Record the serial number in the space provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. DSC-H2/H5

Serial No. _____

Additional information on this product and answers to frequently asked questions can be found at our Customer Support Website.

<http://www.sony.net/>



Printed on 100% recycled paper using VOC (Volatile Organic Compound)-free vegetable oil based ink.



2673176120

Printed in Japan



**Enjoying
the camera**



Using the menu



Using the Setup
screen



Using your computer



Printing still images



Connecting your
camera to your TV



Troubleshooting



Others




Index

WARNING

To reduce fire or shock hazard, do not expose the unit to rain or moisture.

For Customers in the U.S.A.



This symbol is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

IMPORTANT SAFEGUARDS

For your protection, please read these safety instructions completely before operating the appliance, and keep this manual for future reference.

Carefully observe all warnings, precautions and instructions on the appliance, or the one described in the operating instructions and adhere to them.

Use

Power Sources

This set should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of electrical power supplied to your home, consult your dealer or local power company. For those sets designed to operate from battery power, or other sources, refer to the operating instructions.

Polarization

This set may be equipped with a polarized ac power cord plug (a plug having one blade wider than the other).

This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to have a suitable outlet installed. Do not defeat the safety purpose of the polarized plug by forcing it in.

Overloading

Do not overload wall outlets, extension cords or convenience receptacles beyond their capacity, since this can result in fire or electric shock.

Object and Liquid Entry

Never push objects of any kind into the set through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the set.

Attachments

Do not use attachments not recommended by the manufacturer, as they may cause hazards.

Cleaning

Unplug the set from the wall outlet before cleaning or polishing it. Do not use liquid cleaners or aerosol cleaners. Use a cloth lightly dampened with water for cleaning the exterior of the set.

Installation

Water and Moisture

Do not use power-line operated sets near water – for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.

Power-Cord Protection

Route the power cord so that it is not likely to be walked on or pinched by items placed upon or against them, paying particular attention to the plugs, receptacles, and the point where the cord exits from the appliance.

Accessories

Do not place the set on an unstable cart, stand, tripod, bracket, or table. The set may fall, causing serious injury to a child or an adult, and serious damage to the set. Use only a cart, stand, tripod, bracket, or table recommended by the manufacturer.

Ventilation

The slots and openings in the cabinet are provided for necessary ventilation. To ensure reliable operation of the set, and to protect it from overheating, these slots and openings must never be blocked or covered.

- Never cover the slots and openings with a cloth or other materials.
- Never block the slots and openings by placing the set on a bed, sofa, rug, or other similar surface.
- Never place the set in a confined space, such as a bookcase, or built-in cabinet, unless proper ventilation is provided.
- Do not place the set near or over a radiator or heat register, or where it is exposed to direct sunlight.

Lightning

For added protection for this set during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the set due to lightning and power-line surges.

Service

Damage Requiring Service

Unplug the set from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power cord or plug is damaged or frayed.
- If liquid has been spilled or objects have fallen into the set.
- If the set has been exposed to rain or water.
- If the set has been subject to excessive shock by being dropped, or the cabinet has been damaged.
- If the set does not operate normally when following the operating instructions. Adjust only those controls that are specified in the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the set to normal operation.
- When the set exhibits a distinct change in performance – this indicates a need for service.

Servicing

Do not attempt to service the set yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Replacement parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer that have the same characteristics as the original parts. Unauthorized substitutions may result in fire, electric shock, or other hazards.

Safety Check

Upon completion of any service or repairs to the set, ask the service technician to perform routine safety checks (as specified by the manufacturer) to determine that the set is in safe operating condition.

Read this first

For Customers in the U.S.A. and Canada

RECYCLING NICKEL METAL HYDRIDE BATTERIES

Nickel Metal Hydride batteries are recyclable.

You can help preserve our environment by returning your used rechargeable batteries to the collection and recycling location nearest you.

For more information regarding recycling of rechargeable batteries, call toll free 1-800-822-8837, or visit <http://www.rbrc.org/>

Caution: Do not handle damaged or leaking Nickel Metal Hydride batteries.



For Customers in the U.S.A.

If you have any questions about this product, you may call:

Sony Customer Information Services Center
1-800-222-SONY (7669)

The number below is for the FCC related matters only.

Regulatory Information

Declaration of Conformity

Trade Name: SONY
Model No.:DSC-H5
Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo,
San Diego, CA 92127 U.S.A.
Telephone No.: 858-942-2230

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

Trade Name: SONY
Model No.:DSC-H2
Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo,
San Diego, CA 92127 U.S.A.
Telephone No.: 858-942-2230

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The supplied interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

For Customers in Europe

This product has been tested and found compliant with the limits set out in the EMC Directive for using connection cables shorter than 3 meters (9.8 feet).

Attention

The electromagnetic fields at the specific frequencies may influence the picture and sound of this camera.

Notice

If static electricity or electromagnetism causes data transfer to discontinue midway (fail), restart the application or disconnect and connect the communication cable (USB, etc.) again.

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.

Notice for customers in the United Kingdom

A moulded plug complying with BS 1363 is fitted to this equipment for your safety and convenience. Should the fuse in the plug supplied need to be replaced, a fuse of the same rating as the supplied one and approved by ASTA or BSI to BS 1362, (i.e., marked with an  or  mark) must be used.

If the plug supplied with this equipment has a detachable fuse cover, be sure to attach the fuse cover after you change the fuse. Never use the plug without the fuse cover. If you should lose the fuse cover, please contact your nearest Sony service station.

Notes on using your camera

Types of “Memory Stick” that can be used (not supplied)

The IC recording medium used by this camera is a “Memory Stick Duo”. There are two types of “Memory Stick”.

“Memory Stick Duo”: you can use a “Memory Stick Duo” with your camera.



“Memory Stick”: you cannot use a “Memory Stick” with your camera.



Other memory cards cannot be used.

- For details on “Memory Stick Duo”, see page 108.

When using a “Memory Stick Duo” with “Memory Stick” compatible equipment

You can use the “Memory Stick Duo” by inserting it into the Memory Stick Duo Adaptor (not supplied).



Memory Stick Duo Adaptor

Notes on the Nickel-Metal Hydride battery

- Charge both of the Ni-MH batteries (supplied) before using the camera for the first time.
(→ step 1 in “Read This First”)
- The batteries can be charged even if they are not completely discharged. Also, even if batteries are not fully charged, you can use the partially charged capacity of the batteries as is.
- If you do not intend to use the batteries for a long time, use up the existing charge and

remove them from your camera, then store them in a cool, dry place. This is to maintain the batteries’ functions (page 110).

- For details on the usable batteries, see page 110.

Carl Zeiss lens

This camera is equipped with a Carl Zeiss lens which is capable of reproducing sharp images with excellent contrast.

The lens for this camera has been produced under a quality assurance system certified by Carl Zeiss in accordance with the quality standards of Carl Zeiss in Germany.

No compensation for contents of the recording

- The contents of the recording cannot be compensated for if recording or playback is not possible due to a malfunction of your camera or recording media, etc.

Internal memory and “Memory Stick Duo” back up

- Do not turn off the camera or remove the battery or “Memory Stick Duo” while the access lamp is lighted, as the internal memory data or “Memory Stick Duo” data may be destroyed. Always protect your data by making a back up copy. See page 30 for the data back up method.


Notes on recording/playback

- This camera is neither dust-proof, nor splash-proof, nor water-proof. Read “Precautions” (page 112) before operating the camera.
- Before you record one-time events, make a trial recording to make sure that the camera is working correctly.
- Be careful not to get the camera wet. Water entering the inside of the camera may cause malfunctions which in some cases may not be repairable.
- Do not aim the camera at the sun or other bright light. This may cause irrecoverable damage to your eyes. Or it may cause the malfunction of your camera.
- Do not use the camera near a location that generates strong radio waves or emits radiation. The camera may not be able to record or play back properly.

- Using the camera in sandy or dusty locations may cause malfunctions.
- If moisture condensation occurs, remove it before using the camera (page 112).
- Do not shake or strike the camera. In addition to malfunctions and an inability to record images, this may render the recording medium unusable, or cause image data breakdown, damage or loss.
- Clean the flash surface before use. The heat of flash emission may cause dirt on the flash surface to become discolored or to stick to the flash surface, resulting in insufficient light emission.

Notes on the LCD screen, LCD finder and lens

- The LCD screen and the LCD finder are manufactured using extremely high-precision technology so over 99.99% of the pixels are operational for effective use. However, there may be some tiny black points and/or bright points (white, red, blue or green in color) that constantly appear on the LCD screen and the LCD finder. These points are normal in the manufacturing process and do not affect the recording in any way.



Black, white, red,
blue and green
points

- Exposing the LCD screen or the lens to direct sunlight for long periods may cause malfunctions. Be careful when placing the camera near a window or outdoors.
- Do not press against the LCD screen. The screen may be discolored and that may cause a malfunction.
- Images may trail across on the LCD screen in a cold location. This is not a malfunction.
- This camera is equipped with a power zoom lens. Be careful not to bump the lens, and be careful not to apply force to it.

On image data compatibility

- This camera conforms with DCF (Design rule for Camera File system) universal standard established by JEITA (Japan Electronics and

Information Technology Industries Association).

- Playback of images recorded with your camera on other equipment and playback of images recorded or edited with other equipment on your camera are not guaranteed.

Warning on copyright

Television programs, films, videotapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the provisions of the copyright laws.

The pictures used in this manual

The photographs used as examples of pictures in this manual are reproduced images, and are not actual images shot using this camera.

On illustrations

Illustrations used in this manual are of the DSC-H2 unless noted otherwise.

For full use of the digital still camera

Prepare the camera and shoot images easily




“Read This First” (separate volume)

- 1 Prepare the batteries
- 2 Turn the camera on/set the clock
- 3 Insert a “Memory Stick Duo” (not supplied)
- 4 Select the image size for use
- 5 Shoot images easily (Auto adjustment mode)
Shoot still images (Scene Selection)
- 6 View/delete images

Get more friendly with your camera

This manual



- Shoot with your favorite settings (Program auto shooting/ Manual exposure shooting) → page 33
- Enjoy various shooting/playback using the menu → page 43
- Change the default settings → page 56

Connect your camera to a PC or a printer

This manual



- Copy your images to a computer and enjoy editing them in various ways → page 69
- Print images by connecting your camera directly to a printer (PictBridge compliant printers only) → page 86

Table of contents

Read this first.....	5
Notes on using your camera	7



Enjoying the camera

Basic techniques for better images.....	13
Focus – Focusing on a subject successfully.....	13
Exposure – Adjusting the light intensity.....	14
Color – On the effects of lighting	16
Quality – On “image quality” and “image size”	16
Identifying parts	18
Indicators on the screen.....	22
Changing the screen display.....	27
Number of still images and recording time of movies	28
When you do not have a “Memory Stick Duo” (Recording with the internal memory).....	29
Battery life and number of images that can be recorded/viewed	31
Using the jog dial	32
Using the mode dial	33
Shooting with manual adjustment.....	35
Continuous shooting	41

Using the menu

<i>Using menu items</i>	43
<i>Menu items</i>	44
Shooting menu.....	45
COLOR (Color Mode)	
 (Metering Mode)	
WB (White Bal)	
ISO	
 (P.Quality)	
BRK (Bracket Step)	
 (Interval)	
 (Flash Level)	
 (Contrast)	
 (Sharpness)	
 (Setup)	

Viewing menu	49
 (Folder)	
 (Protect)	
DPOF	
 (Print)	
 (Slide)	
 (Resize)	
 (Rotate)	
 (Divide)	
 (Setup)	
Trimming	

Using the Setup screen

<i>Using Setup items</i>	56
 Camera 1	57
AF Mode	
Digital Zoom	
Function Guide	
Red Eye Reduction	
AF Illuminator	
Auto Review	
 Camera 2	60
Expanded Focus	
Flash Sync.	
STEADY SHOT	
Conversion Lens	
 Internal Memory Tool	62
Format	
 Memory Stick Tool	63
Format	
Create REC. Folder	
Change REC. Folder	
Copy	
 Setup 1	65
LCD Backlight (DSC-H5 only)	
EVF Backlight	
Beep	
 Language	
Initialize	
 Setup 2	67
File Number	
USB Connect	
Video Out	
Clock Set	

Using your computer

Enjoying your Windows computer	69
Installing the software (supplied)	71
Copying images to your computer	72
Viewing image files stored on a computer with your camera (using a “Memory Stick Duo”)	78
Using the “Cyber-shot Viewer” (supplied)	79
Using your Macintosh computer	83

Printing still images

How to print still images	85
Printing images directly using a PictBridge compliant printer	86
Printing at a shop	89

Connecting your camera to your TV

Viewing images on a TV screen	91
-------------------------------------	----

Troubleshooting


Troubleshooting	93
Warning indicators and messages	105

Others

On the “Memory Stick”	108
On the battery charger and the batteries	110
Precautions	112
Specifications	114



Index	116
--------------------	-----


**Focus****Exposure****Color****Quality**

This section describes the basics so you can enjoy your camera. It tells you how to use various camera functions such as the mode dial (page 33), jog dial (page 32), the menus (page 43), and so on.


Focus***Focusing on a subject successfully***

When you press the shutter button halfway down, the camera adjusts the focus automatically (Auto Focus). Remember to press the shutter button only halfway down.

Press the shutter button fully down straight away.




Press the shutter button halfway down.



AE/AF lock indicator
Flashing → lit/beeps



Then press the shutter button fully down.



To shoot a still image difficult to focus on → “Choosing a focus method” (page 38)
If the image looks blurred even after focusing, it may be because of camera shake. → See “Hints for preventing blur” (as follows).


Hints for preventing blur

Hold the camera steadily, keeping your arms at your side. Also, you can stabilize the camera by leaning against a tree or a building beside you. Using the 2-second delay self-timer or a tripod, or turning on the anti-blur function may be effective. Also, using the flash in dark places is also recommended.



Exposure Adjusting the light intensity

You can create various images by adjusting the exposure and the ISO sensitivity. Exposure is the amount of light that the camera will receive when you release the shutter.



Overexposure

= too much light
Whitish image



Correct exposure



Underexposure

= too little light
Darker image

The exposure is automatically set to the proper value in the auto adjustment mode. However, you can adjust it manually using the functions below.

Manual exposure:

Allows you to adjust the shutter speed and aperture value manually. → page 37

Image Brightness (EV):

Allows you to adjust the exposure that has been determined by the camera.

→ step 5 in “Read This First”, page 37

Metering Mode:

Allows you to change the part of the subject to be measured to determine the exposure. → page 45

Hints for adjusting the exposure (EV)

When shooting a whitish overall image such as a backlit subject or a snowy scene



The camera judges that the subject is bright so that the exposure is darker.

Adjust in the + direction

When shooting a darker overall image



The camera judges that the subject is dark so that the exposure is brighter.

Adjust in the - direction

You can check the exposure referring to the histogram chart. Be careful not to overexpose or underexpose your subject (giving a whitish or darkish image). → *step 5 in "Read This First"*, page 38

Adjusting the ISO sensitivity

ISO is unit of measurement (sensitivity), estimating how much light an image pickup device (equivalent to photo films) receives. Even when the exposure is the same, images differ depending on the ISO sensitivity.

To adjust the ISO sensitivity → page 47



High ISO sensitivity

Records a bright image even when shooting in a dark location. However, the image tends to become noisy.



Low ISO sensitivity

Records a smoother image. However, when the exposure is insufficient, the image may become darker.

Color

On the effects of lighting

The apparent color of the subject is affected by the lighting conditions.

Example: The color of an image affected by light sources

Weather/lighting	Daylight	Cloudy	Fluorescent	Incandescent
				
Characteristics of light	White (standard)	Bluish	Blue-tinged	Reddish

The color tones are adjusted automatically in the auto adjustment mode.
However, you can adjust color tones manually with [White Bal] (page 46).


Quality

On “image quality” and “image size”


A digital image is made up of a collection of small dots called pixels.

If it contains a large number of pixels, the picture becomes large, it takes up more memory, and the image is displayed in fine detail. “Image size” is shown by the number of pixels. Although you cannot see the differences on the screen of the camera, the fine detail and data processing time differ when the image is printed or displayed on a computer screen.

Description of the pixels and the image size



Selecting the image size for use (→ step 4 in “Read This First”)



The default settings are marked with ✓.

	Image size		Usage guidelines
✓	7M (3072×2304) (DSC-H5 only)	↑ Larger ↓ Smaller	Up to A3/11×17" print
	3:2 ¹⁾ (3072×2048) (DSC-H5 only)		Match 3:2 Aspect Ratio
✓	6M (2816×2112) (DSC-H2 only)		Up to A4/8×10" print
	3:2 ¹⁾ (2816×1872) (DSC-H2 only)		Match 3:2 Aspect Ratio
	5M (2592×1944) (DSC-H5 only)		Up to A4/8×10" print
	3M (2048×1536)		Up to 13×18cm/5×7" print
	2M (1632×1224)		Up to 10×15cm/4×6" print
	VGA (640×480)		For E-mail
	16:9 ²⁾ (1920×1080)		Display On 16:9 HDTV ³⁾

¹⁾ Images are recorded in the same 3:2 aspect ratio as photograph printing paper or postcards, etc.

²⁾ Both edges of the image may be cut off when printing (page 102).

³⁾ By using a Memory Stick slot or USB connection, you can enjoy higher quality images.

	Movie image size	Frame/Second	Usage guidelines
	640(Fine) (640×480)	Approx. 30	Display on TV (high quality)
✓	640(Standard) (640×480)	Approx. 17	Display on TV (standard)
	160 (160×112)	Approx. 8	For E-mail


- The larger the image size, the higher the quality is.
- The more frames per second you played back, the smoother playback can be.

Selecting the image quality (compression ratio) in combination (page 47)


You can select the compression ratio when digital images are saved. When you select a high compression ratio, the image lacks the fineness of detail, but has a smaller file size.

Identifying parts

See the pages in parentheses for details of operation.



- 1** POWER lamp (→ step 2 in “Read This First”)
- 2** Mode dial (33)
- 3** [Play]/BRK button (41)
- 4** Shutter button (→ step 5 in “Read This First”)
- 5** Jog dial (32)
- 6** FOCUS button (38)
- 7** Microphone
- 8** Self-timer lamp (→ step 5 in “Read This First”)/AF illuminator (59)
- 9** Lens
- 10** Flash (→ step 5 in “Read This First”)
- 11** Hook for shoulder strap (20)
- 12** A/V OUT jack (91)
- 13** [USB] (USB) jack (73)
- 14** Jack cover



- 1** [Play] (Playback) button (→ step 6 in “Read This First”)
- 2** FINDER/LCD button (→ step 5 in “Read This First”)
- 3** Finder (→ step 5 in “Read This First”)
- 4** Finder adjustment dial (→ step 5 in “Read This First”)
- 5** LCD screen (27)
- 6** Control button
Menu on: [Up]/[Down]/[Left]/[Right]/[Enter] (→ step 2 in “Read This First”)
Menu off: [Battery]/[LCD]/[Image Size]/[Delete] (→ step 5 in “Read This First”)
- 7** [Image Size/Delete] button (→ step 4 and 6 in “Read This First”)
- 8** Access lamp (→ step 4 in “Read This First”)
- 9** [Steady Shot] (STEADY SHOT) button (→ step 5 in “Read This First”)
- 10** POWER button (→ step 2 in “Read This First”)

- 11** For shooting: Zoom (W/T) button
(→ step 5 in “Read This First”)



For viewing: / (Playback zoom) button/ (Index) button (→ step 6 in “Read This First”)

- 12**  (Screen display switch) button (27)

- 13** MENU button (43)

- 14** Hook for shoulder strap (20)

- 15** AC Adaptor cord cover
When using an AC-LS5K AC Adaptor
(not supplied)
For details, refer to the operation
manual supplied with the AC adaptor.



- Do not pinch the cord when you close the cover.

- 16** Speaker (bottom)

- 17** “Memory Stick Duo” cover (bottom)
(→ step 3 in “Read This First”)


- 18** OPEN button (bottom) (→ step 1 in
“Read This First”)

- 19** Battery cover (bottom) (→ step 1 in
“Read This First”)

- 20** Tripod receptacle (bottom)

- Use a tripod with a screw length of less than 5.5 mm (7/32 inch). You will be unable to firmly secure the camera to tripods having screws longer than 5.5 mm (7/32 inch), and may damage the camera.


Attaching the shoulder strap and the lens cap




Attaching the lens hood

When you shoot in bright lighting conditions, such as outdoors, we recommend that you use the lens hood to reduce the image quality deterioration caused by unnecessary light.

- ① Attach the adaptor ring.



- ② Position the lens hood as shown below and turn the lens hood clockwise until it clicks.




- You can attach the lens cap with the lens hood attached.
- When using the lens hood, be careful that the following:
 - The AF illuminator light may be blocked.
 - The flash light may be blocked, causing the shadow to appear when using the built-in flash.

Storing the lens hood

The lens hood can be attached in the reverse direction to store it with the camera when it is not in use.

Position the lens hood as shown below and turn the lens hood clockwise until it clicks.



Attaching a conversion lens (not supplied)


When you want to do enhanced wide-angle shots or zoom-in shots on distant objects, attach a conversion lens.

- ① Attach the adaptor ring.
 - ② Attach a conversion lens.
- For details, see the operating instructions supplied with your conversion lens.


Indicators on the screen

See the pages in parentheses for details of operation.

When shooting still images



When shooting movies



Display	Indication
P S A M	Mode dial (33)
	Camera mode (→ step 5 in "Read This First")
	Flash mode (→ step 5 in "Read This First")
	Flash charging The LCD screen gets dim while charging. (DSC-H5 only)
	Zoom scaling (57, → step 5 in "Read This First")
	Red-eye reduction (58)
REAR	Flash synchro (60)
	Sharpness (48)
	Contrast (48)
	Conversion lens (61)
	AF illuminator (59)
	Metering mode (45)
VIVID NATURAL SEPIA B&W	Color mode (45)

1

Display	Indication
	Battery remaining (→ step 1 in "Read This First")
	AE/AF lock (→ step 5 in "Read This First")
	Recording mode (33, 41)
	White balance (46)
STBY REC	Standby/Recording a movie (→ step 5 in "Read This First")
	Mode dial (Scene Selection) (→ step 5 in "Read This First")

2

Display	Indication
Peaking High Peaking Low Peaking Off	Peaking (40)
	Manual focus bar (40)
Set	Flexible spot AF (39) Manual focus (40)
	Macro (→ step 5 in “Read This First”)
	Manual focus (40)
	AF mode (57)
	AF range finder frame indicator (38)
	STEADY SHOT OFF (→ step 5 in “Read This First”)

3

Display	Indication
 	Image size (→ step 4 in “Read This First”) • and are displayed only for the DSC-H5. • is displayed only for the DSC-H2. • is displayed only when the Multi Burst is activated.
	Image quality (47)
	Recording folder (63) • This does not appear when using internal memory.
	Remaining internal memory capacity (29)
	Remaining “Memory Stick” capacity (28)
00:00:00 [00:28:05]	Recording time [maximum recordable time] (28, 29)
1/30"	Multi Burst interval (48)
400	Remaining number of recordable images (28, 29)
	Self-timer (→ step 5 in “Read This First”)
C:32:00	Self-diagnosis display (105)
ISO400	ISO number (47)


4

Display	Indication
	Vibration warning (13) Indicates vibration may prevent you from shooting clear images due to insufficient lighting. Even if the vibration warning appears, you can still shoot images. However, we recommend that you turn on the anti-blur function, you use the flash for better lighting or using a tripod or other means to stabilize the camera.
	Low battery warning (31, 105)
+	Spot metering cross hair (45)
	AF range finder frame (38)


5

Display	Indication
	Histogram (27, 38)
NR	NR slow shutter (36) - When using certain shutter speeds*, the NR slow shutter function activates automatically to reduce the picture noise. * When [ISO] is [Auto], [80] to [200]: 1/6 second or slower When [ISO] is [400] to [1000], or the mode dial is set to  (High Sensitivity): 1/25 second or slower
125	Shutter speed (36)
F3.5	Aperture value (36)
+2.0EV	Exposure Value (37, → <i>step5</i> in “ <i>Read This First</i> ”)
 MOVE  MOVE  OK	Flexible spot AF (39) Manual focus (40)
 (not displayed on the screen on the previous page)	Menu (43)

When playing back still images



When playing back movies



1

Display	Indication
	Battery remaining (→ step 1 in “Read This First”)
	Recording mode (33, 41)
	Image size (→ step 4 in “Read This First”)
	Playback mode (→ step 6 in “Read This First”)
	Protect (50)
	Print order (DPOF) mark (89)
	Change folder (49) • This does not appear when using internal memory.
Qx1.3	Zoom scaling (→ step 6 in “Read This First”)
Step 12/16	Frame by frame playback (42)
	Playback (→ step 6 in “Read This First”)
VOL. ■■■■■	Volume (→ step 6 in “Read This First”)

2

Display	Indication
101-0012	Folder-file number (49)
	Playback bar (→ step 6 in “Read This First”)

3

Display	Indication
	PictBridge connecting (87)
	Recording folder (63) This does not appear when using internal memory.
	Playback folder (49) This does not appear when using internal memory.
	Remaining internal memory capacity (29)
	Remaining "Memory Stick" capacity (28)
8/8 12/12	Image number/Number of images recorded in selected folder
C:32:00	Self-diagnosis display (105)
00:00:12	Counter (→ <i>step 6</i> in "Read This First")

4



Display	Indication
	PictBridge connecting (88) Do not disconnect the USB cable, while the icon is displayed.
+2.0EV	Exposure Value (37, → <i>step 5</i> in "Read This First")
ISO400	ISO number (47)
	Metering mode (45)
	Flash
	White balance (46)
	
500	Shutter speed (36)
F3.5	Aperture value (36)
	Playback image (→ <i>step 6</i> in "Read This First")

5

Display	Indication
	Histogram (27, 38)  appears when histogram display is disabled.
2006 1 1 9:30 AM	Recorded date/time of the playback image
	Menu (43)
● PAUSE ● PLAY	Playing back Multi Burst images in series (41)
◀▶ BACK/ NEXT	Select images
◆ VOLUME	Adjust volume

Changing the screen display

Each time you press the  (Screen display switch) button, the display changes as follows.



- By pressing the  (Screen display switch) button longer, you can brighten the LCD backlight (DSC-H5 only)/finder backlight (page 65, → *step 5 in "Read This First"*).
- When you set the histogram display to on, image information is displayed during playback.
- The histogram does not appear in the following situations:
 - While shooting
 - When the menu is displayed.
 - During playback
 - When the menu is displayed.
 - In index mode
 - When you are using playback zoom.
 - When you are rotating still images.
 - During playback of movies
- A large difference in the histogram displayed when shooting and during playback may occur when:
 - The flash strobes.
 - The shutter speed is slow or high.
- The histogram may not appear for images recorded using other cameras.

Number of still images and recording time of movies

The tables show the approximate number of still images and the length of time for movies that can be recorded on a "Memory Stick Duo" formatted with this camera. The values may vary depending on the shooting conditions. For image size and image quality, → *step 4 in "Read This First"*, see page 16.

The number of still images (The image quality is [Fine] on the upper line and [Standard] on the lower line.) (Units: Images)

Capacity Size	32MB	64MB	128MB	256MB	512MB	1GB	2GB
7M (DSC-H5 only)	9	18	37	67	137	279	573
	18	36	73	132	268	548	1125
3:2 (DSC-H5 only)	9	18	37	67	137	279	573
	18	36	73	132	268	548	1125
6M (DSC-H2 only)	10	21	42	77	157	322	660
	19	39	79	142	290	592	1215
3:2 (DSC-H2 only)	10	21	42	77	157	322	660
	19	39	79	142	290	592	1215
5M (DSC-H5 only)	12	25	51	92	188	384	789
	23	48	96	174	354	723	1482
3M	20	41	82	148	302	617	1266
	37	74	149	264	537	1097	2250
2M	33	66	133	238	484	988	2025
	61	123	246	446	907	1852	3798
VGA	196	394	790	1428	2904	5928	12154
	491	985	1975	3571	7261	14821	30385
16:9	33	66	133	238	484	988	2025
	61	123	246	446	907	1852	3798

- The number of images listed is for when the normal mode is selected.
- When the number of remaining shootable images is greater than 9,999, the ">9999" indicator appears.
- You can resize the images later ([Resize], page 52).

The recording time of movies (Units: hour : minute : second)


Capacity Size	32MB	64MB	128MB	256MB	512MB	1GB	2GB
640(Fine)	—	—	—	0:02:50	0:06:00	0:12:20	0:25:10
640(Standard)	0:01:20	0:02:50	0:05:50	0:10:40	0:21:40	0:44:20	1:31:00
160	0:22:40	0:45:30	1:31:30	2:51:20	5:47:00	11:44:20	24:18:20

- Movies with the size set to [640(Fine)] can only be recorded on a "Memory Stick PRO Duo".
- When images recorded using earlier Sony models are played back on this camera, the display may differ from the actual image size.

When you do not have a “Memory Stick Duo” (Recording with the internal memory)

The camera has 30 MB of internal memory. This memory is not removable. Even when there is no “Memory Stick Duo” inserted in the camera, you can record images using this internal memory.

- Movies with the image size set to [640(Fine)] cannot be recorded using the internal memory.



When a “Memory Stick Duo” is inserted

[Recording]: Images are recorded on the “Memory Stick Duo”.

[Playback]: Images on the “Memory Stick Duo” are played back.

[Menu, Setup, etc.]: Various functions can be performed on images on the “Memory Stick Duo”.

When there is no “Memory Stick Duo” inserted

[Recording]: Images are recorded using the internal memory.

[Playback]: Images stored in the internal memory are played back.

[Menu, Setup, etc.]: Various functions can be performed on images in the internal memory.

Recordable number of still images and time of movies in the internal memory are as follows.

The number of still images (The image quality is [Fine] on the upper line and [Standard] on the lower line.)

(Units: Images)

Capacity \ Size	7M ¹⁾	3:2 ¹⁾	6M ²⁾	3:2 ²⁾	5M ¹⁾	3M	2M	VGA	16:9
30MB	8	8	9	9	12	19	31	183	31
	17	17	18	18	22	34	57	459	57

¹⁾ DSC-H5 only

²⁾ DSC-H2 only

The recording time of movies

(Units: hour : minute : second)

Capacity \ Size	640(Standard)	160
30MB	0:01:20	0:21:50

- When measuring media capacity, 1MB equals 1 million bytes, a portion of which is used for data management.

On image data stored in the internal memory

We recommend that you copy (back up) data without fail using one of the following methods.

To copy (back up) data on a “Memory Stick Duo”

Prepare a “Memory Stick Duo” with a capacity of 32 MB or more, then perform the procedure explained in [Copy] (page 64).

To copy (back up) data on a hard disk of your computer

Perform the procedure on pages 72 to 74 without a “Memory Stick Duo” inserted in the camera.

- You cannot move image data on a “Memory Stick Duo” to the internal memory.
- You can copy data stored in the internal memory to a computer via a USB connection between a computer and your camera, but you cannot copy data on a computer to the internal memory.

Battery life and number of images that can be recorded/viewed

The tables show the approximate number of images that can be recorded/viewed and the battery life when you shoot images in [Normal] mode with the batteries (supplied) at full capacity and at an ambient temperature of 25°C (77°F). The numbers of images that can be recorded or viewed take into account changing the “Memory Stick Duo” as necessary. Note that the actual numbers may be less than those indicated depending on the conditions of use.

- The battery capacity decreases as the number of uses increases and also over time (page 110).
- The number of images that can be recorded/viewed and the battery life are decreased under the following conditions:
 - The surrounding temperature is low.
 - The flash is used frequently.
 - The camera has been turned on and off many times.
 - The zoom is used frequently.
 - The brightness of LCD backlight (DSC-H5 only) or EVF backlight is set to up.
 - [AF Mode] is set to [Monitor] or [Continuous].
 - [STEADY SHOT] is set to [Continuous].
 - The battery power is low.

When shooting still images

Battery	LCD/ Finder	No. of images	Battery life (min.)
DSC-H5			
NH-AA-DB (Ni-MH) (supplied)	LCD	Approx. 340	Approx. 170
	Finder	Approx. 370	Approx. 185
Alkaline	LCD	Approx. 50	Approx. 25
	Finder	Approx. 60	Approx. 30
DSC-H2			
NH-AA-DB (Ni-MH) (supplied)	LCD	Approx. 400	Approx. 200
	Finder	Approx. 400	Approx. 200
Alkaline	LCD	Approx. 60	Approx. 30
	Finder	Approx. 60	Approx. 30

- Shooting in the following situations:
 - (P.Quality) is set to [Fine].
 - [AF Mode] is set to [Single].
 - [STEADY SHOT] is set to [Shooting].
 - Shooting once every 30 seconds.
 - The zoom is switched alternately between the W and T ends.
 - The flash strobes once every two times.
 - The power turns on and off once every ten times.
- The measurement method is based on the CIPA standard.
(CIPA: Camera & Imaging Products Association)
- The number of shooting images/battery life does not change, regardless of image size.

When viewing still images

Batteries	No. of images	Battery life (min.)
DSC-H5		
NH-AA-DB (Ni-MH) (supplied)	Approx. 8600	Approx. 430
DSC-H2		
NH-AA-DB (Ni-MH) (supplied)	Approx. 9800	Approx. 490

- Viewing single images in order at about three second intervals

When shooting movies


NH-AA-DB (Ni-MH) (supplied) (min.)	
LCD	Finder
DSC-H5	
Approx. 190	Approx. 230
DSC-H2	
Approx. 250	Approx. 250

- Shooting movies continuously with an image size of [160]

Using the jog dial

The jog dial is used to change the setting values when shooting with the manual adjustment modes (shutter speed priority mode, aperture priority mode, manual exposure mode) or the EV adjustment.

By turning the jog dial, you can also easily view the next/previous image.




To select the value

Turn the jog dial to change the values you want to set.


To select the item

Turn the jog dial to select the item you want to set the value.

When adjusting the value




When selecting the item



- You cannot set items that are not available to select.

Using the mode dial

Set the mode dial to the desired function.



Still image shooting modes

Auto Adjustment

Allows easy shooting with the settings adjusted automatically. → step 5 in “Read This First”

P: Program Auto

Allows you to shoot with the exposure adjusted automatically (both the shutter speed and the aperture value). Also you can select various settings using the menu.

(For details on the functions available → page 44)

S: Shutter Speed Priority Shooting

Allows you to shoot after adjusting the shutter speed manually (page 36).

Also, you can select the various settings using the menu.

(For details on the functions available → page 44)

A: Aperture Priority Shooting

Allows you to shoot after adjusting the aperture value manually (page 36).

Also, you can select the various settings using the menu.

(For details on the functions available → page 44)

M: Manual Exposure Shooting

Allows you to shoot after adjusting the exposure manually (both the shutter speed and the aperture value) (page 37).

Also, you can select the various settings using the menu.

(For details on the functions available → page 44)

: **Scene Selection mode**

Allows you to shoot with preset settings according to the scene. → step 5 in “Read This First”

In this Operating Instructions, the available mode dial setting is shown as follows.



Scene Selection

For details → *step 5 in “Read This First”*


For shooting an image appropriately according to the scene condition, a combination of functions is determined by the camera.

(✓: you can select the desired setting)

	Macro	Flash	White Balance	Flash level	Burst/Multi Burst/ Exposure Bracket
ISO	✓	⊗	✓	—	✓
☾	—	⊗	✓	—	—
☾	✓	⚡SL	Auto/⚡WB/📷	✓	—
🌴	✓	⚡ / ⊗	✓	✓	✓
🚶	✓	⚡ / ⊗	✓	✓	✓
🏞️	—	⚡ / ⊗	✓	✓	✓
👤	✓	✓	✓	✓	✓

Shooting with manual adjustment

The camera automatically adjusts the focus and the exposure, however, you can manually adjust these settings.



Characteristics of “shutter speed”



Faster
Moving objects
appear stopped.



Slower
Moving objects
appear to flow.

Characteristics of “aperture” (F value)



Open
In-focus range
narrows, both
backward and
forward.




Close
In-focus range
widens, both
backward and
forward.

Shooting with Program Shift



You can change the aperture value and shutter speed combination while keeping the brightness fixed.

- 1 Select the aperture value and shutter speed combination using the jog dial (page 32).
P* is indicated while the aperture value and shutter speed combination is shifted.




- 2 Shoot the image.

To cancel Program Shift, turn the jog dial to return the indication from P* to P.

- You cannot shift the aperture value and shutter speed combination when the shutter button is pressed halfway down.
- When the brightness changes, the aperture value and shutter speed also change while maintaining the shift amount.

- You may not be able to change the aperture value and shutter speed combination depending on your shooting situations.
- When the flash mode setting is changed, Program Shift is canceled.
- Setting the mode dial to other than P or turning off the power cancels Program Shift.

Shooting with shutter speed priority mode



You can adjust the shutter speed manually.

- ① Select a shutter speed using the jog dial (page 32).

You can select a shutter speed from 1/1000 to 30 seconds.

- ② Shoot the image.


- Shutter speeds of one second or longer are indicated by ["], for example, 1".
- When you set the shutter speed slower, using a tripod is recommended to prevent the effects of vibration.
- If you select slow shutter speeds, it takes time to process the data.
- If you select certain shutter speeds*, the NR slow shutter function activates automatically to reduce the picture noise and "NR" appears.

* When [ISO] is [Auto], [80] to [200]: 1/6 second or slower

When [ISO] is [400] to [1000]: 1/25 second or slower

- If the proper exposure is not obtained after making the settings, the setting value indicators on the screen flash when the shutter button is pressed halfway down. You can shoot in this condition, but we recommend that you adjust the flashing values again.
- The flash is set to  (Flash forced on) or  (Flash forced off).
- When the shutter speed is high, the amount of flash light may be insufficient even if you fire the flash.

Shooting with aperture priority mode



You can manually adjust the amount of light that passes through the lens.

- ① Select an aperture value using the jog dial (page 32).

– When the zoom is set fully to the W side, you can select an aperture from F2.8 to F8.0.

– When the zoom is set fully to the T side, you can select an aperture from F3.7 to F8.0.

- ② Shoot the image.

- The shutter speed is automatically adjusted from 1/1000 to 8 seconds. When you set an aperture value of F5.6 or more, the values start from 1/2000 second.
- If the proper exposure is not obtained after making the settings, the setting value indicators on the screen flash when the shutter button is pressed halfway down. You can shoot in this condition, but we recommend that you adjust the flashing values again.
- The flash is set to  (Flash forced on),  (Slow synchro) or  (Flash forced off).

Shooting with manual exposure mode



You can manually adjust the shutter speed and the aperture values.

① Select a shutter speed using the jog dial (page 32).

② Select an aperture value using the jog dial (page 32).

The difference between the settings and proper exposure judged by the camera appears as an EV value (below) on the screen. 0EV indicates the value judged as the most suitable by the camera.

③ Shoot the image.

- The camera maintains the setting even when the power is turned off. Once you set a value you like, you can reproduce the same exposure by simply setting the mode dial to M.
- If the proper exposure is not obtained after making the settings, the setting value indicators on the screen flash when the shutter button is pressed halfway down. You can shoot in this condition, but we recommend that you adjust the flashing values again.
- The flash is set to (Flash forced on) or (Flash forced off).


Adjusting the exposure manually — Image Brightness (EV)



Toward –

Toward +

- ① Press on the control button.
The exposure value turns yellow.



- ② Select an exposure value using the jog dial (page 32).


Toward +: Brightens an image.

0EV: The exposure is determined automatically by the camera.

Toward -: Darkens an image.

- For details on the exposure → page 14
- The compensation value can be set in 1/3EV increments (+2.0EV to -2.0EV).
- If a subject is being shot in extremely bright or dark conditions, or the flash is used, the exposure adjustment may not be effective.

Using a histogram



A histogram is a graph showing the brightness of an image. Set the mode dial to , P, S, A or Scene Selection, then press (Screen display switch) repeatedly to display the histogram inside the screen. The graph display indicates a bright image when skewed to the right side, and a dark image when skewed to the left side. Adjust the exposure while checking it with the histogram.

A Number of pixels

B Brightness

- The histogram also appears when the mode dial is set to M, or playing back a single image, but you cannot adjust the exposure.

Choosing a focus method



You can change the focus method. Press the FOCUS button repeatedly when it is difficult to get the proper focus in auto focus mode.

(: The default setting)


✓	Multipoint AF ()	Focuses automatically on a subject in all ranges of the finder frame. When the mode dial is set to , only Multipoint AF is available. This mode is useful when the subject is not in the center of the frame.  AF range finder frame AF range finder frame indicator
	Center AF ()	Focuses automatically on a subject near the center of the frame. Using this with the AF lock function lets you shoot in the desired image composition.  AF range finder frame AF range finder frame indicator

	Flexible Spot AF 	Focuses on an extremely small subject or a narrow area. Flexible Spot AF lets you shoot in the desired image composition. • To set the Flexible Spot AF, see the following procedure. • This is useful when you shoot using a tripod and the subject is out of the center area. • When shooting a moving subject, take care that the subject does not deviate from the range finder frame.
	Manual Focus	Focuses on the subject using a previously set distance to the subject. • To set distance, see page 40. • When shooting a subject through a net or through window glass, it is difficult to get the proper focus in auto focus mode. In these cases, the manual focus mode is convenient.

- AF stands for Auto Focus.
- When you are shooting movies, Multi point AF is recommended as the AF works even with a certain amount of vibration.
- When you use Digital Zoom or AF Illuminator, priority AF movement is given to subjects in or near the center of the frame. In this case the ,  or  indicator flashes and the AF range finder frame is not displayed.

To set the Flexible Spot AF

- ① Press the FOCUS button repeatedly to select  (Flexible Spot AF).
The color of the AF range finder frame changes from white to yellow.




AF range finder frame
(yellow: adjustable/white: fixed)

AF range finder frame indicator

- ② Move the AF range finder frame to the point you want to focus on with , ,  or  on the control button, then press .
The AF range finder frame turns white from yellow.
To move the AF range finder frame again, press  again.
- When the AF range finder frame is being moved, AF mode is set to [Monitor] and pressing  turns to the mode set on the Setup screen.
 - Once you change a focus method, the position of the AF range finder frame you set up is cleared.

To set the manual focus

- Press the FOCUS button repeatedly to select . The manual focus bar appears.



- Set the bar to the desired distance with / on the control button.
 - If flashes, it indicates the limitation of focus adjustment.
 - Using the Expanded focus function (page 60), the image on the screen is expanded double to focus on easily (The default setting).
- Press . changes from yellow to white. To set again, press again.
 - Distance setting information in manual focus is approximate. If you point the lens up or down, the error increases.
 - The distance selection is limited according to the zoom scaling or the setting of the [Conversion Lens].
 - Once you change a focus method, the distance of the manual focus you set up is cleared.

Enhancing the outline of the subject that is visually in focus (Peaking)

The outline of the subject on the screen is enhanced using blue for easier focusing.

Set the peaking level with / on the control button while setting the manual focus.

(: The default setting)


	Peaking High	Sets the peaking level high.
	Peaking Low	Sets the peaking level low.
	Peaking Off	Does not use the peaking function.

Continuous shooting

Shooting continuously



Select a continuous shooting mode by pressing the /BRK button repeatedly.



(✓: The default setting)

	Burst ()	Records the maximum number of images in succession (refer to the following table) when you press and hold down the shutter button. • When “Recording” disappears, you can shoot the next image.
	Exposure Bracket (BRK)	Records a series of three images with the exposure values automatically shifted. + direction Correct – direction • When the mode dial is set to , Exposure Bracket cannot be selected. • You can select the image with the appropriate exposure after recording when you are unable to shoot good pictures depending on the brightness of the subject. • You can select the bracket step value in [Bracket Step] mode (page 47).
	Multi Burst ()	Records 16 frames in succession as a still image file when you press the shutter button. • This is convenient for checking your form in sports, for example. • You can select the Multi Burst shutter interval in [Interval] mode (page 48).
✓	Normal	Does not shoot continuously.

On the Burst

- The flash is set to (Flash forced off).
- When recording with the self timer, a series of a maximum of five images is recorded.
- You cannot select the following shutter speeds.
When [ISO] is [Auto], [80] to [200]: 1/6 second or slower
When [ISO] is [400] to [1000]: 1/25 second or slower
- When the battery level is low, or when the internal memory or “Memory Stick Duo” is full, the Burst stops.
- The recording interval is approximately 0.9 second (DSC-H5) or 0.8 second (DSC-H2).

The maximum number of continuous shots

(Units: images)

Size \ Quality	DSC-H2		DSC-H5	
	Fine	Standard	Fine	Standard
7M	—	—	5	8
6M	7	12	—	—
3:2	7	12	5	8
5M	—	—	6	11
3M	12	21	9	17
2M	19	35	15	27
VGA	100	100	85	100
16:9	19	35	15	27

On the Exposure Bracket




- The flash is set to  (Flash forced off).
- The focus and white balance are adjusted for the first image, and these settings are also used for the other images.
- When the exposure is manually adjusted (page 37) the exposure is shifted based on the adjusted brightness.
- The recording interval is approximately 0.9 second (DSC-H5) or 0.8 second (DSC-H2).
- If the subject is too bright or too dark, you may be unable to shoot properly with the selected bracket step value.
- You cannot select the following shutter speeds.
When [ISO] is [Auto], [80] to [200]: 1/6 second or slower
When [ISO] is [400] to [1000]: 1/25 second or slower
- You may not be able to shoot images in the Exposure Bracket mode depending on the Scene mode (page 34).

On the Multi Burst

- You can play back images shot with Multi Burst using the following procedure.
 - To pause/resume: Press  on the control button.
 - To play back frame-by-frame: Press  in pause mode. Press  to resume playback in series.
- You cannot use the following functions in the Multi Burst mode:
 - Smart zoom
 - Flash
 - Dividing a series of images shot with Multi Burst
 - Deleting or extracting a frame in a series of images shot with Multi Burst
 - Setting the frame interval to a mode other than [1/30] when the mode dial is set to 
 - Setting the shutter speed to lower than 1/30 second
- When playing back a series of images shot with Multi Burst using a computer or a camera not equipped with the Multi Burst function, the image is displayed as a single image with 16 frames.
- The image size of images shot in the Multi Burst mode is 1M.
- You may not be able to shoot images in the Multi Burst mode depending on the Scene mode (page 34).



Using menu items




- 1 Recording: Turn on the camera, then set the mode dial.**
Playback: Press

Different items are available depending on the position of the mode dial and Recording/Playback mode.

- 2 Press MENU to display the menu.**

- 3 Select the desired menu item with** **on the control button.**

- If the desired item is invisible, keep pressing until the item appears on the screen.
- Press after selecting an item in the Playback mode.



- 4 Select the setting with** .

The setting you select is zoomed and is set.

- 5 Press MENU to turn off the menu.**

To turn to the shooting mode

Press the shutter button halfway down so that the menu disappear.

- If there is an item that is not displayed, an mark appears on the edges of the location where menu items usually appear. To display an item that is not displayed, select the mark with the control button.
- You cannot set items that are not available to select.

Menu for shooting (page 45)

The menu items available vary depending on the mode dial position. Only the available items are displayed on the screen.

(✓ : available)

Mode dial position:

	P	S	A	M	Scene	
---	---	---	---	---	-------	---

COLOR (Color Mode)	—	✓	✓	✓	✓	—	✓
 (Metering Mode)	—	✓	✓	✓	✓	✓	✓
WB (White Bal)	—	✓	✓	✓	✓	✓	✓
ISO	—	✓	✓	✓	✓	✓	—
 (P.Quality)	—	✓	✓	✓	✓	✓	—
BRK (Bracket Step)	—	✓	✓	✓	✓	✓*	—
 (Interval)	—	✓	✓	✓	✓	✓*	—
 (Flash Level)	—	✓	✓	✓	✓	✓*	—
 (Contrast)	—	✓	✓	✓	✓	—	—
 (Sharpness)	—	✓	✓	✓	✓	—	—
 (Setup)	✓	✓	✓	✓	✓	✓	✓

Menu for viewing (page 49)

 (Folder)	 (Protect)
DPOF	 (Print)
 (Slide)	 (Resize)
 (Rotate)	 (Divide)
 (Setup)	Trimming**

* The operation is limited according to the Scene mode (page 34).

**Available only during playback zoom.

The default settings are marked with .



You can change the brightness of the image, accompanied by effects.

	B&W (B & W)	Sets the image to monochromatic color
	Sepia (SEPIA)	Sets the image to sepia color
	Natural (NATURAL)	Sets the image to quiet color
	Vivid (VIVID)	Sets the image to deep and vivid color
	Normal	

- You can select only [B&W] and [Sepia] when shooting movies.
- When Multi Burst is selected, the color mode is set to [Normal].



Selects the metering mode that sets which part of the subject to measure to determine the exposure.

	Spot (Spot metering)	Measures only a part of the subject. • This function is useful when the subject is backlit or when there is strong contrast between the subject and the background.  Spot metering cross hairs Positions on the subject
	Center (Center-weighted metering)	Measures the center of the image, and determines the exposure based on the brightness of the subject there.
	Multi (Multi-pattern metering)	Divides into multiple regions and measures each region. The camera determines a well-balanced exposure.

- For details on the exposure → page 14
- When using spot metering or center-weighted metering, setting the AF range finder frame to Center AF is recommended to focus on the metering position (page 38).

WB (White Bal)

Adjusts the color tones according to the lighting condition in a situation, for example, when the colors of an image look strange.

	One Push Set ( SET)	Memorizes the basic white color which will be used in [One Push] () mode. • This is unable to be selected while charging the flash.
	One Push ()	Adjusts the white balance depending on the light source. The white color memorized in [One Push Set] ( SET) mode becomes the basic white color. Use this mode when [Auto] or other modes cannot set the color properly.
	Flash ( WB)	Adjusts for the flash conditions. • You cannot select this item when shooting movies.
	Incandescent ()	Adjusts for places where the lighting conditions change quickly such as at a party hall, or under bright lighting such as at photography studios.
	Fluorescent ()	Adjusts for fluorescent lighting.
	Cloudy ()	Adjusts for a cloudy sky.
	Daylight ()	Adjusts for outdoors, shooting night scenes, neon signs, fireworks, or sunrise, or conditions before and after sundown.
✓	Auto	Adjusts the White Balance automatically.

- For details on the white balance → page 16
- Under fluorescent lights that flicker, the white balance function may not work correctly even though you select [Fluorescent] ().
- Except in [One Push] (), [Flash] ( WB) modes, [WB] is set to [Auto] when the flash strobes.
- Some options are not available depending on the Scene mode (page 34).

To capture the basic white color in [One Push Set] (SET) mode

Memorizes the basic white color for the [One Push] () mode. After selecting  SET, do as follows.

- ① Frame a white object such as a piece of paper filling the screen under the same lighting conditions as you will shoot the subject.
 - ② Select [One Push Set] ( SET) with ▲. The screen momentarily turns black and the  SET indicator flashes quickly. When the white balance has been adjusted and stored in the memory, [One Push] () is selected again.
- If the  indicator flashes slowly, the white balance has not been set or cannot be set. Use automatic white balance.
 - Do not shake or strike the camera while the  SET indicator flashes quickly.
 - When flash mode is set to  (Flash forced on) or  SL (Slow synchro), the white balance is adjusted to the condition with the flash emitting.

ISO



Selects a luminous sensitivity with units of ISO. The larger the number, the higher the sensitivity.

☐	1000	Select a large number when shooting in dark locations or shooting a subject moving at high speed, or select a small number to obtain high image quality.
☐	800	
☐	400	
☐	200	
☐	100	
☐	80	
☒	Auto	

- For details on the ISO sensitivity → page 15
- Note that the image tends to become noisier as the ISO sensitivity number increases.
- [ISO] is set to [Auto] in the Scene mode.
- When shooting under blighter conditions, the camera automatically increases its tone reproduction and helps prevent images to become whitish (excluding when [ISO] is set to [80] or [100].) (DSC-H5 only)

(P.Quality)



Selects the still image quality.

☒	Fine (FINE)	Records with high quality (low compression).
☐	Standard (STD)	Records with standard quality (high compression).

- For details on the image quality → page 16

BRK (Bracket Step)



Selects the bracket step value when the Exposure Bracket is selected with the /BRK button (page 41).

☐	± 1.0EV	Shifts the exposure value by plus or minus 1.0EV.
☒	± 0.7EV	Shifts the exposure value by plus or minus 0.7EV.
☐	± 0.3EV	Shifts the exposure value by plus or minus 0.3EV.

- Select Exposure Bracket with the /BRK button first, set the desired setting for [Bracket Step]. When you select a function other than Exposure Bracket, this function is unavailable (page 41).



Selects the frame interval in the Multi Burst mode (page 41).

☐	1/7.5 (1/7.5")	Select Multi Burst with the /BRK button first, set the desired setting for [Interval]. When you select a function other than Multi Burst, this function is unavailable (page 41).
☐	1/15 (1/15")	
☒	1/30 (1/30")	



Adjusts the amount of flash light.

☐	↑ +2.0EV	Toward +: Makes the flash level higher.
☒	0EV	The amount of flash light that the camera adjusts automatically.
☐	↓ -2.0EV	Toward -: Makes the flash level lower.

- The flash level can be set in 1/3 EV increments.
- The value is not displayed on the screen. It is indicated as + or -.
- To change flash mode → step 5 in "Read This First"
- If the subject is too bright or dark, this adjustment may have no effect.
- When the flash mode is set to  (Flash forced off), you cannot adjust the flash level.



Adjusts the contrast of the image.

☐	+ (☉)	Toward +: Enhances the contrast.
☒	Normal	
☐	- (☉)	Toward -: Reduces the contrast.



Adjusts the sharpness of the image.

☐	+ (▣)	Toward +: Sharpens the image.
☒	Normal	
☐	- (▣)	Toward -: Softens the image.



See page 56.


The default settings are marked with ✓.

(Folder)

Selects the folder containing the image you want to play back when using the camera with “Memory Stick Duo”.

	OK	See the following procedure.
✓	Cancel	Cancels the selection.

- ① Select the desired folder with ◀/▶ on the control button.



- ② Select [OK] with ▲, then press ●.

On the folder

The camera stores images in a specified folder of a “Memory Stick Duo” (page 63). You can change the folder or create a new one.

- To create a new folder → [Create REC. Folder] (page 63)
- To change the folder for recording images → [Change REC. Folder] (page 64)
- When multiple folders are created in the “Memory Stick Duo” and the first or last image in the folder is displayed, the following indicators appear.



Moves to the previous folder.



Moves to the next folder.



Moves to either the previous and next folders.

🔒 (Protect)

Protects images against accidental erasure.

✓	Protect (🔒)	See the following procedure.
	Exit	Exits the Protection function.

To protect images in single-image mode


- ① Display the image you want to protect.
- ② Press MENU to display the menu.
- ③ Select [🔒] (Protect) with ◀/▶ on the control button, then press ●.
The image is protected and the 🔒 (protect) indicator appears on the image.



- ④ To protect other images, select the desired image with ◀/▶, then press ●.

To protect images in index mode

- ① Press  (Index) to display the index screen.
- ② Press MENU to display the menu.
- ③ Select [🔒] (Protect) with ◀/▶ on the control button, then press ●.
- ④ Select [Select] with ▲/▼, then press ●.
- ⑤ Select the image you want to protect with ▲/▼/◀/▶, then press ●.
A green 🔒 indicator appears on the selected image.



- ⑥ Repeat step ⑤ to protect other images.
 - ⑦ Press MENU.
 - ⑧ Select [OK] with ▶, then press ●.
The 🔒 indicator turns white. The selected images are protected.
- To protect all images in the folder, select [All In This Folder] in step ④, and press ●. Select [On] with ▶, then press ●.

To cancel the protection

In single-image mode

Press  in step ③ or ④ of “To protect images in single-image mode.”

In index mode

- ① Select the image for which you want to remove protection in step ⑤ of “To protect images in index mode.”
- ② Press  to turn the  indicator gray.
- ③ Repeat the operation above for all images to be unprotected.
- ④ Press MENU, select [OK] with , and then press .

To cancel protection of all images in the folder

Select [All In This Folder] in step ④ of “To protect images in index mode,” and press . Select [Off] with , then press .

- Note that formatting the internal memory or “Memory Stick Duo” erases all the data stored on the recording media, even if images are protected, and these images cannot be recovered.
- It may take some time to protect an image.

DPOF

Adds a  (Print order) mark to images you want to print (page 89).

(Print)

See page 86.

(Slide)

Plays back recorded images in order (Slide show).

Interval

	3 sec	Sets the slide show interval.
	5 sec	
	10 sec	
	30 sec	
	1 min	

Repeat

	On	Plays back images in a continuous loop.
	Off	After all the images have been played back, the slide show ends.

Image

	Folder	Plays back all images in the selected folder.
	All	Plays back all images stored on the “Memory Stick Duo”.

	Start	See the following procedure.
	Cancel	Cancels the slide show.

① Select [Interval], [Repeat] and [Image] with // on the control button.

② Select [Start] with , then press .

The slide show starts.

To end the slide show, press  to pause the slide show, select [Exit] with , then press .

- While pausing a slide show, you can display the previous/next image with .
- The interval time is just a guideline, so it may vary depending on the image size, etc.

 (Resize)

You can change the image size of a recorded image (Resize), and save it as a new file. The original image is retained even after resizing.

	7M (DSC-H5 only)	The setting size is just a guideline. → step 4 in “Read This First”
	6M (DSC-H2 only)	
	5M (DSC-H5 only)	
	3M	
	2M	
	VGA	
	Cancel	Cancels resizing.

① Display the image you want to resize.

② Press MENU to display the menu.

③ Select [] (Resize) with  on the control button, then press .

④ Select the desired size with , then press .

The resized image is recorded in the recording folder as the newest file.

- For details on [Image Size] → step 4 in “Read This First”
- You cannot change the size of movies or Multi Burst images.
- When you change from a small size to a large size, the image quality deteriorates.
- You cannot resize the image size to [3:2] or [16:9].
- When you resize a [3:2] or [16:9] image, the upper and lower black portions will be displayed on the image.

(Rotate)



Rotates a still image.

		Rotates an image. See the following procedure.
OK		Determines the rotation. See the following procedure.
	Cancel	Cancels rotation.

- ① Display the image to be rotated.
- ② Press MENU to display the menu.
- ③ Select  (Rotate) with /  on the control button, then press .
- ④ Select   with , then rotate the image with / .
- ⑤ Select [OK] with , then press .

- You cannot rotate protected images, movies, or Multi Burst images.
- You may not be able to rotate images shot with other cameras.
- When viewing images on a computer, the image rotation information may not be reflected depending on the software.

(Divide)


Cuts movies, or deletes unnecessary portions of movies. This is the recommended function to use when the internal memory or “Memory Stick Duo” capacity is insufficient, or when you attach movies to your e-mail messages.

- Note that the original movie is deleted and that number is skipped. Also note that you cannot restore files once you cut them.


OK		See the following procedure.
	Cancel	Cancels division.

Example: Cutting a movie numbered 101_0002

This section describes an example of dividing a movie numbered 101_0002 and deleting it in the following file configuration.




1 Cutting scene A.



Divide

101_0002 is divided into 101_0004 and 101_0005.


2 Cutting scene B.



Divide

101_0005 is divided into 101_0006 and 101_0007.


3 Deleting scenes A and B if they are unnecessary.



Delete

Delete

4 Only the desired scenes remain.



Procedure

- ① Display the movie to be divided.
- ② Press MENU to display the menu.
- ③ Select [] (Divide) with ◀/▶ on the control button, then press ●.
- ④ Select [OK] with ▲, then press ●.
The playback of the movie starts.

- ⑤ Press  at the desired cutting point.



- When you want to adjust the cutting point, select [/||/||] (frame rewind/forward) and adjust the cutting point using /||.
- If you want to change the cutting point, select [Cancel]. The playback of the movie starts again.

- ⑥ Select [OK] with , and press .

- ⑦ Select [OK] with , then press .
- The movie is cut.

- The cut movies are assigned new numbers, and then recorded as the newest files in the selected recording folder.
- You cannot cut the following kinds of images.
 - Still image
 - Movies not long enough to cut (shorter than about two seconds)
 - Protected movies (page 50)

(Setup)

See page 56.

Trimming

Records an enlarged image (→ step 6 in “Read This First”) as a new file.

	Trimming	See the following procedure.
	Return	Cancels trimming.



- ① Press MENU during playback zoom to display the menu.
 - ② Select [Trimming] with  on the control button, then press .
 - ③ Select the image size with , then press .
- The image is recorded, and the original image is displayed again.

- The trimmed image is recorded as the newest file in the selected recording folder, and the original image is retained.
- The quality of trimmed images may deteriorate.
- You cannot trim to an image size of [3:2] or [16:9].



Using Setup items

You can change the default settings using the Setup screen.



1 Turn on the camera.


2 Press MENU to display the menu.

3 After pressing **▶** on the control button, go to the  (Setup) setting, then press **▶** again.

4 Press **▲/▼/◀/▶** on the control button to select the item you want to set.

The frame of the selected item turns yellow.

5 Press **●** to enter the setting.



To turn off the  (Setup) screen, press MENU.

To return to the menu from the  (Setup) screen, press **◀** on the control button repeatedly.

- By pressing the shutter button halfway down, the camera turns off the  (Setup) screen and returns to the shooting mode.

When the menu is not displayed

If you press MENU longer, the  (Setup) is displayed.

To cancel the (Setup) setting

Select [Cancel] if it appears, then press **●** on the control button. If it does not appear, select the previous setting again.

- This setting is maintained even when the power is turned off.

The default settings are marked with ✓.

AF Mode

Selects the auto focus operation mode.

✓	Single (S AF)	Automatically adjusts the focus when the shutter button is pressed and held halfway down. This mode is useful for shooting stationary subjects.
	Monitor (M AF)	Automatically adjusts the focus before the shutter button is pressed and held halfway down. This mode shortens the time needed for focusing. • Battery consumption may be faster than in [Single] mode.
	Continuous (C AF)	Adjusts the focus before you press and hold the shutter button halfway down, and then continues to adjust the focus even after AF lock is completed. This mode allows shooting of moving subjects with continued focus. • Battery consumption may be faster than in any other AF mode.

On the [Continuous] (C AF)

- Focus adjustment may not be able to keep up when shooting fast moving subjects.
- The AF range finder frame is Center AF (page 38).
- The focus is not adjusted after the lock is completed in the following cases, and the “C AF” indicator flashes. The camera operates in [Monitor] mode.
 - When shooting in the dark place
 - When shooting with a slow shutter speed
- There is no lock sound when the focus is achieved.
- When you press the shutter button all the way down using the self-timer, the focus is locked.

Digital Zoom


Selects the digital zoom mode. The camera enlarges the image using optical zoom (up to 12×). When the zoom scale exceeds 12×, the camera uses either smart or precision digital zoom.

✓	Smart (Smart zoom) 	Enlarges the image digitally with almost no distortion. This is not available when the image size is set to [7M] (DSC-H5), [6M] (DSC-H2) or [3:2]. • The maximum zoom scale of Smart zoom is shown in the following table.
	Precision (Precision digital zoom) 	Enlarges all image sizes up to a maximum of 24×, but the image quality deteriorates.
	Off	Does not use the digital zoom.

Image size and maximum zoom scale using Smart zoom

	DSC-H2	DSC-H5
Size	Maximum zoom scale	Maximum zoom scale
5M	—	Approx. 14×
3M	Approx. 16×	Approx. 18×
2M	Approx. 20×	Approx. 22×
VGA	Approx. 52×	Approx. 57×
16:9	Approx. 17×	Approx. 19×

- If you press the zoom button, the zoom scale is displayed.



The W side of this line is the optical zoom area, and the T side is the digital zoom area

Zoom scaling indicator

- The maximum zoom scale of smart zoom/precision zoom includes the scale of the optical zoom.
- The AF range finder frame does not appear when using the digital zoom. The ,  or  indicator flashes, and AF operates with priority on subjects located near the center of the frame.
- When using the smart zoom, the image on the screen may look rough. However, this phenomenon has no effect on the recorded image.

Function Guide

When you operate the camera, the instructions of various functions are displayed.

	On	Displays the function guide.
	Off	Does not display the function guide.

Red Eye Reduction



Reduces the red-eye phenomenon when using the flash. Select this before shooting.

	On ()	Reduces the red-eye phenomenon. The flash pre-strobes twice or more before shooting.
	Off	Does not use Red Eye Reduction.

- Because it takes about a second until the shutter clicks, hold the camera firmly to prevent the effects of vibration. Also, do not let the subject move.
- Red-eye reduction may not produce the desired effects depending on individual differences, the distance to the subject, if the subject does not see the pre-strobe, or other conditions.

AF Illuminator

The AF illuminator supplies fill light to focus more easily on a subject in dark surroundings. The AF illuminator emits red light allowing the camera to focus easily when the shutter button is pressed halfway, until the focus is locked. The  indicator appears at this time.

	Auto	Uses the AF illuminator.
	Off	Does not use AF illuminator.

- If the AF illuminator light does not reach the subject sufficiently or the subject has no contrast, focus will not be achieved. (A distance of up to approximately 2.7 m (106 3/8 inches) (zoom: W)/2.6 m (102 3/8 inches) (zoom: T) is recommended.)
- Focus is achieved as long as the AF illuminator light reaches the subject, even if the light is slightly off the center of the subject.
- When the manual focus is selected (page 38), AF Illuminator does not function.
- The AF range finder frame does not appear. The ,  or  indicator flashes, and AF operates with priority on subjects located near the center of the frame.
- The AF illuminator does not operate when  (Twilight) or  (Landscape) is selected in the Scene mode or when [Conversion Lens] is not set to [Off].
- The AF illuminator emits very bright light. Although there are no problems with safety, do not look directly into the AF illuminator emitter at close range.

Auto Review

Displays the recorded image on the screen for approximately two seconds immediately after shooting a still image.

	On	Use the Auto Review.
	Off	Does not use Auto Review.

- If you press the shutter button halfway down during this period, the recorded image display disappears and you can immediately shoot the next image.

The default settings are marked with .

Expanded Focus

Expands the center of the screen double in manual focus mode.

	On	Expands double.
	Off	Does not expand.

Flash Sync.

Select the timing that the flash strobes.

	Front	Normally, use this setting. Since the flash strobes right after the shutter is released, this allows you to get your shot closer to the time you release the shutter. 
	Rear (REAR)	Used for a moving subject, etc. Since the flash strobes right before the shutter is closed, this allows you to reflect the trail of a light or movement afterimage on a subject. 

On the [Rear]

- When the shutter speed is too high, the [Rear] setting effect may not be available.
- When the red-eye reduction is selected, the red-eye reduction effect may not be available at slower shutter speeds.

STEADY SHOT

Selects the anti-blur mode.

✓	Shooting	Activates the anti-blur function when pressing the shutter button halfway down.
	Continuous	Always activates the anti-blur function. You can stabilize images even when zooming up a far subject. • Battery consumption is faster than in [Shooting] mode.

- When shooting movies, [Continuous] is activated even if you select [Shooting].
- You can turn off the anti-blur function using the  (STEADY SHOT) button when the mode dial is not set to . (→ step 5 in “Read This First”)
- The anti-blur function may not work properly in the following cases.
 - When camera shake is too strong
 - When the shutter speed is slow, for example, shooting night scenes

Conversion Lens

Sets for achieving appropriate focus when attaching a conversion lens (not supplied). Attach the supplied adaptor ring, then attach a conversion lens.

	Close-up ()	Attaches a close-up lens.
	Tele ()	Attaches a tele conversion lens.
	Wide ()	Attaches a wide conversion lens.
✓	Off	Does not attach a lens.

- When using the built-in flash, the flash light may be blocked, causing the shadow to appear.
- The available zoom area is limited.
- The available focusing area is limited.
- For details, see the operating instructions supplied with your conversion lens.



This item does not appear when a “Memory Stick Duo” is inserted in the camera.
The default settings are marked with ✓.

Format

Formats the internal memory.

- Note that formatting irrevocably erases all data in the internal memory, including even protected images.

	OK	See the following procedure.
✓	Cancel	Cancels the formatting.

- ① Select [OK] with ▲ on the control button, then press ●.
The message “All data in internal memory will be erased Ready?” appears.
- ② Select [OK] with ▲, then press ●.
The format is complete.

This item appears only when a “Memory Stick Duo” is inserted in the camera.
The default settings are marked with .

Format

Formats the “Memory Stick Duo”. A commercially available “Memory Stick Duo” is already formatted, and can be used immediately.

- Note that formatting irrevocably erases all data on a “Memory Stick Duo”, including even protected images.

☐	OK	See the following procedure.
☒	Cancel	Cancels the formatting.


- ① Select [OK] with  on the control button, then press .
The message “All data in Memory Stick will be erased Ready?” appears.
- ② Select [OK] with , then press .
The format is complete.

Create REC. Folder

Creates a folder in a “Memory Stick Duo” for recording images.

☐	OK	See the following procedure.
☒	Cancel	Cancels folder creation.

- ① Select [OK] with  on the control button, then press .
The folder creation screen appears.



- ② Select [OK] with , then press .
A new folder is created with a number incremented one higher than the largest number, and the folder becomes the current recording folder.


- For details on the folder, see page 49.
- When not creating a new folder, the “101MSDCF” folder is selected as the recording folder.
- You can create folders designated up to “999MSDCF”.
- Images are recorded in the newly created folder until a different folder is created or selected.
- You cannot delete a folder with the camera. To delete a folder, use your computer, etc.
- Up to 4,000 images can be stored in one folder. When the folder capacity is exceeded, a new folder is automatically created.
- For details, see “Image file storage destinations and file names” (page 77).

Change REC. Folder

Changes the folder currently used for recording images.

☐	OK	See the following procedure.
☒	Cancel	Cancels changing the recording folder.

- ① Select [OK] with  on the control button, then press .
- The folder selection screen appears.



- ② Select the desired folder with , , and [OK] with , then press .


- You cannot select the “100MSDCF” folder as a recording folder.
- You cannot move recorded images to a different folder.

Copy

Copies all images in the internal memory to a “Memory Stick Duo”.

☐	OK	See the following procedure.
☒	Cancel	Cancels the copying.

- ① Insert a “Memory Stick Duo” having 32 MB or larger capacity.
 - ② Select [OK] with  on the control button, then press .
- The message “All data in internal memory will be copied Ready?” appears.
- ③ Select [OK] with , then press .
- Copying starts.



- Use a fully charged Nickel-Metal Hydride battery or the AC Adaptor (not supplied). If you attempt to copy image files using a batteries with little remaining charge, the batteries may run out, causing copying to fail or possibly corrupting the data.
- You cannot copy individual images.
- The original images in the internal memory are retained even after copying. To delete the contents of the internal memory, remove the “Memory Stick Duo” after copying, then execute the [Format] command in  (Internal Memory Tool) (page 62).
- You cannot select a folder copied on a “Memory Stick Duo”.
- Even if you copy data, a  (Print order) mark is not copied.

The default settings are marked with ✓.

LCD Backlight (DSC-H5 only)

Selects the brightness of the LCD backlight when using the camera with batteries.

	Bright	Brightens.
✓	Normal	

- You can also change the setting with the  (Screen display switch) button pressed longer. (→ step 5 in “Read This First”)
- Selecting [Bright] uses up the battery charge faster.

EVF Backlight

Selects the brightness of the finder backlight.

	Bright	Brightens.
✓	Normal	

- You can also change the setting with the  (Screen display switch) button pressed longer. (→ step 5 in “Read This First”)
- Selecting [Bright] uses up the battery charge faster.

Beep

Selects the sound produced when you operate the camera.

	Shutter	Turns on the shutter sound when you press the shutter button.
✓	On	Turns on the beep/shutter sound when you press the control button/ press the shutter button.
	Off	Turns off the beep/shutter sound.

Language

Selects the language to be used to display the menu items, warnings, and messages.

Initialize

Initializes the setting to the default setting.

☐	OK	See the following procedure.
☒	Cancel	Cancels the resetting.

- ① Select [OK] with ▲ on the control button, then press ●.
The message “Initialize all settings Ready?” appears.
 - ② Select [OK] with ▲, then press ●.
The settings are reset to the default setting.
- Make sure that the power is not disconnected during resetting.

The default settings are marked with .

File Number

Selects the method used to assign file numbers to images.

	Series	Assigns numbers to files in sequence even if the recording folder or the “Memory Stick Duo” is changed. (When the replaced “Memory Stick Duo” contains a file with a number higher than the last assigned number, a number one higher than the largest number is assigned.)
	Reset	Starts from 0001 each time the folder is changed. (When the recording folder contains a file, a number one higher than the largest number is assigned.)

USB Connect

Selects the USB mode to be used when connecting the camera to a computer or a PictBridge compliant printer using the USB cable.

	PictBridge	Connects the camera to a PictBridge compliant printer (page 86).
	PTP	When [PTP] (Picture Transfer Protocol) is set and the camera is connected to a computer, the images in the recording folder on the camera are copied to the computer. (Compatible with Windows XP and Mac OS X.)
	Mass Storage	Establishes a Mass Storage connection between the camera and a computer or other USB device (page 73).
	Auto	The camera recognizes automatically and sets up communication with a computer or PictBridge compliant printer (pages 73 and 86). • If the camera and a PictBridge compliant printer cannot be connected when set to [Auto], change the setting to [PictBridge]. • If the camera and a computer or other USB device cannot be connected when set to [Auto], change the setting to [Mass Storage].

Video Out

Sets the video signal output according to the TV color system of the connected video equipment. Different countries and regions use different TV color systems. If you want to view images on a TV screen, check page 92 for the TV color system of the country or region where the camera is used.

NTSC	Sets the video output signal to NTSC mode (e.g., for the USA, Japan).
PAL	Sets the video output signal to PAL mode (e.g., for Europe).

Clock Set

Sets the date and time.

☐	OK	Select [OK] with ▲ on the control button, and press ●. Then, perform the procedure explained in “Set the clock” (→ <i>step 2 in “Read This First”</i>).
☒	Cancel	Cancels setting the clock.



Enjoying your Windows computer

For details on using a Macintosh computer, refer to “Using your Macintosh computer” (page 83).

This section describes the English version screen contents.



Install the software (supplied) first (page 71)



Copying images to your computer (page 72)



Viewing images on your computer

Enjoying images using the “Cyber-shot Viewer” (page 79)



- Viewing images saved on your computer
- Viewing photos organized by date
- Editing images



Printing images

Recommended computer environment

The following environment is recommended for a computer connected to the camera.

Recommended environment for copying images

OS (pre-installed): Microsoft Windows 2000 Professional, Windows Millennium Edition, Windows XP Home Edition or Windows XP Professional

- Operation is not assured in an environment based on an upgrade of the operating systems described above or in a multi-boot environment.

USB jack: Provided as standard

Recommended environment for using “Cyber-shot Viewer”

OS (pre-installed): Microsoft Windows 2000 Professional, Windows Millennium Edition, Windows XP Home Edition or Windows XP Professional

Sound card: 16-bit stereo sound card with speakers

Processor/Memory: Pentium III 500 MHz or faster, 128 MB of RAM or more (Recommended: Pentium III 800 MHz or faster and 256 MB of RAM or more)

Hard Disk: Disk space required for installation—200 MB or more

Display:

Screen resolution; 800 × 600 dots or more
Colors; High Color (16-bit color, 65,000 colors) or more

Notes on connecting your camera to a computer

- Operations are not guaranteed for all the recommended computer environments mentioned above.
- If you connect two or more USB devices to a single computer at the same time, some devices, including your camera, may not operate,

depending on the types of USB devices you are using.

- Operations are not guaranteed when using a USB hub.
- Connecting your camera using a USB interface that is compatible with Hi-Speed USB (USB 2.0 compliant) allows advanced transfer (high speed transfer) as this camera is compatible with Hi-Speed USB (USB 2.0 compliant).
- There are three modes for a USB connection when connecting a computer, [Auto] (default setting), [Mass Storage] and [PTP] modes. This section describes the [Auto] and [Mass Storage] as examples. For details on [PTP], see page 67.
- When your computer resumes from a suspend or sleep mode, communication between your camera and your computer may not recover at the same time.


Installing the software (supplied)

You can install the software (supplied) using the following procedure.

- When using Windows 2000/Mc, do not connect the camera to the computer before installation.
- In Windows 2000/XP, log on as Administrator.
- When the supplied software is installed, the USB driver is installed automatically.

1 Turn on your computer, and insert the CD-ROM (supplied) into the CD-ROM drive.

The installation menu screen appears.



- If it does not appear, double-click  (My Computer) →  (CYBERSHOTSOFT).

2 Click [Install].

The “Choose Setup Language” screen appears.

3 Select the desired language, then click [Next].

The “License Agreement” screen appears.

Read the agreement carefully. If you accept the terms of the agreement, click the radio button next to [I accept the terms of the license agreement] and then click [Next].

4 Follow the instructions on the screen to complete the installation.

When the restarting confirmation message appears, restart the computer following the instructions on the screen.

5 Remove the CD-ROM after the installation is complete.

Copying images to your computer

This section describes the process using a Windows computer as an example. You can copy images from the camera to your computer as follows.

For a computer with a “Memory Stick” slot

Remove the “Memory Stick Duo” from the camera and insert it in the Memory Stick Duo Adaptor. Insert the Memory Stick Duo Adaptor in the computer and copy the images.

If the “Memory Stick PRO Duo” is not recognized, see page 101.

For a computer without a “Memory Stick” slot

Follow Stages 1 through 4 on pages 72 to 76 to copy images.


- When using Windows 2000/Me, install the supplied software before proceeding. With Windows XP, the installation is unnecessary.
- The screen displays shown in this section are the examples for copying images from “Memory Stick Duo”.

Stage 1: Preparing the camera and the computer

1 Insert a “Memory Stick Duo” with recorded images into the camera.


- When copying images in the internal memory, this step is unnecessary.

2 Insert the sufficiently charged Nickel-Metal Hydride batteries in the camera, or connect the camera to a wall outlet (wall socket) with the AC Adaptor (not supplied).




- When you copy images to your computer using batteries, copying may fail or image data may become corrupted if the batteries shut down too soon.

3 Press to turn on the camera and the computer.




Stage 2: Connecting the camera and your computer



- With Windows XP, the AutoPlay wizard appears on the desktop.

“USB Mode Mass Storage” appears on the screen of the camera.



When a USB connection is established for the first time, your computer automatically runs a program to recognize the camera. Wait for a while.

- * During communication, the access indicators turn red. Do not operate the computer until the indicators turn white.
- If “USB Mode Mass Storage” does not appear, set [USB Connect] to [Mass Storage] (page 67).


Stage 3-A: Copying images to a computer

XP

- For Windows 2000/Me, follow the procedure explained in “Stage 3-B: Copying images to a Computer” on page 74.
- For Windows XP, when the wizard screen does not appear automatically, follow the procedure explained in “Stage 3-B: Copying images to a Computer” on page 74.

This section describes an example of copying images to a “My Documents” folder.

- 1 After making a USB connection in Stage 2, click [Copy pictures to a folder on my computer using Microsoft Scanner and Camera Wizard] → [OK] as the wizard screen appears automatically on the desktop.



The “Scanner and Camera Wizard” screen appears.

- 2 Click [Next].

The images saved on the “Memory Stick Duo” of the camera appear.

- If no “Memory Stick Duo” is inserted, images in the internal memory appear.

- 3** Click the check box of unwanted images to remove the checkmark so they are not copied, then click [Next].



The “Picture Name and Destination” screen appears.

- 4** Select a name and destination for the images, then click [Next].




Image copying starts. When the copying is completed, the “Other Options” screen appears.

- This section describes an example of copying images to the “My Documents” folder.

- 5** Click the radio button next to [Nothing. I'm finished working with these pictures] to select it, then click [Next].



The “Completing the Scanner and Camera Wizard” screen appears.

- 6** Click [Finish].

The wizard screen closes.

- To continue copying other images, disconnect the USB cable (page 76). Then follow the procedure explained in “Stage 2: Connecting the camera and your computer” on page 73.


Stage 3-B: Copying images to a Computer

2000 Me

- For Windows XP, follow the procedure explained in “Stage 3-A: Copying images to a computer” on page 73.


This section describes an example of copying images to the “My Documents” folder.

1 Double-click [My Computer] → [Removable Disk] → [DCIM].



- If the “Removable Disk” icon is not displayed, see page 99.

2 Double-click the folder where the image files you want to copy are stored. Then, right-click an image file to display the menu and click [Copy].



- On the storage destination of the image files, see page 77.

3 Double-click the [My Documents] folder. Then, right-click on the “My Documents” window to display the menu and click [Paste].



The image files are copied to the “My Documents” folder.

- When an image with the same file name exists in the copy destination folder, the overwrite confirmation message appears. When you overwrite an existing image with a new one, the original file data is deleted. To copy an image file to the computer without overwriting, change the file name to a different name and then copy the image file. However, note that if you change the file name (page 78), you may not be able to play back that image with your camera.

Stage 4: Viewing images on your computer

This section describes the procedure for viewing copied images in the “My Documents” folder.

1 Click [Start] → [My Documents].



The contents of the “My Documents” folder are displayed.

- If you are not using Windows XP, double-click [My Documents] on the desktop.

2 Double-click the desired image file.



The image is displayed.

To delete the USB connection

Perform the procedures listed below beforehand when:

- Disconnecting the USB cable
- Removing a “Memory Stick Duo”
- Inserting a “Memory Stick Duo” into the camera after copying images from the internal memory
- Turning off the camera

■ For Windows 2000/Me/XP

- ① Double-click  on the taskbar.




Double-click here

- ② Click  (Sony DSC) → [Stop].
- ③ Confirm the device on the confirmation window, then click [OK].
- ④ Click [OK].
The device is disconnected.
- Step 4 is unnecessary for Windows XP.

Image file storage destinations and file names

The image files recorded with your camera are grouped as folders on the “Memory Stick Duo”.

Example: viewing folders on Windows XP



- A** Folder containing image data recorded using a camera not equipped with the folder creating function
- B** Folder containing image data recorded using this camera
When no new folders are created, there are folders as follows:
 - “Memory Stick Duo”; “101MSDCF” only
 - Internal memory; “101_SONY” only
- You cannot record any images to the “100MSDCF” folder. The images in these folders are available only for viewing.
- You cannot record/playback any images to the “MISC” folder.
- Image files are named as follows. □□□□ stands for any number within the range from 0001 to 9999. The numerical portions of the name of a movie file recorded in movie mode and its corresponding index image file are the same.
 - Movie files: MOV0□□□□.MPG
 - Index image files that are recorded when you record movies: MOV0□□□□.THM
- For more information about folders, see pages 49 and 63.

Viewing image files stored on a computer with your camera (using a “Memory Stick Duo”)

This section describes the process using a Windows computer as an example. When an image file copied to a computer no longer remains on a “Memory Stick Duo”, you can view that image again on the camera by copying the image file on the computer to a “Memory Stick Duo”.

- Step 1 is not necessary if the file name set with your camera has not been changed.
- You may be unable to play back some images depending on the image size.
- When an image file has been processed by a computer or when the image file was recorded using a model other than that of your camera, playback on your camera is not guaranteed.
- When there is no folder, first create a folder with your camera (page 63) and then copy the image file.

1 Right-click the image file, then click [Rename]. Change the file name to “DSC0□□□□.”


Enter a number from 0001 to 9999 for □□□□.



- If the overwrite confirmation message appears, enter a different number.
- An extension may be displayed depending on the computer settings. The extension for still images is JPG, and the extension for movies is MPG. Do not change the extension.

2 Copy the image file to the “Memory Stick Duo” folder in the following order.

- ① Right-click the image file, then click [Copy].
- ② Double-click [Removable Disk] or [Sony MemoryStick] in [My Computer].
- ③ Right-click the [□□□MSDCF] folder in the [DCIM] folder, then click [Paste].
 - □□□ stands for any number within the range from 100 to 999.



Using the “Cyber-shot Viewer” (supplied)

You can use still images and movies from the camera more than ever by taking advantage of the software.

This section summarizes the “Cyber-shot Viewer” and gives basic instructions.

“Cyber-shot Viewer” overview

With the “Cyber-shot Viewer” you can:

- Import images shot with the camera and display them on the monitor.
- Organize images on the computer on a calendar by shooting date to view them.
- Retouch, print, and send still images as e-mail attachments, change the shooting date, and more.
- For details on the “Cyber-shot Viewer”, refer to the Help.

To access the Help, click [Start] → [Programs] (in Windows XP, [All Programs]) → [Sony Picture Utility] → [Help] → [Cyber-shot Viewer].

Starting and exiting the “Cyber-shot Viewer”

Starting the “Cyber-shot Viewer”

Double-click the  (Cyber-shot Viewer) icon on the desktop.

Or, from the Start menu: Click [Start] → [Programs] (in Windows XP, [All Programs]) → [Sony Picture Utility] → [Cyber-shot Viewer].

Exiting the “Cyber-shot Viewer”

Click  button in the top right corner of the screen.

Basic instructions

Follow these steps to import and view images from the camera.

Importing images

1 Make sure “Media Check Tool”* is running.


* “Media Check Tool” is a program that automatically detects and imports images when a “Memory Stick” is inserted or when the camera is connected.

Look for a  (Media Check Tool) icon in the taskbar.

- If there is no  icon: Click [Start] → [Programs] (in Windows XP, [All Programs]) → [Sony Picture Utility] → [Cyber-shot Viewer] → [Tools] → [Media Check Tool].

2 Connect the camera to your computer with the USB cable.


After the camera is automatically detected, the [Import Images] screen is displayed.



- If you will use the “Memory Stick” slot, first refer to page 72.
- In Windows XP, if the AutoPlay Wizard appears, close it.

3 Import the images.

To start importing images, click the [Import] button.




By default, images are imported into a folder created in “My Pictures” that is named with the date of importing.

- For instructions on changing the “Folder to be imported”, refer to page 82.

Viewing images

1 Checking imported images

When importing is complete, the “Cyber-shot Viewer” starts. Thumbnails of the imported images are displayed.




- The “My Pictures” folder is set as the default folder in “Viewed folders”.
- You can double-click a thumbnail to display the image by itself.


2 Viewing images in “Viewed folders” arranged by shooting date on a calendar

- ① Click the [Calendar] tab.
Years when images were shot are listed.
- ② Click the year.
Images shot that year are displayed, arranged on the calendar by shooting date.
- ③ To display images by month, click the desired month.
Thumbnails of images shot that month are displayed.
- ④ To display images by time, click the desired date.
Thumbnails of images shot that day are displayed, arranged by hour.


Year display screen



Month display screen




Hour display screen



- To list images from a particular year or month, click that period on the left of the screen.

3 Displaying individual images


On the hour display screen, double-click a thumbnail to display the image by itself in a separate window.



- You can edit displayed images by clicking the  toolbar button.

Displaying images in full-screen mode

To display a slide show of current images in full-screen mode, click the  button.




- To play or pause the slide show, click the  button on the lower left of the screen.
- To stop the slide show, click the  button on the lower left of the screen.

Other functions

Preparing images stored on the computer for viewing

To view them, register the folder that contains the images as one of the “Viewed folders”.

From the [File] menu, choose [Register Viewed Folders...] to display the settings screen for “Viewed folders” registration.




Click the [Add...] button, and then specify the folder with images for importing to register the folder as a “Viewed folder.”

- Images in any subfolders of “Viewed folders” are also registered.

Changing the “Folder to be imported”

To change the “Folder to be imported”, access the “Import Settings” screen.

To display the “Import Settings” screen, choose [Image Import Settings...] from the [File] menu.



Choose the “Folder to be imported”.

- You can specify the “Folder to be imported” from folders registered as “Viewed folders.”

Updating image registration information

To update image information, choose [Update Database] from the [Tools] menu.

- Updating the database may take a while.
- If you rename image files or folders in “Viewed folders”, they cannot be displayed with this software. In this case, update the database.

Uninstalling the “Cyber-shot Viewer”

- ① Click [Start] → [Settings] → [Control Panel]. Double-click [Add/Remove Programs]. (For Windows XP, click [start] → [Control Panel], then double-click [Add or Remove Programs].)
- ② Select [Sony Picture Utility] and click [Change/Remove] (For Windows XP, [Remove]) to uninstall.

Technical Support

Additional information on this product and answers to frequently asked questions can be found at the Sony Customer Support Website.
<http://www.sony.net/>

Using your Macintosh computer

You can copy images to your computer.

- The supplied software is not compatible with Macintosh computers.

Recommended computer environment

The following environment is recommended for a computer connected to the camera.

Recommended environment for copying images

OS (pre-installed): Mac OS 9.1, 9.2 or Mac OS X (v10.0 or later)

USB jack: Provided as standard

Notes on connecting your camera to a computer

- Operations are not guaranteed for all the recommended computer environments mentioned above.
- If you connect two or more USB devices to a single computer at the same time, some devices, including your camera, may not operate depending on the types of USB devices you are using.
- Operations are not guaranteed when using a USB hub.
- Connecting your camera using a USB interface that is compatible with Hi-Speed USB (USB 2.0 compliant) allows advanced transfer (high speed transfer) as this camera is compatible with Hi-Speed USB (USB 2.0 compliant).
- There are three modes for a USB connection when connecting a computer, [Auto] (default setting), [Mass Storage] and [PTP] modes. This section describes the [Auto] and [Mass Storage] as examples. For details on [PTP], see page 67.
- When your computer resumes from the suspend or sleep mode, communication between your camera and your computer may not recover at the same time.

Copying and viewing images on a computer

1 Prepare the camera and a Macintosh computer.

Perform the same procedure as that described in “Stage 1: Preparing the camera and the computer” on page 72.

2 Connect the USB cable.

Perform the same procedure as that described in “Stage 2: Connecting the camera and your computer” on page 73.

3 Copy image files to the Macintosh computer.

- ① Double-click the newly recognized icon → [DCIM] → the folder where the images you want to copy are stored.
 - ② Drag and drop the image files to the hard disk icon.
The image files are copied to the hard disk.
- For details on the storage location of the images and file names, see page 77.

4 View images on the computer.

Double-click the hard disk icon → the desired image file in the folder containing the copied files to open that image file.

To delete the USB connection

Perform the procedures listed below beforehand when:

- Disconnecting the USB cable
- Removing a “Memory Stick Duo”
- Inserting a “Memory Stick Duo” into the camera after copying images from the internal memory
- Turning off the camera

Drag and drop the drive icon or the icon of the “Memory Stick Duo” to the “Trash” icon.

The camera is disconnected from the computer.

- If you are using Mac OS X v10.0, perform the procedure above after you have turned your computer off.

Technical Support

Additional information on this product and answers to frequently asked questions can be found at the Sony Customer Support Website.
<http://www.sony.net/>



How to print still images

When you print images shot in [16:9] mode, both edges may be cut off, so be sure to check before printing (page 102).

Printing directly using a PictBridge compliant printer (page 86)



You can print images by connecting the camera directly to a PictBridge compliant printer.

Printing directly using a “Memory Stick” compliant printer




You can print images with a “Memory Stick” compliant printer. For details, see the operating instructions supplied with the printer.

Printing using a computer



You can copy images to a computer using the “Cyber-shot Viewer” software in the supplied CD-ROM and print the images.

Printing at a shop (page 89)



You can take a “Memory Stick Duo” containing images shot with your camera to a photo printing service shop. You can make a  (Print order) mark on images that you want to print out in advance.

Printing images directly using a PictBridge compliant printer

Even if you do not have a computer, you can print images shot using your camera by connecting the camera directly to a PictBridge compliant printer.



- “PictBridge” is based on the CIPA standard. (CIPA: Camera & Imaging Products Association)


In single-image mode

You can print a single image on a printing sheet.



In index mode


You can print several images at a reduced size on a printing sheet. You can print a set of either the same images (①) or different images (②).



- An index print function may not be provided depending on the printer.
- The quantity of images that can be printed as an index image differ depending on the printer.
- You cannot print movies.
- If the  indicator flashes on the screen of the camera for about five seconds (error notification), check the connected printer.

Stage 1: Preparing the camera

Prepare the camera to connect it to the printer via a USB connection. When connecting the camera to a printer that is recognized when [USB Connect] is set to [Auto], Stage 1 is unnecessary.




- It is recommended to use fully charged Nickel-Metal Hydride batteries or an AC Adaptor (not supplied) to prevent the power from turning off partway through printing.

1 Press MENU to display the menu.

2 Press on the control button to select (Setup).

3 Select (Setup2) with , then select [USB Connect] with .


4 Select [PictBridge] with , then press .



The USB mode is set.


Stage 2: Connecting the camera to the printer

1 Connect the camera to the printer.



2 Turn on your camera and the printer.

After the connection is made, the indicator appears.



The camera is set to playback mode, then an image and the print menu appear on the screen.

Stage 3: Printing

Regardless of what the mode dial is set to, the print menu appears when you complete Stage 2.

1 Select the desired printing method with $\blacktriangle/\blacktriangledown$ on the control button, then press $\bullet$.

[All In This Folder]

Prints all the images in the folder.

[DPOF image]

Prints all the images with a (Print order) mark (page 89) regardless of the displayed image.

[Select]

Selects images and prints all the selected images.

① Select the image you want to print with $\blacktriangle/\blacktriangledown$, then press $\bullet$.

The mark appears on the selected image.

- To select other images, repeat this procedure.


② Select [Print] with $\blacktriangledown$, then press $\bullet$.

[This image]

Prints a displayed image.

- If you select [This image] and set [Index] to [On] in step 2, you can print a set of the same images as an index image.

2 Select print settings with $\blacktriangle/\blacktriangledown/\blacktriangleleft/\blacktriangleright$.



[Index]

Select [On] to print as an index image.

[Size]

Select the size of the printing sheet.

[Date]

Select [Day&Time] or [Date] to insert the date and time on images.

- When you choose [Date], the date will be inserted in the order you select (→ *step 2 in “Read This First”*). This function may not be provided depending on the printer.

Quantity

When [Index] is set to [Off]:

Select the number of sheets of an image that you want to print. The image will be printed as a single image.

When [Index] is set to [On]:


Select the number of sets of images that you want to print as an index image. If you selected [This image] in step 1, select the number of the same image you want to print side by side on a sheet as an index image.

- The designated number of images may not all fit onto a single sheet depending on the quantity of images.

3 Select [OK] with ▼/►, then press ●.


The image is printed.

- If the  (PictBridge Connecting) icon appears on the screen, do not disconnect the USB cable.



When you connect the camera to a printer, the print menu appears. Select [Cancel] to turn off the print menu, then proceed as follows.

- ① Press  (Index).
The index screen appears.
- ② Press MENU to display the menu.
- ③ Select [] (Print) with ►, then press ●.
- ④ Select the desired printing method with ▲/▼, then press ●.



[Select]

Selects images and prints all the selected images.

Select the image you want to print with ▲/▼/◀/▶, then press ● to display the ✓ mark. (Repeat this procedure to select other images.) Then, press MENU.

[DPOF image]

Prints all the images with a  (Print order) mark regardless of the displayed image.

[All In This Folder]

Prints all the images in the folder.

- ⑤ Perform steps 2 and 3 of “Stage 3: Printing” (page 87).

To print other images

After step 3, select [Select] and the desired image with ▲/▼, then perform from step 1.

To print images on the index screen

Perform “Stage 1: Preparing the camera” (page 86) and “Stage 2: Connecting the camera to the printer” (page 87), then proceed with the following.

Printing at a shop

You can take a “Memory Stick Duo” containing images shot with your camera to a photo printing service shop. As long as the shop supports photo printing services conforming to the DPOF, you can make a  (Print order) mark on images in advance so that you do not need to reselect them when you print them out at the shop.

- You cannot print images stored in the internal memory at a print shop directly from the camera. Copy the images to a “Memory Stick Duo”, then take the “Memory Stick Duo” to the print shop.

What is DPOF?


DPOF (Digital Print Order Format) is a function allowing you to make a  (Print order) mark on images of “Memory Stick Duo” that you want to print out later.

- You can also print the images with the  (Print order) mark using a printer that conforms to the DPOF (Digital Print Order Format) standard or using a PictBridge compliant printer.
- You cannot mark movies.
- When you mark images shot in Multi Burst mode, all the images are printed on one sheet divided into 16 panels.

When taking a “Memory Stick Duo” to a shop

- Consult your photo printing service shop as to what types of “Memory Stick Duo” they handle.
- If a “Memory Stick Duo” is not handled by your photo printing service shop, copy the images you want to print out to other medium such as a CD-R and take it to the shop.
- Be sure to take the Memory Stick Duo Adaptor with it.
- Before you take image data to a shop, always copy (back up) your data to a disk.
- You cannot set the number of prints.

Marking in single-image mode




1 Display the image you want to print.

2 Press MENU to display the menu.

3 Select DPOF with , then press .

A  (Print order) mark is marked on the image.



4 To mark other images, display the desired image with , then press .

To remove the mark in single-image mode

Press  in step 3 or 4.

Marking in index mode

- 1 Display the index screen (→ *step 6 in "Read This First"*).
- 2 Press MENU to display the menu.
- 3 Select DPOF with ◀/▶, then press ●.
- 4 Select [Select] with ▲/▼, then press ●.

- You cannot add a  mark in [All In This Folder].

- 5 Select the image you want to mark with ▲/▼/◀/▶, then press ●.

A green  mark appears on the selected image.



- 6 Repeat step 5 to mark other images.
- 7 Press MENU.
- 8 Select [OK] with ▶, then press ●.

The  mark turns white.

To cancel, select [Cancel] in step 4 or select [Exit] in step 8, then press ●.

To remove the mark in index mode

Select the images from which you want to remove the mark in step 5, then press ●.

To remove all the marks in the folder

Select [All In This Folder] in step 4, then press ●. Select [Off], then press ●.




Viewing images on a TV screen

You can view images on a TV screen by connecting the camera to a TV.

Turn off both your camera and the TV before connecting the camera and the TV.

1 Connect the camera to the TV.




- If your TV has stereo input jacks, connect the audio plug (black) of the A/V cable to the left audio jack.

2 Turn on the TV and set the TV/video input switch to “video.”

- For details, see the operating instructions supplied with the TV.

3 Press to turn on the camera.



Images shot with the camera appear on the TV screen.

Press   on the control button to select the desired image.

- When using your camera abroad, it may be necessary to switch the video signal output to match that of your TV system (page 68).

On TV color systems

If you want to view images on a TV screen, you need a TV with a video input jack the A/V cable. The color system of the TV must match that of your digital still camera. Check the following lists for the TV color system of the country or region where the camera is used.

NTSC system

Bahama Islands, Bolivia, Canada, Central America, Chile, Colombia, Ecuador, Jamaica, Japan, Korea, Mexico, Peru, Surinam, Taiwan, the Philippines, the U.S.A., Venezuela, etc.

PAL system

Australia, Austria, Belgium, China, Czech Republic, Denmark, Finland, Germany, Holland, Hong Kong, Hungary, Italy, Kuwait, Malaysia, New Zealand, Norway, Poland, Portugal, Singapore, Slovak Republic, Spain, Sweden, Switzerland, Thailand, United Kingdom, etc.

PAL-M system

Brazil

PAL-N system

Argentina, Paraguay, Uruguay

SECAM system

Bulgaria, France, Guiana, Iran, Iraq, Monaco, Russia, Ukraine, etc.



If you experience trouble with your camera, try the following solutions.

❶ Check the items on pages 94 to 104.

If a code such as “C/E:□□:□□” appears on the screen, see page 105.

❷ Remove the batteries, and insert the batteries again after about one minute, and turn on the power.

❸ Initialize the settings (page 66).

❹ Consult your Sony dealer or local authorized Sony service facility.

Please understand that you give your consent that the contents of the internal memory may be checked when you send your camera to be repaired.

Batteries and power

The battery remaining indicator is incorrect, or sufficient battery remaining indicator is displayed but the power runs out too quickly.

- This phenomenon occurs when you use the camera in an extremely hot or cold location (page 110).
- The batteries are discharged. Install charged batteries (→ *step 1 in “Read This First”*).
- The poles of batteries or the terminals of the battery cover are dirty so the batteries are not charged sufficiently. Clean them with a cotton swab, etc. (page 110).
- The displayed time remaining differs from the current one due to the memory effect (page 110), etc. Fully discharge and then charge the batteries to correct the display.
- The batteries are dead (page 110). Replace them with new ones.

The batteries run down too quickly.

- Charge them sufficiently (→ *step 1 in “Read This First”*).
- You are using the camera in an extremely cold location (page 110).
- The batteries are dead (page 110). Replace them with new ones.

Cannot turn on the camera.

- Install the batteries correctly (→ *step 1 in “Read This First”*).
- The batteries are discharged. Install charged batteries (→ *step 1 in “Read This First”*).
- The batteries are dead (page 110). Replace them with new ones.

The power turns off suddenly.

- If you do not operate the camera for about three minutes while the power is on, the camera turns off automatically to prevent wearing down the batteries. Turn on the camera again (→ *step 2 in “Read This First”*).
- The batteries are discharged. Install charged batteries (→ *step 1 in “Read This First”*).

Shooting still images/movies

The LCD screen does not turn on even when the power is turned on.

- The finder is turned on. Turn on the LCD screen using the FINDER/LCD button (→ *step 5 in “Read This First”*).

The image is not clear on the finder.

- Adjust the diopter scale properly using the finder adjustment dial (→ *step 5 in “Read This First”*).

Your camera cannot record images.

- Check the free capacity of the internal memory or “Memory Stick Duo” (page 28). If it is full, do one of the following:
 - Delete unnecessary images (→ *step 6 in “Read This First”*).
 - Change the “Memory Stick Duo”.
 - You are using the “Memory Stick Duo” with the write-protect switch, and the switch is set to the LOCK position. Set the switch to the recording position (page 108).
 - You cannot record images while charging the flash.
 - When shooting a still image, set the mode dial to a position other than .
 - Set the mode dial to  when shooting movies.
 - The image size is set to [640(Fine)] when recording movies. Do one of the following:
 - Set the image size to other than [640(Fine)].
 - Insert a “Memory Stick PRO Duo” (page 108).
-

The subject is not visible on the screen.

- Your camera is set to the Playback mode. Press the shutter button halfway down, change the mode dial position, or press  to change to the recording mode (→ *step 6 in “Read This First”*).
-

Recording takes a long time.

- The NR slow shutter function is activated (page 24). This is not a malfunction.
-

The image is out of focus.

- The subject is too close. Record in the close-up (Macro) recording mode. Make sure to position the lens farther away from the subject than the shortest shooting distance, approximately 2 cm (13/16 inches) (W)/90 cm (35 1/2 inches) (T), when shooting. (→ *step 5 in “Read This First”*).
 -  (Twilight) or  (Landscape) is selected in the Scene mode when shooting still images.
 - The manual focus is selected. Select the auto focus mode using the FOCUS button (page 38).
 - Confirm that the setting of [Conversion Lens] is correct (page 61).
-

Precision digital zoom does not function.

- Set [Digital Zoom] to [Precision] (page 57).
 - This function cannot be used while shooting movies.
-

Smart zoom does not function.

- Set [Digital Zoom] to [Smart] (page 57).
- This function cannot be used when:
 - The image size is set to [7M] (DSC-H5), [6M] (DSC-H2) or [3:2].
 - Shooting in Multi Burst mode.
 - Shooting movies.

The flash does not work.

- The flash is set to  (Flash forced off) (→ *step 5 in “Read This First”*).
- You cannot use the flash when:
 - Multi Burst, Burst or Exposure Bracket mode is selected (page 41).
 -  (High Sensitivity) or  (Twilight) is selected in the Scene Selection.
 - When the mode dial is set to .
- Set the flash to  (Flash forced on) when  (Beach),  (High-Speed Shutter) or  (Landscape) is selected in the Scene Selection.

The close-up (Macro) function does not work.

-  (Twilight) or  (Landscape) is selected in the Scene mode (page 34).

The date and time are not displayed.

- While shooting, the date and time are not displayed. Only during playback, the date and time are displayed.

The date and time are recorded incorrectly.

- Set the correct date and time (→ *step 2 in “Read This First”*).

The F value and shutter speed flash when you press and hold the shutter button halfway down.

- The exposure is incorrect. Correct the exposure (page 37, → *step 5 in “Read This First”*).

The image is too dark.

- You are shooting a subject with a light source behind the subject. Select the metering mode (page 45) or adjust the exposure (page 37, → *step 5 in “Read This First”*).
- When the brightness of the LCD backlight (DSC-H5 only)/finder backlight is too low, adjust the brightness of the backlight (page 65, → *step 5 in “Read This First”*).
- The LCD screen becomes dark while the flash is being charged (DSC-H5 only).

The image is too bright.

- You are shooting a spotlighted subject in a dark location such as on a stage. Adjust the exposure (page 37, → *step 5 in “Read This First”*).
- When the brightness of the LCD backlight (DSC-H5 only)/finder backlight is too high, adjust the brightness of the backlight (page 65, → *step 5 in “Read This First”*).

The image colors are not correct.

- Adjust the [Color Mode] to [Normal] (page 45).

Vertical streaks appear when you are shooting a very bright subject.

- The smear phenomenon is occurring. This phenomenon is not a malfunction.

Noise appears in the image when you view the screen in a dark place.

- The camera is attempting to increase the visibility of the screen by temporarily brightening the image under conditions of low illumination. There is no effect on the recorded image.

The eyes of the subject come out red.

- Set [Red Eye Reduction] in the  (Setup) menu to [On] (page 58).
- Shoot the subject at a distance closer than the recommended shooting distance using the flash (→ *step 5 in "Read This First"*).
- Light the room and shoot the subject.

The outline of the subject turns blue.

- The peaking function is worked (page 40). If it is unnecessary, cancel the function.

Dots appear and remain on the screen.

- This is not a malfunction. These dots are not recorded (page 8, → *"Read This First"*).

Cannot shoot images in succession.

- The internal memory or "Memory Stick Duo" is full. Delete unnecessary images (→ *step 6 in "Read This First"*).
- The battery level is low. Install charged batteries.

Viewing images

Refer to "Computers" (page 98) in conjunction with the following items.

Your camera cannot play back images.

- Press  (→ *step 6 in "Read This First"*).
- The folder/file name has been changed on your computer (page 78).
- When an image file has been processed by a computer or when the image file was recorded using a model other than that of your camera, playback on your camera is not guaranteed.
- The camera is in USB mode. Delete the USB connection (page 76).

The date and time are not displayed.

-  (Screen display switch) button is turned off (page 27).

The image appears rough right after playback starts.

- The image may appear rough right after playback starts due to image processing. This is not a malfunction.

Color unevenness may appear during video playback.

- This is not a malfunction. The recorded images are not affected.

Images are not displayed on the screen.

- Remove the A/V cable if the cable is connected (page 91).

The image does not appear on the TV screen.

- Check [Video Out] to see if the video output signal of your camera is set to the color system of your TV (page 68).
- Check whether the connection is correct (page 91).
- The USB cable is connected to the USB jack. Disconnect it according to the correct procedure (page 76).

Deleting/Editing images

Your camera cannot delete an image.

- Cancel the protection (page 51).
- You are using the “Memory Stick Duo” with the write-protect switch, and the switch is set to the LOCK position. Set the switch to the recording position (page 108).

You have deleted an image by mistake.

- Once you have deleted an image, you cannot restore it. We recommend that you protect images (page 50), or use the “Memory Stick Duo” with the write-protect switch and set the switch to the LOCK position (page 108) to prevent accidental erasure.

The resizing function does not work.

- You cannot resize movies and Multi Burst images.

You cannot display a DPOF (Print order) mark.

- You cannot display DPOF (Print order) marks on movies.

You cannot cut a movie.

- The movie is not long enough to cut (shorter than about two seconds).
- Cancel the protection (page 51).
- Still images cannot be cut.

Computers

You do not know if the OS of your computer is compatible with the camera.

- Check “Recommended computer environment” on page 70 for Windows, and page 83 for Macintosh.

Your computer does not recognize your camera.

- Turn on the camera (→ *step 2 in “Read This First”*).
- When the battery level is low, install the charged batteries (→ *step 1 in “Read This First”*), or use the AC Adaptor (page 19).
- Use the USB cable (supplied) (page 73).
- Disconnect the USB cable, and connect it again firmly. Make sure that “USB Mode Mass Storage” is displayed (page 73).
- Set [USB Connect] to [Mass Storage] in the  (Setup) menu (page 67).
- Disconnect all equipment other than the camera, the keyboard and the mouse from the USB jacks of your computer.
- Connect the camera directly to your computer without passing through a USB hub or other device (page 73).
- The software (supplied) is not installed. Install the software (page 71).
- Your computer does not properly recognize the device because you connected the camera and your computer with the USB cable before you installed the software (supplied). Delete the erroneously recognized device from your computer, then install the software (see the next item).

The “Removable disk” icon does not appear on the computer screen when you connect your computer to the camera.

- Follow the procedure below to install the USB driver again. The following procedure is for a Windows computer.
 - 1 Right-click [My Computer] to display the menu, then click [Properties].
The “System Properties” screen appears.
 - 2 Click [Hardware] → [Device Manager].
 - For Windows Me, click the [Device Manager] tab.
 The “Device Manager” appears.
 - 3 Right-click [ Sony DSC], then click [Uninstall] → [OK].
The device is deleted.
 - 4 Install the software (supplied) (page 71).
The USB driver is also installed.

You cannot copy images.

- Make the USB connection by properly connecting the camera with your computer (page 73).
- Follow the designated copy procedure for your OS (pages 73, 83).
- When you shoot images with a “Memory Stick Duo” formatted by a computer, you may not be able to copy the images to a computer. Shoot using a “Memory Stick Duo” formatted by your camera (page 63).

After making a USB connection, “Cyber-shot Viewer” does not start automatically.

- Start “Media Check Tool” (page 79).
- Make the USB connection after the computer is turned on (page 73).

The image cannot be played back on a computer.

- If you are using “Cyber-shot Viewer,” refer to the Help.
- Consult the computer or software manufacturer.

The image and sound are interrupted by noise when you view a movie on a computer.

- You are playing back the movie directly from the internal memory or the “Memory Stick Duo”. Copy the movie to the hard disk of your computer, then play back the movie from the hard disk (page 72).

You cannot print an image.

- Check the printer settings.

Images once copied to a computer cannot be viewed on the camera.

- Copy them to a folder recognized by the camera, such as “101MSDCF” (page 77).
- Operate correctly (page 78).

Cyber-shot Viewer

Images are not displayed correctly.

- Make sure the folder of the images is registered in “Viewed folders”. If the images are not displayed even if the folder is registered in “Viewed folders”, update the database (page 82).

You cannot find images imported.

- Look in the “My Pictures” folder.
- If you have changed the default settings, refer to “Changing the “Folder to be imported”” on page 82 and check what folder is used for importing.

You want to change the “Folder to be imported”.

- Access the “Import Settings” screen to change “Folder to be imported”. You can specify a different folder after using “Cyber-shot Viewer” to register it in “Viewed folders” (page 79).

All imported images are displayed on the calendar with the date January 1.

- The date has not been set on the camera. Set the date on the camera (→ *step 2 in “Read This First”*).

“Memory Stick Duo”

Cannot insert a “Memory Stick Duo”.

- Insert it in the correct direction (→ *step 3 in “Read This First”*).

Cannot record on a “Memory Stick Duo”.

- You are using the “Memory Stick Duo” with the write-protect switch, and the switch is set to the LOCK position. Set the switch to the recording position (page 108).
- The “Memory Stick Duo” is full. Delete unnecessary images (→ *step 6 in “Read This First”*).
- Insert a “Memory Stick PRO Duo” (page 28) when recording movies with the image size set to [640(Fine)].

Cannot format a “Memory Stick Duo”.

- You are using the “Memory Stick Duo” with the write-protect switch, and the switch is set to the LOCK position. Set the switch to the recording position (page 108).

You have formatted a “Memory Stick Duo” by mistake.

- All the data on the “Memory Stick Duo” is deleted by formatting. You cannot restore it. We recommend that you set the write-protect switch on the “Memory Stick Duo” to the LOCK position to prevent accidental erasure (page 108).

“Memory Stick PRO Duo” is not recognized by a computer with a “Memory Stick” slot.

- Check whether the computer and the card reader support “Memory Stick PRO Duo”. Users of computers and card readers made by companies other than Sony should contact those manufacturers.
- If “Memory Stick PRO Duo” is not supported, connect the camera to the computer (page 72). The computer recognizes the “Memory Stick PRO Duo”.

Internal memory

The camera or your computer cannot play back the data in the internal memory.

- There is a “Memory Stick Duo” inserted in the camera. Remove it (→ *step 4 in “Read This First”*).

Cannot record images using the internal memory.

- There is a “Memory Stick Duo” inserted in the camera. Remove it (→ *step 4 in “Read This First”*).

The free capacity of the internal memory does not increase even when you copy the data stored in the internal memory to a “Memory Stick Duo”.

- The data is not deleted after copying. Execute the [Format] command (page 62) to format the internal memory after copying the data.

Cannot copy the data stored in the internal memory to a “Memory Stick Duo”.

- The “Memory Stick Duo” is full. Check the capacity (32 MB or more recommended).

Cannot copy the data on the “Memory Stick Duo” or the computer to the internal memory.

- Data on a “Memory Stick Duo” or a computer cannot be copied to the internal memory.

Printing

Also see “PictBridge compliant printer” (as follows) in conjunction with the following items.

Images are printed with both edges cut off.

- When you print an image shot with the image size set to [16:9], both edges of the image may be cut off.
- When printing images using your own printer, try canceling the trimming or borderless settings. Consult the printer manufacturer as to whether the printer provides these functions or not.
- When having images printed at a digital print shop, ask the shop whether they can print the images without cutting off both edges.

PictBridge compliant printer

A connection cannot be established.

- The camera cannot be connected directly to a printer that is not compliant with the PictBridge standard. Consult the printer manufacturer as to whether the printer is compliant with PictBridge or not.
- Check that the printer is turned on and can be connected to the camera.
- Set [USB Connect] to [PictBridge] in the  (Setup) menu (page 67).
- Disconnect the USB cable, and connect it again. If an error message is indicated on the printer, refer to the operating instructions supplied with the printer.

Cannot print images.

- Check the USB cable is connected correctly.
- Turn on the printer. For further information, refer to the operating instructions supplied with the printer.
- If you select [Exit] during printing, images may not print. Disconnect and connect the USB cable again. If you still cannot print your images, disconnect the cable, turn the printer off and then on, then connect the cable again.
- Movies cannot be printed.
- Images shot using cameras other than this camera or images modified with a computer may not be printed.

Printing is canceled.

- You disconnected the USB cable before the  (PictBridge Connecting) mark disappears.

Cannot insert the date or print images in the index mode.

- The printer does not provide these functions. Consult the printer manufacturer as to whether the printer provides these functions or not.
- The date may not be inserted in the index mode depending on the printer. Consult the printer manufacturer.

“---- -- --” is printed on the date-inserted part of the image.

- Images that do not have the recording data cannot be printed with the date inserted. Set [Date] to [Off] and print the image again (page 87).

Cannot select the print size.

- Consult the printer manufacturer as to whether the printer can provide the desired size.

Cannot print the image at the size selected.

- If you have changed the paper size after having the USB cable connected, then connect the printer again.
- The print setting of the camera differs from that of the printer. Change the setting of either the camera (page 87) or the printer.

Cannot operate the camera after canceling printing.

- Wait for a while as the printer is carrying out the cancellation. It may take some time depending on the printer.

Others

Your camera does not work.

- Use the type of batteries you can use with this camera (page 110).
- The battery level is low (The  indicator appears). Charge the batteries (→ step 1 in “Read This First”).

The power is on, but the camera does not work.

- The built-in microcomputer is not working properly. Remove the batteries, and then, after one minute, insert the batteries and turn on the camera.

Cannot identify an indicator on the screen.

- See page 22.

The lens gets fogged.

- Moisture condensation has occurred. Turn off the camera and leave it for about an hour before using it (page 112).

The camera becomes warm when you use it for a long time.

- This is not a malfunction.

The lens does not move when you turn off the camera.

- The batteries are discharged. Replace them with charged batteries (→ *step 1* in “*Read This First*”) or use the AC Adaptor (not supplied).

The Clock Set screen appears when you turn on the camera.

- Set the date and time again (→ *step 2* in “*Read This First*”).

Warning indicators and messages

Self-diagnosis display

If a code starting with a letter of the alphabet appears, your camera has a self-diagnosis display. The last two digits (indicated by □□) will differ depending on the state of the camera.

If you are unable to solve the problem even after trying the following corrective actions a few times, your camera may need repair. Contact your Sony dealer or local authorized Sony service facility.

C:32:□□

- There is trouble with your camera's hardware. Turn the power off and on again.

C:13:□□

- The camera cannot read or write data on the "Memory Stick Duo". Either turn off and on the camera or re-insert the "Memory Stick Duo" several times.
- The internal memory has experienced a format error, or an unformatted "Memory Stick Duo" is inserted. Format the internal memory or the "Memory Stick Duo" (pages 62, 63).
- The inserted "Memory Stick Duo" cannot be used with your camera, or the data is damaged. Insert a new "Memory Stick Duo" (page 108).

E:61:□□

E:62:□□

E:91:□□

E:92:□□

- A camera malfunction has occurred. Initialize the camera (page 66), then turn the power on again.

Messages

If the following messages appear, follow the instructions.

Lens cap attached

- Remove the lens cap.

Turn the power off and on again

- A problem with the lens has caused an error.



- The battery level is low. Charge the batteries immediately (→ *step 1 in "Read This First"*). Depending on the conditions of use or the type of battery, the indicator may flash even though there are still 5 to 10 minutes of remaining battery time left.

System error

- Turn the power off and then on again (→ *step 2 in "Read This First"*).

Internal memory error

- Turn the power off and then on again (→ *step 2 in "Read This First"*).

Reinsert the Memory Stick

- Insert the "Memory Stick Duo" correctly.
- The inserted "Memory Stick Duo" cannot be used in your camera (page 108).
- The "Memory Stick Duo" is damaged.
- The terminal section of the "Memory Stick Duo" is dirty.

Memory Stick type error

- The inserted "Memory Stick Duo" cannot be used in your camera (page 108).

Format error

- Format the media again (pages 62, 63).

Memory Stick locked

- You are using the “Memory Stick Duo” with the write-protect switch, and the switch is set to the LOCK position. Set the switch to the recording position (page 108).

No memory space in internal memory

No memory space in Memory Stick

- Delete unnecessary images or files (→ *step 6 in “Read This First”*).

Read only memory

- Your camera cannot record or delete images on this “Memory Stick Duo”.

No file

- No images have been recorded in the internal memory.

No file in this folder

- No images have been recorded in this folder.
- You did not operate correctly when copying images from your computer (page 78).

Folder error

- A folder with the same first three digit number already exists on the “Memory Stick Duo” (For example: 123MSDCF and 123ABCDE). Select another folders, or create a new folder (page 63).

Cannot create more folders

- The folder with a name beginning with “999” exists on the “Memory Stick Duo”. You cannot create any folders if this is the case.

Cannot record

- The camera cannot record images in the selected folder. Select a different folder (page 64).

File error

- An error occurred while the image was playing back.

File protect

- Cancel the protection (page 51).

Image size over

- You are playing back an image of a size that cannot be played back on your camera.

Cannot divide

- The movie is not long enough to be divided (shorter than about two seconds).
- The file is not a movie.

Invalid operation

- You are trying to play back a file that is not compatible with the camera.



(Vibration warning indicator)

- Camera shake may occur due to insufficient light. Use the flash, turn on the anti-blur function, or mount the camera on a tripod to secure the camera.

640(Fine) is not available

- 640(Fine) size movies can be recorded only using a “Memory Stick PRO Duo”. Insert a “Memory Stick PRO Duo” or set the image size to a size other than [640(Fine)].

Enable printer to connect

- [USB Connect] is set to [PictBridge], however the camera is connected to a non-PictBridge compliant device. Check the device.
- The connection is not established. Disconnect the USB cable, and connect it again. If an error message is indicated on the printer, refer to the operating instructions supplied with the printer.

Connect to PictBridge device

- You tried to print images before the printer connection was established. Connect to a PictBridge compliant printer.

No printable image

- You tried to execute [DPOF image] without placing a DPOF (Print order) mark on the image(s).
- You tried to execute [All In This Folder] while a folder that holds only movies was selected. You cannot print movies.

Printer busy

Paper error

No Paper

Ink error

Low Ink

No Ink

- Check the printer.

Printer error

- Check the printer.
- Check if the image you want to print is corrupted.



- The data transmission to the printer may not be completed yet. Do not disconnect the USB cable.

Processing

- The printer is canceling the current print job. You cannot print until it is finished. This may take time, depending on the printer.



On the “Memory Stick”

A “Memory Stick” is a compact, portable IC recording medium. The types of “Memory Stick” that can be used with this camera are listed in the table below. However, proper operation cannot be guaranteed for all “Memory Stick” functions.

“Memory Stick” type	Recording/ Playback
Memory Stick (without MagicGate)	—
Memory Stick (with MagicGate)	—
Memory Stick Duo (without MagicGate)	○
Memory Stick Duo (with MagicGate)	○*1*2
MagicGate Memory Stick	—
MagicGate Memory Stick Duo	○*1
Memory Stick PRO	—
Memory Stick PRO Duo	○*1*2*3

*1 “Memory Stick Duo”, “MagicGate Memory Stick Duo” and “Memory Stick PRO Duo” are equipped with MagicGate functions. MagicGate is copyright protection technology that uses encryption technology. Data recording/playback that requires MagicGate functions cannot be performed with this camera.


*2 Supports high-speed data transfer using a parallel interface.

*3 640(Fine) size movies can be recorded.

- A “Memory Stick Duo” formatted with a computer is not guaranteed to operate with this camera.
- Data read/write speeds differ depending on the combination of the “Memory Stick Duo” and the equipment used.

Notes on using a “Memory Stick Duo” (not supplied)

- You cannot record, edit or delete images if you slide the write-protect switch to LOCK with a fine-tipped object.



Some “Memory Stick Duo” cards do not have a write-protect switch. On “Memory Stick Duo” with this switch, the position and shape may vary depending on the “Memory Stick Duo”.

- Do not remove the “Memory Stick Duo” while reading or writing data.
- Data may be corrupted in the following cases:
 - When the “Memory Stick Duo” is removed or the camera is turned off during a read or write operation
 - When the “Memory Stick Duo” is used in locations subject to static electricity or electrical noise
- We recommend backing up important data.
- Do not press down hard when you write down on the memo area.
- Do not attach a label on the “Memory Stick Duo” itself nor on a Memory Stick Duo Adaptor.
- When you carry or store the “Memory Stick Duo”, put it in the case supplied with it.
- Do not touch the terminal section of the “Memory Stick Duo” with your hand or a metal object.
- Do not strike, bend or drop the “Memory Stick Duo”.
- Do not disassemble or modify the “Memory Stick Duo”.
- Do not expose the “Memory Stick Duo” to water.
- Do not leave the “Memory Stick Duo” within the reach of small children. They might accidentally swallow it.

- Do not use or store the “Memory Stick Duo” under the following conditions:
 - High temperature locations such as the hot interior of a car parked in direct sunlight
 - Locations exposed to direct sunlight
 - Humid locations or locations with corrosive substances present

Notes on using the Memory Stick Duo Adaptor (not supplied)

- To use a “Memory Stick Duo” with a “Memory Stick” compliant device, be sure to insert the “Memory Stick Duo” into a Memory Stick Duo Adaptor. If you insert a “Memory Stick Duo” into a “Memory Stick” compliant device without a Memory Stick Duo Adaptor, you might not be able to remove it from the device.
- When inserting a “Memory Stick Duo” into a Memory Stick Duo Adaptor, make sure the “Memory Stick Duo” is inserted facing in the correct direction, then insert it all the way in. Incorrect insertion may result in a malfunction.
- When using a “Memory Stick Duo” inserted into a Memory Stick Duo Adaptor with a “Memory Stick” compliant device, make sure that the Memory Stick Duo Adaptor is inserted facing the correct direction. Note that improper use may damage the equipment.
- Do not insert a Memory Stick Duo Adaptor into a “Memory Stick” compliant device without a “Memory Stick Duo” attached. Doing so may result in malfunction of the unit.

Note on using “Memory Stick PRO Duo” (not supplied)

“Memory Stick PRO Duo” with a capacity up to 2 GB have been confirmed to operate properly with this camera.

On the battery charger and the batteries

■ On the battery charger

- Do not charge any other batteries except Sony Nickel-Metal Hydride batteries in the battery charger supplied with your camera. If you try to charge any other type of battery (e.g., manganese batteries, alkaline batteries, primary lithium batteries, or Ni-Cd batteries) than the batteries specified, those batteries may leak, overheat, or explode, causing the danger of burns or other injuries.
- Remove the charged batteries from the battery charger. If you keep charging them, there is a danger of leaks, excessive heat, explosions, or electric shock.
- When charging a high capacity battery other than the supplied battery using the supplied battery charger, the full capacity of the battery may not be available.
- When the CHARGE lamp flashes, this may indicate a battery error or that batteries other than the specified type have been inserted. Check that the batteries are the specified type. If the batteries are the specified type, remove all the batteries, replace them with new ones or another ones and check if the battery charger operates correctly. If the battery charger operates correctly, a battery error may have occurred.
- If the battery charger is dirty, charging may not be performed successfully. Clean the battery charger with dry cloth, etc.

Batteries you can and cannot use with your camera

Battery type	A	B	C
HR 15/51:HR6 (size AA) Nickel-Metal Hydride batteries ¹⁾²⁾	○	○	○
LR6 (size AA) alkaline batteries ²⁾	—	○	—
ZR6 (size AA) Oxy Nickel Primary Battery ²⁾	—	○	—
Lithium batteries	—	○	—
Manganese batteries	—	—	—
Ni-Cd batteries	—	—	—

A: supplied

B: supported

C: rechargeable

¹⁾NH-AA-2DB twin pack, etc.

²⁾Before using batteries, read the following precaution for each type of battery.

As for unsupported batteries, operating performance cannot be ensured if voltage drops or other problems are caused by the nature of the battery.

■ On Nickel-Metal Hydride batteries

- Do not peel off the external seals or damage the batteries. Never use batteries from which the seals have been partially or completely removed, or batteries that have been split in any way. These may cause leakage, explosion, or heat-up of the battery, and personal scald or injury may be caused. These may cause a malfunction of the battery charger.
- Always carry the Nickel-Metal Hydride batteries in the supplied battery case. Otherwise, metallic objects may short the + and - ends, resulting in the risk of heating or fire.
- If the poles of the Nickel-Metal Hydride batteries are dirty, the batteries may not charge properly. Wipe them with a dry cloth, etc.
- At the time of purchase, or when the Nickel-Metal Hydride batteries have not been used for a long time, they may not full charge. This is typical of this type of battery, and is not a malfunction. If this happens, repeatedly using

up the batteries fully, and then recharging them should correct the problem.

- If you recharge Nickel-Metal Hydride batteries before fully using up the existing charge, the low battery warning may be displayed sooner than expected. This is called the “memory effect.”* If this problem occurs, charging the batteries only after using up the existing charge will correct it.

* The “memory effect” - the situation in which the capacity of the battery is temporarily lowered.

- To use up the batteries completely, put the camera in the slide show mode (page 51) and leave it that way until the batteries are used up.
- Do not mix new and used batteries.
- Do not expose the battery to water. The battery is not water-resistant.

Effective use of Nickel-Metal Hydride batteries

- Batteries are discharged even when they are not used. We recommend you charge the batteries just before using them.
- Battery performance decreases in low-temperature surroundings, and the battery life is shortened under such circumstances. To use the battery longer, we recommend you keep the battery in its case in a pocket close to your body to warm it, and insert it in your camera just before you start shooting.
- If the poles of the batteries and the terminals on the battery cover of the camera are dirty, the battery life may be extremely shortened. Occasionally wipe them with a dry cloth, etc. to keep them clean.
- If you shoot a lot using the flash and the zoom, the battery power will be used up faster.
- We recommend having spare batteries handy for two or three times the expected shooting time, and try test shooting before actually using the camera.

Battery life of Nickel-Metal Hydride batteries

- The battery life is limited. The battery capacity decreases little by little as you use it more and more, and as time passes. When the battery operating time seems to have been considerably shortened, a probable cause is that the batteries have reached the end of their life.

- The battery life varies depending on storage, operating conditions, and environment, and is different for each battery.

On alkaline batteries/Oxy Nickel Primary Battery

- Alkaline batteries/Oxy Nickel Primary Battery cannot be charged.
- Alkaline batteries/Oxy Nickel Primary Battery have a shorter life compared to the supplied Nickel-Metal Hydride batteries. For this reason, the power may turn off even though the battery remaining indicator shows sufficient battery life remaining.
- Battery performance differs greatly depending on the manufacturer and the type of battery, and in some cases the battery life may be extremely short. This is especially true at low temperatures, and you may not be able to shoot at temperatures below 5°C (41°F).
- Do not mix new and old batteries.
- The battery remaining indicator does not display the correct information when using alkaline batteries/Oxy Nickel Primary Battery.
- Due to characteristics of alkaline batteries/Oxy Nickel Primary Battery, there is a large difference between the available shooting time and the available playback time. For this reason, the camera may turn off with the lens portion extended when you switch the mode dial. In this case, replace the batteries with new ones or fully charged Nickel-Metal Hydride batteries.

Precautions

■ Do not use/store the camera in the following places

- In an extremely hot, dry or humid place
In places such as in a car parked in the sun, the camera body may become deformed and this may cause a malfunction.
- Under direct sunlight or near a heater
The camera body may become discolored or deformed, and this may cause a malfunction.
- In a location subject to rocking vibration
- Near strong magnetic place
- In sandy or dusty places
Be careful not to let sand or dust get into the camera. This may cause the camera to malfunction, and in some cases this malfunction cannot be repaired.

■ On cleaning

Cleaning the LCD screen

Wipe the screen surface with an LCD cleaning kit (not supplied) to remove fingerprints, dust, etc.

Cleaning the lens

Wipe the lens with a soft cloth to remove fingerprints, dust, etc.

Cleaning the camera surface

Clean the camera surface with a soft cloth slightly moistened with water, then wipe the surface with a dry cloth. Do not use the following as they may damage the finish or the casing.

- Chemical products such as thinner, benzene, alcohol, disposable cloths, insect repellent, sunscreen or insecticide, etc.
- Do not touch the camera with the above on your hand.
- Do not leave the camera in contact with rubber or vinyl for a long time.

■ On operating temperatures

Your camera is designed for use under the temperatures between 0 and 40°C (32 and 104°F) (In case of Alkaline battery/Oxy Nickel Primary Battery, the temperatures are between 5 and 40°C (41 and 104°F).) . Shooting in extremely cold or hot places that exceed this range is not recommended.

■ On moisture condensation

If the camera is brought directly from a cold to a warm location, moisture may condense inside or outside the camera. This moisture condensation may cause a malfunction of the camera.

Moisture condensation occurs easily when:

- The camera is brought from a cold location such as a ski slope into a warmly heated room.
- The camera is taken from an air-conditioned room or car interior to the hot outdoors, etc.

How to prevent moisture condensation

When bringing the camera from a cold place to a warm place, seal the camera in a plastic bag and allow it to adapt to conditions at the new location over about an hour.

If moisture condensation occurs

Turn off the camera and wait about an hour for the moisture to evaporate. Note that if you attempt to shoot with moisture remaining inside the lens, you will be unable to record clear images.

■ On the internal rechargeable battery

This camera has an internal rechargeable battery for maintaining the date and time and other settings regardless of whether the power is on or off.

This rechargeable battery is continually charged as long as you are using the camera. However, if you use the camera for only short periods, it discharges gradually, and if you do not use the camera at all for about one month it becomes completely discharged. In this case, be sure to charge this rechargeable battery before using the camera.

However, even if this rechargeable battery is not charged, you can still use the camera as long as you do not record the date and time.

Charging method of the internal rechargeable battery

Insert charged batteries in the camera, or connect the camera to a wall outlet (wall socket) using the AC Adaptor (not supplied), and leave the camera for 24 hours or more with the power off.

Charging method of the battery

→ *step 1 in "Read This First"*

Specifications

Camera

[System]

Image device	DSC-H5 7.20 mm (1/2.5 type) color CCD, Primary color filter DSC-H2 7.18 mm (1/2.5 type) color CCD, Primary color filter
Total pixel number of camera	DSC-H5 Approx. 7 410 000 pixels DSC-H2 Approx. 6 183 000 pixels
Effective pixel number of camera	DSC-H5 Approx. 7 201 000 pixels DSC-H2 Approx. 6 003 000 pixels
Lens	Carl Zeiss Vario-Tessar 12× zoom lens f = 6.0 – 72.0 mm (36 – 432 mm when converted to a 35 mm still camera) F2.8 – 3.7
Exposure control	Automatic exposure, Shutter speed priority, Aperture priority, Manual exposure, Scene Selection (7 modes)
White balance	Automatic, Daylight, Cloudy, Fluorescent, Incandescent, Flash, One push
File format (DCF compliant)	Still images: Exif Ver. 2.21 JPEG compliant, DPOF compatible Movies: MPEG1 compliant (Monaural)
Recording media	Internal Memory (30 MB) “Memory Stick Duo”
Flash	Flash range (ISO set to Auto): approx. 0.3 m to 9.0 m (11 7/8 inches to 29 feet 6 3/8 inches) (W)/approx. 0.9 m to 6.8 m (35 1/2 inches to 22 feet 3 3/4 inches) (T)
Viewfinder	Electric viewfinder (color)

[Input and Output connectors]

A/V OUT jack (Monaural)	Minijack Video: 1 Vp-p, 75 Ω unbalanced, sync negative Audio: 327 mV (at a 47 k Ω load) Output impedance 2.2 k Ω
USB jack	mini-B
USB communication	Hi-Speed USB (USB 2.0 compliant)

[LCD screen]

LCD panel	DSC-H5 7.5 cm (3.0 type) TFT drive DSC-H2 5.1 cm (2.0 type) TFT drive
Total number of dots	DSC-H5 230 400 (960×240) dots DSC-H2 84 960 (354×240) dots

[Finder]

Panel	0.5 cm (0.2 type) color
Total number of dots	Approx. 200 000 dots equivalent

[Power, general]

Power	HR 15/51:HR6 (size AA) Nickel-Metal Hydride batteries (2), 2.4 V LR6 (size AA) alkaline batteries (2), 3 V ZR6 (size AA) Oxy Nickel Primary Battery (2), 3 V AC-LS5K AC Adaptor 4.2 V
Power consumption (during shooting with the LCD screen)	DSC-H5 1.4 W DSC-H2 1.1 W
Operating temperature	0 to 40°C (32 to 104°F)
Storage temperature	–20 to +60°C (–4 to +140°F)

Dimensions	113.2×83.0×94.0 mm (4 1/2 inches × 3 3/8 inches × 3 3/4 inches) (W/H/D, excluding protrusions)
Mass	DSC-H5 Approx. 554 g (1 lb 3.5 oz) (including two batteries, shoulder strap, adaptor ring, lens hood, lens cap, etc.) DSC-H2 Approx. 537 g (1 lb 2.9 oz) (including two batteries, shoulder strap, adaptor ring, lens hood, lens cap, etc.)
Microphone	Electret condenser microphone
Speaker	Dynamic speaker
Exif Print	Compatible
PRINT Image Matching III	Compatible
PictBridge	Compatible

BC-CS2A/CS2B Ni-MH battery charger

Power requirements	AC 100 to 240 V, 50/60 Hz, 3 W
Output voltage	AA: DC 1.4V 400 mA × 2 AAA: DC 1.4 V 160 mA × 2
Operating temperature	0 to +40°C (+32 to +104°F)
Storage temperature	-20 to +60°C (-4 to +140°F)
Dimensions	Approx. 71×30×91 mm (2 7/8×1 3/16×3 5/8 inches) (W/H/D)
Mass	Approx. 90 g (3 oz)

Design and specifications are subject to change without notice.



Index

A

- A/V cable 91
- AC Adaptor 19
 - *step 1 in "Read This First"*
- Accessories supplied
 - *in "Read This First"*
- Adaptor ring 20
- AE/AF lock indicator
 - *step 5 in "Read This First"*
- AF Illuminator 59
- AF Mode 57
- AF range finder frame 38
- AF range finder frame indicator 38
- Aperture 14, 36
- Auto adjustment mode
 - *step 5 in "Read This First"*
- Auto Focus 13
- Auto power-off function
 - *step 2 in "Read This First"*
- Auto Review 59

B

- B&W 45
- Backlight 65
 - *step 5 in "Read This First"*
- Batteries 110
 - Battery life 31
 - Charging
 - *step 1 in "Read This First"*
 - Insert/Remove
 - *step 1 in "Read This First"*
 - Remaining indicator
 - *step 1 in "Read This First"*
- Batteries you can use 110

- Battery charger 110
 - *step 1 in "Read This First"*
- Beach
 - *step 5 in "Read This First"*
- Beep 65
- Blur 13
- Bracket Step 47
- Brightness of image
 - *step 5 in "Read This First"*
- BRK 41
- Burst 41

C

- C AF 57
- Camera 1 57
- Camera 2 60
- CD-ROM 71
- Center AF 38
- Center-weighted metering 45
- Change REC. Folder 64
- Charging batteries
 - *step 1 in "Read This First"*
- Cleaning 112
- Clock Set 68
- Cloudy 46
- Color 16
- Color Mode 45
- Compression ratio 17
- Computer 69
 - Copying images 72, 83
 - Macintosh 83
 - Recommended environment 70, 83
 - Software 71, 79

- Viewing image files stored on a computer with your camera 78
- Windows 69

Connecting

- Computer 73
- Printer 87
- TV 91
- Continuous 57
- Contrast 48
- Conversion lens 21
- Copy 64
- Copying images to your computer 72
- Create REC. Folder 63
- Cyber-shot Viewer 79

D

- Daylight 46
- Delete
 - *step 6 in "Read This First"*
 - Format 62, 63
- Digital Zoom 57
- Divide 53
- DPOF 89

E

- Effective pixels 114
- Electronic transformer
 - *step 1 in "Read This First"*
- EV 37
 - *step 5 in "Read This First"*
- EVF Backlight 65
- Expanded Focus 60
- Exposure 14
- Extension 77, 78

F

- File name 77

File Number	67
File storage destination	77
Finder	
→ step 5 in “Read This First”	
Fine	47
Flash	46
Flash forced off	
→ step 5 in “Read This First”	
Flash forced on	
→ step 5 in “Read This First”	
Flash Level	48
Flash mode	
→ step 5 in “Read This First”	
Flash Sync	60
Flexible Spot AF	39
Fluorescent	46
Focus	13
Folder	49
Changing	64
Creating	63
Format	62, 63
Function Guide	58

H

High Sensitivity	
→ step 5 in “Read This First”	
High-Speed Shutter	
→ step 5 in “Read This First”	
Histogram	27, 38
Holding the camera	
→ step 5 in “Read This First”	

I

Identifying parts	18
Image file storage destinations and file names	77
Image quality	16, 47

Image size	16
→ step 4 in “Read This First”	
Incandescent	46
Index mode printing	86
Index screen	
→ step 6 in “Read This First”	
Indicator	see “Screen”
Initialize	66
Install	71
Internal memory	29
Internal Memory Tool	62
Internal rechargeable battery	
.....	112
Interval	48
ISO	14, 15, 47

J

JPG	77
-----------	----

L

Landscape	
→ step 5 in “Read This First”	
Language	65
→ step 2 in “Read This First”	
LCD Backlight (DSC-H5 only)	65
LCD Screen	see “Screen”

M

M AF	57
Macintosh computer	83
Recommended environment	83
Macro	
→ step 5 in “Read This First”	
Mains lead	
→ step 1 in “Read This First”	
Manual exposure	37

Manual focus	38
Mass Storage	67
“Memory Stick Duo”	108
Insert/Remove	
→ step 3 and 4 in “Read This First”	
Number of images/recording time	28
Write-protect switch	108
Memory Stick Tool	63
Menu	43
Items	44
Shooting	45
Viewing	49
Metering Mode	45
Moisture condensation	112
Monitor	57
MPG	77
Multi Burst	41
Multi-pattern metering	45
Multipoint AF	38

N

Natural	45
NR slow shutter	24
NTSC	68
Number of images/Recording time	28

O

One Push	46
One Push Set	46
Optical zoom	57
→ step 5 in “Read This First”	
OS	70, 83
Overexposure	14

P

PAL	68
PC	see “Computer”

Peaking	40
PictBridge	86
Pixel	16
Playback zoom	
→ <i>step 6 in "Read This First"</i>	
Portrait	
→ <i>step 5 in "Read This First"</i>	
Power cord	
→ <i>step 1 in "Read This First"</i>	
Precautions	112
Precision digital zoom	57
Pressing halfway down	13
→ <i>step 5 in "Read This First"</i>	
Print	85
Index mode	86
Single-image mode	86
Print order mark	89
Printing at a shop	89
Printing directly	86
Program auto mode	33
Protect	50
PTP	67

R

Red Eye Reduction	58
Resize	52
Rewind/Fast forward	
→ <i>step 6 in "Read This First"</i>	
Rotate	53

S

S AF	57
Scene Selection	34
→ <i>step 5 in "Read This First"</i>	

Screen	
Changing the display	27
EVF Backlight	65
Indicator	22
LCD Backlight	65
Self-diagnosis display	105
Self-timer	
→ <i>step 5 in "Read This First"</i>	
Sepia	45
Set the clock	
→ <i>step 2 in "Read This First"</i>	
Setup	48, 55, 56
Camera 1	57
Camera 2	60
Internal Memory Tool	62
Memory Stick Tool	63
Setup 1	65
Setup 2	67
Setup 1	65
Setup 2	67
Sharpness	48
Shooting	
Movie	
→ <i>step 5 in "Read This First"</i>	
Still image	
→ <i>step 5 in "Read This First"</i>	
Shooting menu	45
Shooting movies	
→ <i>step 5 in "Read This First"</i>	
Shoulder strap	20
Shutter speed	14, 36
Single	57
Single-image mode	
printing	86
Slide	51
Slow synchro	
→ <i>step 5 in "Read This First"</i>	

Smart zoom	57
Software	79
Specifications	114
Spot metering	45
Spot metering cross hairs	45
Standard	47
STEADY SHOT	61

T

Trimming	55
Troubleshooting	93
TV	91
Twilight	
→ <i>step 5 in "Read This First"</i>	
Twilight Portrait	
→ <i>step 5 in "Read This First"</i>	

U

Underexposure	14
USB cable	73, 87
USB Connect	67
Using your camera abroad	
→ <i>step 1 in "Read This First"</i>	

V

VGA	
→ <i>step 4 in "Read This First"</i>	
Video Out	68
Viewing	
Movie	
→ <i>step 6 in "Read This First"</i>	
Still image	
→ <i>step 6 in "Read This First"</i>	
Viewing menu	49
Vivid	45
Volume	
→ <i>step 6 in "Read This First"</i>	

W

Warning indicators and messages	105
WB	46
White balance	46
Windows computer	69
Recommended environment	70
Write-protect switch	108

Z

Zoom	
→ step 5 in “Read This First”	

Trademarks

- **Cyber-shot** is trademarks of Sony Corporation.
- “Memory Stick”,  “Memory Stick PRO”, **MEMORY STICK PRO**, “Memory Stick Duo”, **MEMORY STICK DUO**, “Memory Stick PRO Duo”, **MEMORY STICK PRO DUO**, “MagicGate”, and **MAGIC GATE** are trademarks of Sony Corporation.
- Microsoft, Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Macintosh and Mac OS are trademarks or registered trademarks of Apple Computer, Inc.
- Intel, MMX, and Pentium are trademarks or registered trademarks of Intel Corporation.
- In addition, system and product names used in this manual are, in general, trademarks or registered trademarks of their respective developers or manufacturers. However, the TM or ® marks are not used in all cases in this manual.

