

USER MANUAL

JUICE EXTRACTOR

Model Number - **SINJ60SCK**



SINGER[®]
TECHNOLOGIES
AT HOME WORLDWIDE

I. Important Safety Instructions

When using electrical appliance, these basic safety precautions should always be followed:


1. Read all instructions before use.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Young children must be supervised to ensure that they do not play with the appliance.
4. If the supply cord is damaged, it must be replaced before further use by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Refer damaged appliances to an authorized repairer..
6. Always use the appliance on a dry & level surface. Do not place on or near a hot gas or electric burner, or any hot surface.
7. Handle the appliance carefully; the blade attachment is sharp. If the unit is dropped or bumped, it may cause the unit to malfunction.
8. Do not let cord hang over edge of table, touch hot surfaces or knot up.
9. To protect against electric shock, do not immerse cord, plug or motor base in water or other liquid.
10. Do not allow water to splash onto the appliance.
11. Always leave the appliance unplugged when not in use, and during assembly/disassembly. Do not use an extension cable, and do not plug it into the same outlet or use it on the same circuit as other appliances, to prevent circuit overload.
12. Use only the attachments provided with this appliance. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or injury to persons.
13. Assemble all parts correctly and securely, before using the machine.
14. Don't insert hands or anything other than the provided Pusher into the Transparent Cover.
15. This machine is suitable for juicing fruit (such as apple) and vegetable. etc. Don't use to cut, chop etc, or to process hard fruit.
16. When cleaning the appliance, don't use abrasive materials or chemicals; they may damage the surface of the appliance.

II. Main function

Juice extraction: apples, bananas, carrot, other fruit, vegetable

III. Overview

1	Pusher	9	Juice Mug
2	Transparent Cover	10	Residue Mug
3	Juicing Blade	11	Blender Jug Cover
4	Middle Body	12	Blender Jug
5	Drive Hub	13	Sealing Ring
6	Lock	14	Blade Unit
7	Base Unit	15	Glass Jar Base
8	Power Switch	16	'Pulse' Button



IV. Operation

1. Before first use, remove the product from packaging and carefully peel off any protective sheets from on the Juicing Blade.
2. Your appliance, on first use, may emit light smoke and some odour for a little while; this is just the excess coating being heated off the inside of the appliance.

This is not cause for concern, and should stop after a few minutes.

[If there is still smoke after 15 mins of continuous use, please contact Customer Service for assistance]

Juicing:

1. Put the Middle Body (4) onto the Base Unit (7).
2. Put Juicing Blade (3) into Drive Hub (5) then push until secure.
3. Place Transparent Cover (2) onto Middle Body (4), then secure the Lock (6). If this Lock is not properly secured, the motor will not run.
4. Place Residue Mug (10) under the residue exit in the Middle Body (4), and place the Juice Mug (9) under the juice exit.
5. Prepare the fruit/vegetable that you are going to juice – only the pulp/soft portions should enter the juicer.
6. Connect the power plug (check that the rating on the unit's rating label matches the power source), then turn the Power Switch (8); the motor starts to work.
7. Put the prepared fruit/vegetable through the opening in the Transparent Cover, then push it in slowly with the Pusher (1).
8. To avoid motor blockage, clean the residue out of the appliance after approximately 1 minute of continuous use, or if you notice the motor struggling.

Blending:

1. Make sure the power plug is disconnected from the power source.
2. Prepare the fruit/vegetable that you are going to blend, and place them in the Blender Jug – only the pulp/soft portions should enter the Jug. For crushing ice, please also add some ice, then install the Blender Jug Cover (11).
3. If the 'Juicing' Assembly is on the Base Unit: Remove Pusher (1), Transparent Cover (2), Juicing Blade (3) and Middle Body (4) first,

then open the Lock arms (6).

4. Place Glass Blender Jug onto Base Unit, aligning with the mark on the Base Unit (7), to turn on the internal safety switch. If the Blender Jug is not seated properly, the motor will not run.
5. Connect the power plug (check that the rating on the unit's rating label matches the power source).
6. Push the Pulse Button (P) 3 to 5 times to start with, then turn the Power Switch to 1 (low speed) or 2 (high speed) until done. The Pulse Button (P) is recommended for crushing ice (when used in short bursts).

Note:

- **Do NOT put your hand or any other objects into the opening in the Transparent Cover or into the Blender Jug, unless the power cord is disconnected from the power source.**
- **For best results during Juicing, push the fruit in slowly with the Pusher.**
- **Turn off the mains power and unplug the power cord before cleaning the Blender Jug or Residue Mug or any part of the appliance – this will prevent accidental motor operation.**
- **For easy cleaning, you can place a plastic bag into the Residue Mug before juicing.**

V. Points to Note

1. The machine should be placed on a flat, horizontal surface during operation, then operate it according to the instructions in this manual.
2. If the Lock is not correctly secured, the motor will not run.
3. This appliance incorporates protection against excessive temperature - when the temperature is too high, the power to the unit will be cut off automatically, and will resume automatically when the motor is cool (after about 15 mins).

4. Do not run the motor for more than 1 minute at a time; if further operation is required, wait for a few minutes for the motor to cool down, then run again.
 5. After use, clean all parts of the unit carefully, then dry thoroughly and store in a cool, dry place.
-

V. Cleaning

1. Before cleaning, switch off the appliance and pull out the power plug from the mains.
 2. Disassemble the parts (1, 2, 3, 4, 9, and 10) and wash them with water.
 3. Dry all parts thoroughly.
 4. Wipe the Main Body with a damp (not dripping wet) cloth, then dry thoroughly with a soft, dry cloth.
-

VI. Technical Specifications

Voltage: AC 240V, 60Hz

Power: 1000W

1000ml Juice Mug

1.8 Litre Blender Jug

Distributed In Aus/NZ by:
BLESSINGTON PTY LTD
Unit 17, 167 Prospect Hwy, Seven Hills
NSW, 2147, Australia
Phone: +61 2 9620 5922