

USER MANUAL

BLENDER

with Coffee Grinder

Model Number - **SIBL500CG01**




SINGER®
TECHNOLOGIES
AT HOME WORLDWIDE

IMPORTANT SAFETY ADVICE

When using any electrical appliance, basic safety precautions should always be followed, including the following:

- Please read through the information and safety advice contained in these operating instructions carefully and thoroughly before you use the blender for the first time.
- This blender is intended only for domestic use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Young children should be supervised to ensure that they do not play with the appliance.
- Make sure that the voltage shown on the rating plate corresponds with that of the mains supply. The rating plate can be found on the bottom of the motor block. The blender is only to be connected to an AC power supply. The motor must always be switched off before the blender is connected with the mains supply.
- Cutting blades are very sharp. Handle the blender with extreme care and caution, especially when cleaning.
- This blender only operates if the blending unit has been inserted into the motor block.
- Before switching on the blender, make sure that the blending unit has been assembled correctly and has been inserted into the motor block with the lid attached.
- Allow any hot liquids to cool to a lukewarm temperature before you pour them into the blending unit.
- Repairs are only to be carried out by a suitably qualified person. Improper adjustments will void your warranty and may cause hazards.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- **Do not immerse the base unit in water or any liquids**
- **Do not operate the appliance without food or liquid.**

Accessories



OPERATION

Before first use

- All parts of the blender are to be thoroughly cleaned before being used for the first time.
- Take out the required length of cable from the cable tidy on the base of the blender and connect to the mains supply.

Assembly of the Glass Jug

1. Put the Sealing Ring (No. 4) on the Blade Unit (No. 5)
2. Put the blade unit with sealing ring into Cup Base (No. 6)
3. Mount the Glass Jug (No. 3) onto the above assembly and twist shut
4. Place the Glass Jug Assembly (No. 9) onto the Motor Base Unit (do not twist the Glass Jug when it is in the Motor Base Unit).
5. Place the foodstuff into the Glass Jug
6. Put the Lid (No. 2) on the Glass Jug and close securely. Place the Inner cover (No. 1) and twist shut

Warning:

1. Hold the Glass Jug during use.
2. Make sure the unit is switched off or unplugged before placing/removing anything from the Motor Base Unit, and switch off the unit after using, by setting the Rotary Switch (No. 8) to "0"

Speed setting

Use

1	For light usage with liquids
2	For more solid consistency – for mixing liquids and solid foodstuffs
"M" setting	For crushing ice, and short powerful impulse movements

- **The appliance operating time must not exceed 30 seconds per use, with a rest period of 1 minute in between uses.**
- The switch does not permanently engage in the 'M' setting. You have to hold the switch in the 'M' setting or turn it repeatedly into the 'M' setting.
- After using the blender, always move the switch into the '0' setting and pull out the mains plug.
- To remove the glass jug just lift it up. You do not have to rotate the glass jug to remove it.

Useful tips

- To achieve the best results when pureeing solid ingredients, place small portions into the glass jug one by one instead of placing a large quantity all at once.
- If you are processing solid ingredients, cut them into small pieces (2-3cm) first.
- When mixing solid ingredients start off first with a small amount of liquid. Gradually add more and more liquid through the opening in the lid.
- Always place your hand on top of the blender when you are operating the device.
- Be careful when processing hot liquids.
- For stirring solid or very thick liquid ingredients we recommend that you use the blender in impulse (M) mode to prevent the blades from becoming stuck.

Assembly of the Coffee Grinder

1. Before First Use: Clean and Dry thoroughly
2. Remove Coffee Grinder Cover (No. 10) from Coffee Grinder Base (No. 11)
3. Put the coffee beans in the Coffee Grinder Base
4. Place the Coffee Grinder Cover onto the Coffee Grinder Base and tighten it following the "Open – Close" directions on the cover
5. Place Coffee Grinder Assembly (No. 12) onto the Motor Base Unit (No. 7) securely

Warning: Make sure the unit is switched off before using, and switch off the unit after using, by setting the Rotary Switch (No. 8) to "0"

CLEANING

Motor Base Unit

Never immerse the motor block in water. Wipe it only with a moist cloth, then dry thoroughly with a clean cloth.

Simple cleaning / rinsing out the assembled glass jug

Empty the glass jug and fill it with water. Place the glass jug on the motor block and turn the switch several times into the 'M' setting. Empty the glass jug and rinse until clean.

Thorough cleaning of the dismantled glass jug

Ensure that the glass jug is completely empty before you unscrew it from the Cup Base. Be careful when handling the cutting blade. All removable parts are suitable for the dishwasher.

Technical information

Voltage/frequency: 230–240V ~ 50Hz 500 watts

Glass jug capacity: 1.5 litres

Rated operating time: 30 seconds

Design and specifications are subject to change without notice.

Distributed In Aus/NZ by:

BLESSINGTON PTY LTD
Unit 17,167 Prospect Hwy,Seven Hills
NSW,2147,Australia
Phone(02) 9620 5922

