



USER MANUAL

BLENDER

MODEL:SIYD2239



SINGER[®]
TECHNOLOGIES
AT HOME WORLDWIDE



Features

- | | | |
|-----------------|-----------------|----------------|
| ① Inner cover | ② Lid | ③ Glass jug |
| ④ Cup Sealing | ⑤ Cutting blade | ⑥ Cup base |
| ⑦ Control Panel | ⑧ Motor block | ⑨ Jug assembly |

Important safety advice

- Please read through the information and safety advice contained in these operating instructions carefully and thoroughly before you use the blender for the first time.
- This blender is intended only for domestic use.
- CAUTION: Ensure that the blender is switched off before removing it from the stand.
- Children should be supervised to ensure that they do not play with the appliance.
- Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Make sure that the voltage shown on the rating plate corresponds with that of the mains supply. The rating plate can be found on the bottom of the motor block. The blender is only to be connected to an AC supply (~). The motor must always be switching off before the blender is connected with the mains supply. (switch in the '0' setting).
- Care shall be taken when handling the sharp cutting blades, emptying the jug and during cleaning.
This blender only operates if the blending unit has been inserted into the motor block.

Before first use

- All parts of the blender are to be thoroughly cleaned before being used for the first time. (see Section: Cleaning).
- Take out the required length of cable from the cable tidy on the base of the blender and connect the device to the mains supply.

Assembly of the Glass jug


1. Put the sealing ring (4) on the inner edge of the blade unit (5).
2. Put the blade unit (5) with sealing ring into the cup base (6).
3. Mount the glass cup (3) onto the cup base unit and tune the cup base unit in clockwise direction until it is fixed.
4. Mount the cup with cup unit onto the base unit.
5. After putting the ingredients in the cup, fix the lid (2) onto the cup by pressing down.
6. Insert the inner cover (1) into the opening of the lid, and tune it in clockwise direction until it is locked.

Inserting the Glass jug

1. Make sure that the blender is switched off (Switch in the '0' setting).
2. Place the Jug assembly (9) onto the motor block (8) and tune it in clockwise direction until it is locked.

Use

1. Place the foodstuff you wish to process into the glass jug.
2. Put the lid on the glass jug and close securely. Place the inner cover into the hole in the lid and turn clockwise to lock.
3. Control panel on the motor block:



Turn rotation knob into “program” position (the three indicator lamps flash):

- (1) Press “ice crush” button , the correlative indicator lamp is ON (the other two indicator lamps are OFF) , The blender will start an automatic programme with different speeds and several pauses.. The programme automatically ends after about 68 seconds. You can Stop. the programme at any time by pressing the stop button ■ . the motor stops working and all the three indicator lamps flash.
- (2) Press “smoothie” button, the correlative indicator lamp is ON (the other two indicator lamps are OFF) The blender will start an automatic programme with different speeds
The programme automatically ends after about 60 seconds. You can Stop. the programme at any time by pressing the stop button ■ .

the motor stops working and all the three indicator lamps flash.

(3) Press “interval” button, the correlative indicator lamp is ON (the other two indicator lamps are OFF) The blender will start an automatic programme with different speeds and several pauses.

The programme automatically ends after about 43 seconds. You can stop the programme at any time by pressing the stop button ■ , the motor stops working and all the three indicator lamps flash.

Turn rotation knob from “MIN” position to “MAX” position:

(the three indicator lamps are OFF)

The “ice crush” button / “smoothie” button/ “interval” button don’t work.

You can set the speed of the high-performance motor to 12 levels between a min and max by using the selector switch on the propulsion unit. To start, select the desired level. Then press the start button ► .

To switch off, either press the stop button ■ or turn the selector switch back to ‘0’ setting..

Attention: The blender will only be switched on if the glass jug is correctly Fitted. A safety shutdown prevents operation without the jug.

Speed setting	Use
rotation knob in “ON” position +interval button	for cleaning
rotation knob in “ON” position +ice crush button	for ice crushing
rotation knob in “ON” position +smoothie button	for sand ice
rotation knob in the position from “MIN” to “MAX”	for mixing liquids and solid foodstuffs

After using the blender, To switch off, either press the stop button ■ or turn the selector switch back to ‘0’ setting and pull out the mains plug. To remove the glass jug just turn it in anticlockwise direction to loose and lift it up.

Useful tips

- To achieve the best results when pureeing solid ingredients, place small portions into the glass jug one by one instead of placing a large quantity all at once.
- If you are processing solid ingredients, cut them into small pieces (2-3cm) first.
- When mixing solid ingredients start off first with a small amount of liquid. Gradually add more and more liquid through the opening in the lid.
- Always place your hand on top of the blender when you are operating the device.
- Be careful when processing hot liquids.
- For stirring solid or very thick liquid ingredients we recommend that you use the blender in impulse mode to prevent the blades from becoming stuck.

Motor block

Never immerse the motor block in water. Wipe it only with a moist cloth.

Simple cleaning/ rinsing out the assembled glass

jug

Empty the glass jug and fill it with water. Place the glass jug on the motor block and allow the motor to run for a few seconds or use the 'interval' function..With a maximum of 1 litre of fresh water and add a few drops of a washing-up liquid. Afterward, thoroughly rinse the entire jar with fresh water.

Thorough cleaning of the dismantled glass jug

Ensure that the glass jug is completely empty before you unscrew the retaining ring. Be careful when handling the cutting blade. All removable parts are suitable for the dishwasher.

We reserve the right to make amendments.

Remove the power plug after use. Never submerge the propulsion unit in Water, but rather only wipe the outside of it with a damp towel.

Distributed In Aus/NZ by:
BLESSINGTON PTY LTD
Unit 17, 167 Prospect Hwy, Seven Hills
NSW, 2147, Australia
Phone: +61 2 8811 1900