

SONY®

α

SLT-A65/SLT-A65V/SLT-A77/SLT-A77V

The new functions provided by this firmware update and their respective operations are described here.

Please refer to the “Instruction Manual,” and the “α Handbook”* contained on the supplied CD-ROM.

* The “α Handbook” is not supplied with the SLT-A77/A77V.

Functions provided

The following new functions are provided by this firmware update.

New items provided	Functions
MOVIE Button	Sets the mode that activates the MOVIE button.

MOVIE Button

Sets whether or not to activate the MOVIE button.

1 MENU →  3 → [MOVIE Button] → desired setting.

	Always	Always activates the MOVIE button.
	Movie Mode Only	Activates the MOVIE button only when the mode dial is set to  (Movie).